# Зип Общепит SERVICE МАЛИЦАL +7(812)987-08-81

# TDR 8 P GAS FIRED ROTISSERIE OVEN

MODELS

Programmable controls TDR 8 P

Gas types: Natural gas G20/25 Propane G31 (Butane G30)



Model TDR 8 P Gas

#### - NOTICE -

This manual is prepared for the use of trained Service Technicians and should not be used by those not properly qualified. If you have attended a training for this product, you may be qualified to perform all the procedures in this manual.

This manual is not intended to be all encompassing. If you have not attended training for this product, you should read, in its entirety, the repair procedure you wish to perform to determine if you have the necessary tools, instruments and skills required to perform the procedure. Procedures for which you do not have the necessary tools, instruments and skills should be performed by a trained technician.

Reproduction or other use of this Manual, without the express written consent of Fri-Jado, is prohibited.



WWW.FRIJADO.COM



# Зип Общепит vsezip.ru +7(812)987-08-81

# EMPTY PAGE





Versions			
Version	Issue date	Remarks	
	dd/mm/yy	17(019)007_00_01	
10/2013	01/10/2013	First release.	
01/2014	01/01/2014	Added reset and small textual changes. Exploded views and electric	
		diagrams changed.	
03/2014	01/03/2014	Working of rotisserie changed. Error 55 explanation. Small other	
		changes.	
11/2014	01/11/2014	New errors, various updates.	



TABLE OF CONTENTS

# Зип Общепит

Index	ezip.ru
General technical data	6
Technical data	0007-00-016
Programming instructions for the TDR 8 P gas	.)907-00-01
The automatic cook correction	
	23
Removal and replacement of parts for the TDR 8	
Right or left side panel	
lop cover	
Operating panel (general)	
Iumble switch reset	
Electric panel	
Operating panel, glass + backplate + keypad	
Power and I/O board	
CPU board	
Replacing of broken buzzer	
Keypad	
Relay	
Safety thermostat with reset	
Door switch	
Halogen lamp holder (customer side)	
Halogen lamp holder (service side)	الا
BIOWER MOTOR	
PT 1000 sensor	
Gas mixture blower	53 دد
Gas purner safety control	
Gas control block	
Ignition/ionization set	
Ring core transformer	
Drive motor	
Door adjustment (left side)	
Door glass inside	
Working of gas fired rotisserie	
Gas technical data	
Timing diagram gas burner safety control	
Sticker on gas burner safety control	
Electrical tests and service procedures	
PT1000 sensor test	
Drive motor, blower and transformer test	
Control location	
Error codes on display	
Gas block Honeywell type VK4115V - 2004	
Ignition/Ionization set	
Temporary bridging of reset switch	
Resetting of gas burner safety control	
Flue gas analyser	
Gas consumption	
Maintenance gas processing	

# тавle of contents Зип Общепит



Parameter listing TDR P	47
Introduction	47
Reaching the parameter menus	47
Manager menu - description of the submenus	50
Service menu - description of the submenus.	51
Adapting parameters	53
Loading software	53
Read and store recipies in the manager menu	54
Read and store recipies and parameters in the service menu	55
Parameter List P	57
General troubleshooting list	58
Troubleshooting for the TDR 8 gas rotisseries	58
Error 55 explanation	60
Exploded views & partlists	67
TDR 8 P Gas - sheet metal work	
TDR 8 P Gas - electrical parts	64
TDR 8 P Gas - doors	66
TDR 8 P Gas - gas parts	68
Electrical diagrams	
Circuit diagram TDR 8 P Gas	
wiring diagram IDK & P Gas	



GENERAL TECHNICAL DATA

# ЗИП ОбЩеПИТ GENERAL TECHNICAL DATA

+/(8|Z)98/-U8-81

This manual covers the TDR 8 P gas fired rotisserie ovens suitable for G 20/25 (natural gas), G 31 (Propane), G30 (Butane) and blend of Propane:Butane 60:40 till 100:0.

• TDR 8 – Oven with eight spits ( 32 to 40 chickens ).

All of the information, illustrations and specifications contained in this manual are based on the latest product information available at the time of printing.

# **TECHNICAL DATA**

Туре	TDR 8
Gas power (KW) Natural gas, Propane, blend Propane:Butane 60:40 - 100:0	14.7
Gas Power (KW) Butane	15.8
Electric power (W)	345
Fuses needed with power connection 230 V, 1N ~5060 Hz (1 phase with zero)	1x 10 A
Standard plug from factory single pole	16A
Net weight (kg)	210
Gross weight (kg)	230
Height (mm)	1065
Width (mm)	1005
Depth (mm)	830

### Tools

- Standard set of tools.
- Metric wrenches, sockets and hex socket key wrenches.
- Multi-meter.
- AC current clamp tester.
- Temperature tester.
- Insulation value tester (Megger).
- Toxicity meter.
- Gas pressure meter.
- Gas consumption/flow meter.
- Field Service Grounding Kit.



# PROGRAMMING INSTRUCTIONS FOR THE TDR 8 P GAS

vsezip.ru

Зип Общепит I

# @p7(/8112)/987-08-81



Кеу	Function
On / Off	Switching the unit On / Off
Undo	Go back to previous menu
List	Recipe / programming modus
Forward	One step ahead in setting
Rotor	Switching the rotor on
ОК	Acknowledge a function or change
Back	One step back in setting



Interface P Eco TDR Version x.x.x





# Chicken 98 99 1 2 3





- 1. Press Start.
- 2. Display shows Fri-Jado logo.

08-81

- 3. Display shows software version.
- 4. Display shows latest cooking program.
- 5. Use the arrow buttons for program selection.
- 6. Display shows selected program.
- 7. Confirm the selected program.
- 8. Display shows pre-heat (only when pre-heat is defined).







- 11. After loading, close the door. A reminder to empty the fat tray appears.
- 12. Press OK to confirm.

program.

- 13. Display show programmed temperature and time (hour : min).
- 14. (Optional) Press OK button for the actual temperature and time (shows about 2 seconds).
- 15. During the last minute the time blinks.
- 16. Display show the remaining time, the interval is 5 seconds.
- 17. Open the door.



LOAD

or START















# ОРЕГАТІОN OPTIONS

# vsezip.ru

- 5.2. Operation options
- 5.2.1. To end a running program.







Chicken				
98 99	1	2	3	

# 5.2.2. Check the actual temperature



1. Press and hold start for 3 seconds.

fri-jado

2. Make a choice with the arrow buttons.

**Note:** Select NO to abort ending the program.

- 3. Confirm the selection. (Within 5 seconds).
- 4. Display shows the last operated program.

- For example: Check the current temperature in program 1 Chicken, step 1.
- 2. Press the OK button.
- 3. The display shows during 3 seconds the actual temperature.

PROGRAMMING INSTRUCTIONS



5.2.3. Check the remaining time in a program



#### 5.2.4. Show all actual program information



- 1. Display shows actual program. (step one is active).
- 2. Press List button.
- 3. Display shows the programmed temperature and time.
- 4. Press List button again for additional information.
- Display shows the programmed steps and remaining times in one overview.
   (Step – temperature – program time – actual time)
  - P: Preheat
  - 1-3: Program step
  - H: Holding
  - C: Cook correction



# vsezip.ru

ощепит





Press the OK button to update the screen (automatically refreshed every 15 seconds).

- 7. Press List button to go back.
- 8. Display returns to the original operating display.

#### 5.2.5. Eco function

1 Chicken

180°C P123

1 Chicken	ECO
180°C P <u>1</u> 23	0:20

0:20

Optional: only available when activated in the service menu.

In the ECO mode the accumulated heat in the cavity will be used to cook the product.

Depending on the settings, the product and program an energy saving of 5% can be achieved.

#### 5.2.6. Cook correction



Optional: only available when activated in the service menu.

Cook correction: Depending on the load of products the cooking time will be automatically adjusted.

The first cook is the reference cook and will be used to fix the correct parameters.

The activation of the cook correction is NOT visible in this display.



### ВИП ОБЩЕПИТ PROGRAMMING

vsezip.ru

#### 6. MANAGER MENU

# 6.1. Manager menu itemsFormula and a stressFormula and a stressFormula and a stressChange pinNewPre-HeatClockNewPre-HeatClock

Edit Delete Copy	Preheat temperature Holding Holding temperature Cook correction* Eco function* Language Big digits Sound preheat Sound step Sound done	Transfer Version USB Reading recipes Store recipes
------------------------	---	--

\* Only visible when selected in the service menu.

#### 6.2. Programming the rotisserie

Possible programming steps:

- Preheat
- Step 1
- Step 2
- Step 3
- Holding



1. Start the unit.









- 2. Logo appears.
- 3. Unit information appears.
- 4. Last used program appears.
- 5. Press the list button.

fri-jado







Preheat functions:

- Y: Yes
- N: No
- C: Continuously







32. Press the OK button to confirm.

<u>ощепит</u>



10 Step 1 Temp 215 °C Time 21 -



10 Step 1 Temp 215 °C Time 210



10 Step 1 Temp 215 °C Time 210  $\leftarrow$   $\checkmark$   $\checkmark$   $\checkmark$ 

10 Step 2 Temp <u>2</u>15 °C

10 Holding Temp <u>8</u>5 °C Time 999 ← ✓ 33. Set the second digit.

34. Press the OK button to confirm.

35. Set the last digit.

36. Press the OK button to confirm.

37. The Step is now completed.

Select the right arrow and press the OK button to go to the next step. Select the left arrow button and press the OK button to go back to the last setting. Select the  $\vee$  and press the OK button to finish programming.

- Program the next step (when required). See step 1 for the procedure.
- 39. After step 3 or when entering no time at step 2 (or 3) the holding step will appear. Set the temperature and time as required.

#### Note:

Set the time to 999 for continuous operating.

Only available when activated (refer to section 6.3).

fri-jado		PROGRAMMING INSTRUCTIONS
		Зип Общепит
		40. When ready programming press the OK button to confirm. <b>40. When ready programming press the OK button to confirm.</b>
10 TES	т	41. Save the finished programs.
	Save Disc	<b>Note:</b> if the program is not saved all changes are lost!
		42. Press the OK button to confirm.
RECIPE	S NEW EDIT	43. The screen returns to the RECIPES menu.
		44. Press back to enter the manager menu.
MA Usb F	ANAGER MENU Programming Para	45. Manager menu appears.
	()	46. Press back to enter the user menu.
Drum 5	stick 6789	47. The last program used is shown.



PROGRAMMING INSTRUCTIONS			
Зип Общепит			
Language: En Change Next	ysez 9. Use 9. Use Previous 9. Pres men	the arrow buttons to select nge, Next or Previous. as back to enter the manager u.	
Language: Englis	h	10. Use the arrow buttons to select Save and press the OK button to confirm. This is valid for software version V1.04-09 or higher. Note: when you select the Undo key the	
Save	Disc. changes wil back to step	l not be saved and you go 94.	
	 10a. Untill s had to press	oftware version V1.03.10 you s the undo key to go to save.	Ð
	11. Use othe	the arrow buttons to select the r settings:	
Big Digits	YES/NO:	Default set at YES	
Sound preheat	Sound T1-T3 Volume 1-4	Default set at T1 Default set at 2	
Sound Step	Sound T1-T3 Volume 1-4	Default set at T2 Default set at 1	
Sound Done	Sound T1-T3 Volume 1-4	Default set at T3 Default set at 3	
Preheat	YES/NO:	Default set at NO	
Preheat Temperature	50-250 °C (122-482 °F)	Default set at 210°C (410°F)	
Holding	YES/NO:	Default set at YES	
Holding Temperature	50-250 °C (122-482 °F)	Default set at 85°C (185°F)	
Cook correction	YES/NO:	Default set at YES	
Eco function	YES/NO:	Default set at YES	
	)		





Press back to enter the manager menu.

Press (again) back to enter the user menu.

# MANAGER MENU: CHANGE PINCODE

#### 6.4. Change pin code

MANAGER MENU Para Change Pin Clock

Pin <u>0</u>000 Enter new code

## 6.5. Clock



SET TIME

12..

## 6.6. Transfer



Insert stick and press enter

## 6.7. Version

Interface P Eco TDR Version x.x.x

- vsezip.ru
  - 1. Manager menu.

fri-jado

- 2. Select Change Pin.
- 3. Press the OK button.
- 4. Enter the new pin code.
- 5. Press the OK button.

- 1. Manager menu.
- 2. Select Clock.
- 3. Press the OK button.
- 4. Set the correct date and time.
- 5. Press the OK button.

- 1. Manager menu.
- 2. Select Transfer.
- 3. Press the OK button.
- 4. Insert stick and press OK.

1. Display shows software version.



*Note:* When reading new programs all existing programs will be deleted.

# ЗИП Общепит THE AUTOMATIC COOK CORRECTION

The automatic cook correction facility will automaticly add or deduct time to the pro grammed cooking time in order to have constant cooking quality.

After programming a new program, the first cooking process will be the "learning" process. It is recommended to do the first cook with a half load.

The program calculates the surface from the diagram below the curved line. (temperature \* time). The result is the so called heat num ber. This heat number is stored into the cook ing program.

All further cooking programs will try to get the same heat number.

The second diagram shows an example with full load. It takes more time for the unit to reach the programmed cooking temperature. See dashed line. The surface above the dashed line represents the missing part of the heat number. The cook correction will put this miss ing part behind the normal cooking time. Therefore extra time is added in order to reach the desired heat number. It is also possible that time is deducted in case a smaller load has been put into the oven.

### Time will be added in case of:

A bigger load. A colder load. (straight from the freezer) A lower gas quality. Somebody opened the door.

## Time will be deducted in case of:

A smaller load. A warmer load. (defrosted) Higher gas quality.

## Note 1:

In case the time or temperature will be changed in the cooking program, the heat number will be adapted with this amount.

*Note 2:* Only if you delete a program or change the name the "learning" process starts again from the beginning.



🗧 fri-jado

The heat number is stored in the cooking program. In case such a program is copied and stored in another rotisserie, the heat number goes with it.

It is possible that in case the program has changed a lot, the cook correction is not able to perform well anymore. In that case the program has to be deleted and repro grammed with the good parameters. It is possible to disable this cook cor rection feature in the service parameters. See "parameter listings" -> "cook correction".



# Зип Общепит

# REMOVAL AND REPLACEMENT OF PARTS FOR THE TDR 8

**WARNING:** Disconnect the electrical power to the machine at the main circuit box. Place a tag on the circuit box indicating the circuit is being serviced.

# **RIGHT OR LEFT SIDE PANEL**



- 1. Remove the screws that secure the panel to the frame.
- 2. Remove the panel.
- 3. Reverse the procedure to install.



# TOP COVER

**OPERATING PANEL (GENERAL)** 

- 1. Remove the right side panel according prior procedure.
- 2. Remove the screws securing both large and small top covers.
- 3. Remove the top cover. (Lift at right side and remove to the left).
- 4. Reverse the procedure to install.





- 1. Remove the right side panel according prior
  - procedures2. Remove the bolt, nut and ring on the top side on the backside of the operating panel.
  - 3. Pull the panel away from the top side.
  - 4. Remove the flatcables and earth cable from the CPU board on the backside.
  - 5. Remove the panel.
  - 6. Reverse the procedure to install.



## ЗИП ООЩЕПИТ TUMBLE SWITCH RESET





# ting panel according prior procedures.

- 22 Remove the wiring
  - 3. Remove the switch by pushing the clamps, on the inside, with a screw driver.
- 4. Reverse the procedure to install.



- 1. Remove the right side panel and operating panel according prior procedures.
- 2. Disconnect the wiring.
- 3. Remove on the front side the 2 screws and on the inside the nut that secure the panel.
- 4. Remove on the inside bottom of the electric panel the bolt and nuts.
- 5. Slide the electric panel backwards to remove this.
- 6. Reverse the procedure to install.

# **OPERATING PANEL, GLASS + BACKPLATE + KEYPAD**





- Remove the right hand panel according prior procedure.
- 2. Remove the operating panel according prior procedure.
- 3. Remove the USB connection, the reset switch and the red indicaton light.
- 4. Remove the 4 nuts and rings on the CPU board and remove the board.
- 5. Reverse the procedure to install.

**Note 1:** For connection flatcable of the keypads see CPU board on page 28.

**Note 2:** For older units with earth wire in right hand bottom corner. Take care that the ring terminal doesn't make contact with with the solder point (see arrow) .Otherwise the illumination of the display and keys can be out.



REMOVAL AND REPLACEMENT OF PARTS

# POWER AND I/O BOARD



## 1. Remove the right side panel according

oprior procedure.\_ o

ющепит

- 2. Disconnect the wiring and flatcable on the board.
- 3. Remove the board from the clips by pinching the clips.
- 4. Reverse the procedure to install.





# CPU BOARD

Before changing the CPU board and display be sure to download (with a USB stick) or write down the grilling programs and the parame ters.

- 1. Remove the right side panel according prior procedure.
- 2. Remove the operating panel according prior procedure.
- 3. Remove the 4 nuts and rings on the CPU board and remove the board.
- 4. Reverse the procedure to install.
- 5. Read the grilling programs and parameters from the USB stick to the CPU board.

*Note 1:* Flatcable keypad must be connected to connector "Touchpanel 1" on CPU board.

**Note 2:** "Touchpanel 2" is flatcable connection for the rotor switch keypad on customer side.

**Note 3:** For older units with earth wire in right hand bottom corner. Take care that the ring terminal doesn't make contact with with the solder point (see arrow) .Otherwise the il-lumination of the display and keys can be out.

# REPLACING OF BROKEN BUZZER



1. Remove the right side panel according prior procedure.

fri-jado

- 2. Remove the operating panel according prior procedure.
  - Stick connector of new buzzer in plug next to the existing broken buzzer (see white arrow).
  - 4. Reverse the procedure to install.

*Note:* buzzer can dangle loosely without any problem.

# KEYPAD



- 1. Remove the right side panel, the operating panel and the CPU board according prior procedures.
- 2. Remove the keypad and degrease the surface of the glass.
- 3. Glue the new keypad on its place with the red connectors on the bottom side.
- 4. Reverse the procedure to install.

**Note 1:** For connection flatcable of the key pads see CPU board on page 28.

**Note 2:** When the keypad is on the panel on customer side you need a long extended flatcable for connection to the CPU board.

RELAY



- V & Remove the right side panel according prior procedure.
  - 2) Loosen the clamp handle.
  - Gently remove the relay.
  - 4. Reverse the procedure to install.

Note: When placing a relay be sure the connecting pins are in place.

# SAFETY THERMOSTAT WITH RESET



Thermostat with automatic reset





Thermostat with manual reset

Remark: The thermostat with manual reset is only used for the following 6 serial numbers. 100064637 and 638 + 100064776 until 779. all other units have a thermostat with automatic reset.

- 1. Remove the rotor and the right side panel according prior procedure.
- 2. Remove the bolts that secure the air guide plate and remove this plate. Lower the plate in vertical position and lift it out of the hinge pins.
- 3. Remove the thermostat-probe from the clip in the oven and guide it outside through the opening in the side wall.
- 4. Disconnect the wiring on the thermostat.
- 5. Remove the screws on the electric panel that secure the thermostat and remove the thermostat.
- 6. Reverse the procedure to install.

Note: Set the new thermostat to its maximum position by turning it clockwise (320°C).



# DOOR SWITCH





ration panel according prior procedures.

fri-jado

- 2 Penrove the 2 screws that secure the switch and remove the switch.
- 2. Disconnect the wiring of the switch.
- 4. Reverse the procedure to install.

*Note:* The contact pin of the switch must run free through the chassis.

# HALOGEN LAMP HOLDER (CUSTOMER SIDE)



- 1. Remove the top cover according prior procedure.
- 2. Remove the wiring of the lamp on the connector.
- 3. Remove the cap nuts that secure the air suction plate and remove this plate.
- 4. Remove the glass and lamp from the lamp holder. Turning direction of glass in counter clockwise.
- 5. Remove the holder. You have to deform the holder to take it out.
- 6. Insert a new holder and click this in.
- 7. Reverse the procedure to install.





# HALOGEN LAMP HOLDER (SERVICE SIDE)





- 1. Remove the top cover according prior procedure.
- 2. Remove the wiring of the lamp on the connector.
- 3. Remove the glass and lamp from the lamp holder. Turning direction of glass is counter clockwise.
- 4. Remove the holder. You have to deform the holder to take it out.
- 5. Insert a new holder and click this in.
- 6. Reverse the procedure to install.

# ВLOWER MOTOR





- 1. Remove the right side panel, the top
- cover and the air suction plate according prior procedures.
- 2. Remove the wing nut on the fan blade and remove fan blade. (Left handed threads).
- 3. Disconnect wiring of the motor.
- 4. Remove the screws that secure the motor and remove the motor.
- 5. Reverse the procedure to install.

*Note:* The blowers are equipped with a capacitor of 1.5uF. Check the direction of rotation of the motor (clockwise, see arrows) and change the wiring if necessary.

# PT 1000 SENSOR



- 1. Remove the right side panel according prior procedure.
- 2. Disconnect the wiring of the sensor.
- 3. Remove the screw that secures the sensor and remove the sensor.
- 4. Reverse the procedure to install.

Note: The wiring cable is an insulated cable with an earthing screen.

# GAS MIXTURE BLOWER





1. Remove the right side panel and small top cover plate according prior procedures.

fri-jado

- 2. Remove the varing from the top of the gas mixture blower.
- 3. Remove the silencer.
- Remove the 4 nuts from the air inlet (A) and the 4 bolts with nuts from the gas inlet (B) and remove the gas mixture blower.
- 5. Remove the screws that secure the venturi to the blower and remove the blower.
- 6. Reverse the procedure to install.

# GAS BURNER SAFETY CONTROL



- 1. Remove the right side panel according prior procedure.
- 2. Remove the screw that secures the burner control on the gas block and remove the burner control by sliding it to the left.
- 3. Remove the screw that secures the plastic cover (see arrow) and remove this cover.
- 4. Remove the wiring from the control.
- 5. Reverse the procedure to install.





# GAS CONTROL BLOCK

- **F**7(
- burner safety control according prior pro-
  - 2698775 08 81
  - 2. Remove the nuts from the pipe clamps to create some clearance.
  - Remove the 4 screws on the top and bottom flange from the gas control block.
  - 4. Remove the wiring.
  - 5. Reverse the procedure to install.

# **IGNITION/IONIZATION SET**







- 2. Remove the insulation around the exhaust pipe.
- 3. Remove the wiring from the set on the gas burner safety control C and A and from the earthing B.
- 4. Remove the nuts that secure the set and remove the set. Replace the gasket.
- 5. Reverse the procedure to install.
- 6. Connect A to A , B to B and C to C. The faston for A is 4.8 mm. The faston for C is 2.8 mm.



# **RING CORE TRANSFORMER**



- 1. Remove the right side panel according prior procedure.
- 2. Remove the wiring from the transformer.
- 3. Remove the screw and nut that secure the transformer and remove the transformer.
- 4. Reverse the procedure to install.

#### 

15 Genove the right side panel and rotor discs according prior procedure.

fri-jado

- 2. Disconnect the wiring of the motor. Check where the wire, marked A is connected.
  - 3. Remove the screws that secure the fan cover and remove the cover.
  - Set the drive arm in a position vertical downwards. This can be done electrically by pushing the rotor key or manually by turning the fan blade by hand.
  - 5. Note down how far the drive arm sticks out from the inner wall (see white arrow).
  - Mark the position of the motor on the support and the support on the side wall with a marker.
  - Remove the bolts that secure the motor and the nuts that secure the motor support and remove the motor.
  - 8. Check the white Teflon ring. Replace this if necessary.
  - Check the position of the red gasket between motor support and the side wall. Replace this if necessary.
  - 10. Install the fan blade of the old motor on the new motor.
  - 11. Reverse the procedure to install.

*Note:* Always make a test run of 15 minutes on maximum temperature to insure the motor is well mounted and adjusted and turns parallel to the side wall.

# DOOR ADJUSTMENT (LEFT SIDE)

- Remove the left side panel according prior procedure.
- 2. Loosen the nuts A of the upper hinge. The door must be closed.
- Loosen the locknut B and adjust the bolt C in or out to adjust the door.
- 4. Tighten the nuts of the hinge and mount the left-hand panel.







#### **ЗИП ООЩЕПИТ** DOOR GLASS INSIDE



- VSIC Lift the inside door upward out of the hinges and place it on a table.
  - 2. Remove the nuts and rings on the profiles of the door.
    - 3. Remove the profiles from the glass.
    - Mount the profiles on the new glass.
      Do not forget the Teflon flange bushes inside the holes.
    - 5. Mount the nuts and rings.
    - 6. Place the door in the hinges.

Note: Tightening of nuts max. 8 Nm.

# DOOR OUTSIDE

- Lift the inner door out of the hinges and lay this aside.
- 2. Remove the left side panel according prior procedure.
- Remove the 2 nuts behind the upper hinge and loosen the locknut according prior procedure. The door must be closed.
- Hold the door on both sides and move this towards yourself, before lifting it out of the hinge on the bottom side. See to it that the washers stay on the hinge. Also remove the top hinge.
- 5. Place the top hinge on the new door.
- Place the new door on the hinge on the bottom side and push the 2 studs on the top hinge through the openings on the top side and screw the nuts on it.
- 7. Adjust the door according prior procedure.

*Note:* Tightening of nuts max. 8 Nm. or 5.9 lbf.ft




# WORKING OF THE GAS FIRED ROTISSERIE

After plugging the unit in always first check the proper polarity for good ignition.



ип Общепит

After starting the rotisserie up with the on/off key the reset will light up. First press this switch for 2 seconds till the light is out. Also the gas mixture blower will turn in low speed for max. 9 minutes in stand by position regulated by the burner control.

After selection of a program and pressing the OK key the PT 1000 temperature sensor measures a temperature below the set temperature and this will activate relay K1 by contact X9 on the Power and I/O board. Relay K1 activates the burner control sequence. This sequence is as follows:

- Activating of low speed of the gas mixture blower to create a rich gas/air mixture for easy and fast ignition.

- Activating of spark plug (max. 5 seconds).

- Activating/opening of the gas valve.

- Activating of the ionisation (measuring of a low Amperage (~35mA) between ionisation pin and burner bed).

- Activating the high speed of the gas mixture blower when the gas is burning and the ionisation measuring is OK.

**Note:** If the speed of the gas mixture blower is not within 5% of the adjusted speed in the burner control there will be no ignition and the red indication light on the reset switch will light up. In this case the blower has to be replaced.

The PT 1000 temperature sensor now takes care of the temperature regulation of the oven, by switching the burner control on and off.

If there is no ignition/burning of the gas/air mixture after 5 seconds of ignition there will be a pause of 5 seconds and after this the ignition sequence will start up for maximum 2 times. If there is still no burning of the gas the burner control will close the gas valve and activates the red indication lamp on the reset switch. By pressing the rest switch for 2 seconds the sequence will start up again.

After ending of a grilling process the gas mixture blower will keep on turning for 9 minutes on an adjusted speed, regulated by the burner control to ensure that there is no gas left in the heat exchanger and is clean. The power on the gas mixture blower is activated by contact X13 on the Power and I/O board which activates relay K2.

After intermediate stopping of the program or when the machine is switched off the gas mixture blower will run also for 9 minutes.

# Note: Gas supply pressure should be between 15 and 50 mbar, depending on the gas type. See table on next page.

Pressure over 60 mbar will damage the gas block. You can check the pressure on the gas block, see page 42. Valves on the gas block can be checked by holding your hand on it, or by holding a steel object on the coil. This will be magnetic after switching in.



(e) n		Sono	
CAC TECH		DATA.	
(745 16(8	INICAL	DAIA	

Gas	Inlet	min pressure (Qn-Hi)	Consumption	Consumption	Specific density
type	pressure	max pressure (Qr. Hi)	kg-ctn-LBS	— m3/h	kg/m3 - lb/cf
	mbar - inch wc - PSI	mbar - inch wc - PSI			5
G20	20 - 8 - 0,3	17 - 7 - 0,25	1,0 - 0,80 - 2.2	1,37	0,718 - 0,044
		25 - 10 - 0,36		-	
G25	25 - 10 - 0,31	17 - 7 - 0,25	1,5 - 1,05 - 3.3	1,78	0,833 - 0,052
		30 - 12 - 0,43			
G30	37 - 15 - 0,54	25 - 10 - 0,36	1,2 - 0,25 - 2.6	0,44	2,701 - 0,168
		55 - 22 - 0,80			
G31	37 - 15 - 0,54	25 - 10 - 0,36	1,0 - 0,29 - 2.2	0,49	2,011 - 0,128
		55 - 22 - 0,36			
LPG	37 - 15 - 0,54	25 - 10 - 0,36	0,70 - 0,27 - 1,5	0,46	1,560 - 0,098
		55 - 22 - 0,36			

# vsezip.ru

Gas type	Orifice mm - inch	Air inlet mm - inch	Power KW - BTU
G20	4,2 - 1/6	18,1 - 17/24	14.7 - 50.000
G25	4,5 - 11/64	18,1 - 17/24	14.7 - 50.000
G30	3,2 - 1/8	18,1 - 17/24	14.7 - 50.000
G31	3,2 - 1/8	18,1 - 17/24	14.7 - 50.000
LPG	3,2 - 1/8	18,1 - 17/24	14.7 - 50.000

Qn = power (inlet) Hi = inferior caloric value LPG should contain at least 50% Propane!

#### TIMING DIAGRAM GAS BURNER SAFETY CONTROL





# STICKER ON GAS BURNER SAFETY CONTROL



#### 24V circuit:

Tacho (nr.1) = White wire to speed regulation gas mixture blower.

Reset (nr.2) = Brown wire to reset knob on side wall.

High limit (nr.3) = Yellow wire to high limit thermostat.

APS (nr.4) = Not connected.

PWM (nr.5) = Black wire to speed regulation gas mixture blower.

BL (nr.9) = Blue wire to speed regulation gas mixture blower.

O (nr.10) = Orange wire to high limit thermostat.

GR (nr.13) = Grey wire to speed regulation gas mixture blower.

#### 230 V circuit:

HD (nr. 1) = White wire to relay K1. On/off regulation by PT sensor

Alarm (nr. 2) = Brown wire to red external alarm indication on side wall and alarm indication on burner safety control.

F (nr.3) = Grey wire to stand-by speed of gas mixture blower.

Burn on (nr.4) = Not connected.

L (nr.5) = Orange wire for live connection 230V.

Nr. 7 to 10 = Black-blue- red-yellow wires for neutral.

# ЗИП Общепит

# ELECTRICAL TESTS AND SERVICE PROCEDURES

**WARNING:** Disconnect the electrical power to the machine at the main circuit box. Place a tag on the circuit box indicating the circuit is being serviced.

## PT1000 SENSOR TEST

Temperature		Resistance $\Omega$
°F	°C	± 5 Ohms
32	0	1000
60	16	1062
70	21	1082
80	27	1106
90	32	1124
100	38	1148
125	52	1202
150	65	1252
200	94	1362
250	121	1464
350	177	1674
450	233	1880

**Note:** When testing the resistance of the sensor remove the wiring. Refer to the removal and replacement part of the manual on how to do this.

- 1. Remove the wiring from the sensor.
- 2. Connect a temperature sensor to the probe for comparison.
- 3. Test the probe with an Ohmmeter.

### DRIVE MOTOR, BLOWER AND TRANSFORMER TEST

Note: When testing the resistance remove the wiring.

Туре	Description	Voltage	Resistance Ω
TDR 8	Drive motor	230	Between white A and white wire ~ 234 Between white A and brown wire ~ 117 Between white and brown wire ~ 117
TDR 8	Blower rotisserie	230	Between blue and brown wire ~ 310 Between blue and black wire ~ 190 Between brown and black wire ~ 500
TDR 8	Transformer	230/12	Between white and white wire ~9 Between white and other colors infinite Between yellow and red wire ~0,5 Between grey and blue wire ~0,5 Between yellow and grey infinite Between yellow and blue wire infinite Between grey and red wire infinite Between red and blue wire infinite





#### ERROR CODES ON DISPLAY

**Error 11:** Full contact between wires of PT sensor. Temp. indication on display doesn't go up. **Error 33:** No connection between wires of PT sensor. Temp. indication on display 317°C/602°F. **Error 55:** Heating defect. Temperature rise in °C/minute of the PT sensor during cooking of the products is under the minimum value as indicated in parameter "Temp. grad." See also the parameterlist on page 57 and explanation on page 52.

**Error 77:** If the expected heat number is more than 20% lower than the stored heat number in the cooking program. This error does not result in a complete shut down of the rotisserie, but is stored in the fault messages in the service menu.

**Error 88:** If the expected heat number is more than 20% higher than the stored heat number in the cooking program. This error does not result in a complete shut down of the rotisserie, but is stored in the fault messages in the service menu.

App. Error: - Parameter file cannot be openend when switching the TDR on.

- Failure during loading of parameters or programs.
- Communication failure keypad and CPU.

For explanation and solving of the errors see general troubleshooting list on page 58.

Key

On / Off

Forward

Rotor

OK

Back

Undo

List



# GAS BLOCK HONEYWELL TYPE VK4115V - 2004

# vsezip.ru

Gas inlet: Inlet of gas after gas pressure reduction valve (max. 55 mbar or 22" H2O). Pressure depending of gas type (see table on page 35). 987-08-81

Gas outlet: Outlet of gas into gas mixture blower.

Coils: 2 Coils for the gas valves.

Inlet pressure: Measuring tube (during operation) for gas pressure after reduction valve. In order to measure loosen the screw on inside of tube.

Outlet or burner pressure: Measuring tube of gas going into gas mixture blower. In order to measure loosen the screw on inside of tube.



#### Measuring notes:

1. Inlet pressure: During operation you measure the pressure of the setting of the reduction valve.

2. Outlet pressure: During operation you measure a pressure of zero.

You can use this measuring point also to check if the gas valves are opening. When you start up the machine and the valve is not openend yet you measure a underpressure due to the suction of the gas mixture blower and this pressure will be zero when the valve is opened.

#### **ЗИП ООЩЕПИТ** IGNITION/IONIZATION SET

When placing a new ignition/ionization set or for checking the adjustment of this set see drawing below. Here you can find the distance between the spark plug and the distance between the ignition pins and the burner bed and the distance between the ionisation pin and the burner bed.



Page 43

6 and 8 mm = distance between ignition pins and burner bed.

10 mm = distance between ionisation pin and burner bed.

4 mm = distance between the two ignition pins.

fri-jado



# TEMPORARY BRIDGING OF RESET SWITCH

For testing of the system, when reset switch could be maifunctioning, it is possible to bridge the reset switch by temporary, for 2 seconds, connecting both the grev and brown wires together. In this way you can perform a test and do a check up on the reset switch.



1. Remove the 2 grey and brown wires from the reset switch.



- 2. Connect these 2 jacks together with a separate wire.
- 3. Start a program and disconnect the 2 jacks.

### **RESETTING OF GAS BURNER SAFETY CONTROL**

For testing of the system, when reset switch could be malfunctioning, it is possible to make a reset direct on the gas burner safety control. In this way you can perform a test and do a check up on the reset switch.



- 1. Remove right hand panel according prior procedure.
- 2. Press the reset knob.
- 3. Start a program.



With the flue gas analyser you can measure the exhaust cas or the rotisserie for toxicity. With the use of a Testo 330-1LL you get the following measurements:

- 7/05

		· · · · · · · · · · · · · · · · · · ·	$(0   \mathbf{Z})$
Testo	330-1LL		
V1.21		01297080	
10003	35026	G 20	
06.03	.2014	11:42:13	
Fuel:		Natural gas	
O2 re	f.:	3.0%	
CO2 r	nax:	9.1%	
5.2	%	Oxigen	
9.0	%	CO2	
1.33		Lambda	
5	ppm	CO	
0.01		GI	
26.7	%	qR	
73		efficiency	
54	°C	dew point	130°F
378	°C	Exhaust gas temp.	713°F
23	°C	Ambient temp.	74°F



fri-jado

The 2 most important values are the CO2 percentage and the exhaust gas temperature. CO2% G 20/25 between 8.7 - 8.9% CO2% G 30 between 10.4 - 10.6% CO2% G 31 between 11.2 - 11.5% CO max value 500 ppm

Exhaust gas between 370 - 420°C (698 - 788 °F)

# GAS CONSUMPTION

With a flow meter you can measure the gas **VSEZIP.** It consumption/flow. See table on page 38. To get an accurat consumption you have to cold 2987-measurement of 3-5 minutes. During this period the rotisserie the rotisserie may not turn off.



## MAINTENANCE GAS PROCESSING

The customer should have the gas rotisserie periodically checked by a skilled technician according local, state or national regulations.

First remove the right side panel according procedure in removal and replacement of parts. Check for gas leaks and/or bad connections of the gas supply inside and outside.

- Check the gas burner and the ignition/ionisation set.
- Check the adjustment of the ignition/ionistation set.
- Check all gaskets.
- Check the inlet pressure and re-adjust if necessary. For the correct value, see table on page 10.
- Check the consumption of the gas, see table on page 38.
- Measure the exhaust gas with a flue gas analyzer, see page 45.
- Check the electrical supply.
- Make a test run.

# PARAMETER LISTING TDR P

PARAMETERS



INTRODUCTION F7(812)987=08=81

зип Общепит

This chapter contains an explanation and listing of the parameters for the P-control system of the TDR. The first section contains explanations for every parameter. The sections after that contain instructions and a parameter table for the TDR P.

The P-control system has 2 seperate parameter sections, one titled "Manager" and one titled "Service". The manager parameters are protected with a standard password "1111". The manager can also protect this with his own 4-digits password.

The service section is only accesible for qualified service technicians.

The start up screen lists general information such as software version number, model name and Fri-Jado company logo.

Please make sure you read the paragraph titled "adapting parameters" before changing parameters. It contains some important information concerning the programming of the parameters.



#### **REACHING THE PARAMETER MENUS**

To reach the Manager parameter menu, press the "list" key and enter with the standard password **"1111"** (if not protected by a specific Manager password).

To reach the Service menu press and hold the "UNDO" key for 5 seconds and enter with the password "**4878**". This only can be reached in the standby position of the rotisserie.

To leave a section use the UNDO key.

**Note:** The service section is by default protected with a default password **"4878"**.

**Note:** The manager section can be protected by a seperate password, this password can be set inside the manager menu. It is possible to read this password through the service menu in the User PIN parameter.

fri-jado



#### **ЗИП Общепит** OPTIONS MANAGER MENU

# vsezip.ru

To enter the manager menu press and hold the List key. The manager section can be protected by a seperate password. The standard number is "1111', This password can be changed inside the manager menu.





PARAMETERS

# **ЗИП Общенит** MANAGER MENU - DESCRIPTION OF THE SUBMENUS

VSezip, ru			
	Menu section: Manager menu		
Parameter	Description		
USB	In this menu you can read recipies from the USB stick to the CFU board, or store programs from the CPU to the USB stick.		
Programming	In this menu you can process the cooking programs. You can make a new program or edit, delete or copy an existing program.		
Parameters	In this menu you can view or change all manager parameters. Note: when changing a parameter in this manager menu, this will automatically be changed also in the service menu. For an overview of the parameters see parameter list manager menu.		
Change pin	In this menu you can change the manager pincode.		
Clock	In this menu you can set the time and the time format (12/24h clock).		
Transfer	In this menu you can store log data on the USB stick. These are 2 separate files. One with a error overview and the second with all parameter settings.		

Parameter list Manager menu			
Parameter	Description		
Language	This parameter allows the setting of the language of the different texts used by the unit. Note that some texts may not yet have an updated translation.		
Big digits	This parameter allows to choose for big digits on the display during preheat, cooking and hold cycle.		
Preheat allowed	This parameter allows the enabeling of preheating before a recipe. If "yes" is selected, every program can have a preheat step included, you have a choice in this. If "no" is selected preheating is not possible, even if there is a program with a preheat step.		
Holding allowed	This parameter allows the enabeling of a warm hold step at the end of the grilling step(s). If "yes" is selected every program can have a holding step included, you have a choice in this. If "no" is selected holding is not possible, even if there is a program with a holding step.		
Preheat tempera- ture	This parameter allows the programming of a general preheat temperature. Note: this preheat temperature is suggested and can be overwritten in the programs.		
Holding tempera- ture	This parameter allows the programming of a general holding temperature. Note: this holding temperature is suggested and can be overwritten in the programs.		
Sound preheat T1	This parameter allows to set an alarm sound at the end of the preheat step. You can choose 3 different sounds (T1-T2-T3) and the level of the sound (up to 4 white blocks) or no sound (no white block).		
Sound step T2	This parameter allows to set an alarm sound at the end of the first grilling step. You can choose 3 different sounds (T1-T2-T3) and the level of the sound (up to 4 white blocks) or no sound (no white block).		
Sound done T3	This parameter allows to set an alarm sound at the end of the grilling step(s). You can choose 3 different sounds (T1-T2-T3) and the level of the sound (up to 4 white blocks) or no sound (no white block).		



### ип Общепит SERVICE MENU - DESCRIPTION OF THE SUBMENUS

54

Menu section. Solvitemena			
Parameter	Description		
USB	In this menu you can reached recipies from the USB stick to the CFU board. And you can store recipies, parameters and LOG data to the USB stick.		
Function	This menu allows access to the I/O test screen, Through this, several inputs and outputs of the machine can be monitored and toggled.		
Parameters	In this menu you can view or change all service parameters. Note: when changing a param- eter in this service menu, this will automatically be changed also in the manager menu. For an overview of the parameters see parameter list service menu.		
Clock	In this menu you can set the time and the time format (12/24h clock).		
Counter	In this menu you can view the total working hours of the fan, gearbox and heaters. After repalcing one of these parts you have to set the counter on zero again.		
Operation	In this menu you can view the total hours of operation. This value is not resettable.		
User pin	In this menu you can view the current set pincode. This code can only be viewed and not changed.		
Fault	In this menu you can view all occurred errors and, if applied, in what cooking program.		
Test program	In this menu you can start a test program. This fixed program has one cooking step of 250°C for 20 minutes and a holding program of 85°C and 10 minutes.		
Set demo on	In this menu you can set the machine into a demonstration mode. In demonstration mode the machine will not turn the heating elements on and will simulate the machine heating up only through software.		
	Parameter list Service menu		
Parameter	Description		
Language	This parameter allows the setting of the language of the different texts used by the unit. Note that some texts may not yet have an updated translation.		
Big digits	This parameter allows to choose for big digits on the display during preheat, cooking and hold cycle.		
Preheat allowed	This parameter allows the enabeling of preheating before a recipe. If "yes" is selected, every program can have a preheat step included, you have a choice in this. If "no" is selected preheating is not possible, even if there is a program with a preheat step.		
Holding allowed	This parameter allows the enabeling of a warm hold step at the end of the grilling step(s). If "yes" is selected every program can have a holding step included, you have a choice in this. If "no" is selected holding is not possible, even if there is a program with a holding step.		
Preheat tempera- ture	This parameter allows the programming of a general preheat temperature. Note: this preheat temperature is suggested and can be overwritten in the programs.		
Holding tem- perature	This parameter allows the programming of a general holding temperature. Note: this holding temperature is suggested and can be overwritten in the programs.		
Sound preheat T1	This parameter allows to set an alarm sound at the end of the preheat step. You can choose 3 different sounds (T1-T2-T3) and the level of the sound (up to 4 white blocks) or no sound (no white block).		
Sound step T2	This parameter allows to set an alarm sound at the end of the first grilling step. You can choose 3 different sounds (T1-T2-T3) and the level of the sound (up to 4 white blocks) or no sound (no white block).		
Sound done T3	This parameter allows to set an alarm sound at the end of the grilling step(s). You can choose 3 different sounds (T1-T2-T3) and the level of the sound (up to 4 white blocks) or no sound (no white block).		
Temp. unit	This parameter allows the switching between showing degrees either in Celcius (°C) or Fahrenheit (°F). Changing the parameter affects all values directly and no restart of the machine is required.		

fri-jado

PARAMETERS

	Parameter list Service menu			
Parameter	Description			
Ecocook allowed	This parameter alows the ecocook to be activated or not. Ecocook on yes means that the accumulated heat in the cavity will be used to cook the product and to save energy. Heating elements will not be activated during the last period of the last grilling step.			
Ecocook var.	This parameter alows to set the variable of the ecocook. var. adjustable from 1 to 9. This is the percentage of the total cooking time.			
Boost allowed	This parameter allows to add extra cooking time at the end of the grilling cycle. If set on "yes" you can add extra time in minutes.			
User PIN in use	This parameter allows free access to the Manager menu if set on "no". Or protected access by means of a pin code if set on "yes". If set on "no" there is no pin code protection for the Manager menu and you have free access to this menu. If set on "yes" the standard Manager pin code is "1111", but can also be changed to another pin code. Note: Always set the pincode back on "yes" after work has ended.			
Lights out	This parameter allows the lights to be shut off during opening of the door during stand by position. If set on "no" the lights will go on for 20 seconds.			
key beep	This parameter allows to set a beep sound when a key is touched. If set on "off" the beep sound will be off.			
Temp. offset	This parameter allows to set an offset in the temp. regulation. For example: if temp. is set on 200°C and offset on -20°C the software regulates the temp. on 220°C, so a real higher operating temp. Offset can be adjusted on $\pm$ 59,9°C.			
Cook correction allowed	This parameter allows a cooking time that automatically will be adjusted depending on the load of products. The first cook is the reference cook and will be used to fix the correct parameters. The activation of the cook correction is not visible in the display.			
Key sens	This parameter allows the adjustment of the sensitivity of the keys. Sensitivity is highest on value 1 and lowest on 9.			
Temp. grad.	This parameter allows the setting of the minimal temperature rise, in °C or °F/minute, of the PT sensor during the preheat, cooking and hold steps until maximal 150°C / 302°F. Measuring only starts after 5 minutes in these steps and the actual temperature in the cabinet is at least 30 °C/54°F lower than the set temperature. Measuring takes place every 2 minutes and when the temperature rise is lower during 5 consecutive measurements than the setting of this parameter, an "error 55" will be indicated and the machine switches off.			
Second display	<ul> <li>This parameter allows the setting of the display on customer side.</li> <li>0 = Second display has only the rotor function in stand by position.</li> <li>1 = Second display has only limited functions like viewing during cooking proces.</li> <li>2 = As 1 + possibility of selection of programs and starting.</li> <li>3 = Not in use.</li> </ul>			
Thermistor	This parameter alows the activation of an error on the clixon inside the blower motor. If set on "yes" the clixon is connected, by relay K3, to the input of the CPU board and stops the blower and rotisserie when overheating and indicates an error 66. If set on "no" the clixon is not activated.			

#### Notes:

- After parameter changes have been made in both Manager or Service menu, you have to press the undo key to go to save and press OK key to confirm.
- When parameters, that are both in Manager and Service menu, are changed in one menu they will be also adjusted in the other menu.
- When preheat allowed or holding allowed is set on zero, no preheat or holding will take place even if this is programmed in a recipe.
- When preheat is set in the Manager or Service menu and the recipe itself has no prehat programmed, there will be no preheat in the cooking cycle.
- It is not possible to program only a preheat or hold step, without a cooking step.
- The countdown of the last minute in the cooking cycle is displayed in seconds.



The P-control system utilises a large set of parameters, of these parameters a select group is open to customization. This meaning these parameters can be adjusted to offer functionality more fitting to the intended purpose of the unit.

The manager parameters are open to modification. It is however important to know beforehand what a parameter does before changing it, a detailed description of all parameters can be found earlier in this chapter.

Generally speaking all Service parameters are considered important and should not deviate from the value as listed in the parameter lists found in this document.

When changing the critical service parameters beyond the value listed in this document Fri-Jado cannot guarantee that the unit will function as to be expected.

#### LOADING SOFTWARE

Software can only be loaded to the CPU board by means of a memory stick. The download is always done out of a folder called "42-P+CPU" (see also explanation updating system software below). This folder has to be placed direct on the memory stick and cannot be placed in another folder, otherwise it will not work. That means only one folder "42-P+CPU" can be placed direct on the memory stick. **How to read the software version see also operation on page 8.** 

To load new software from a memory stick to the CPU board is as follows:

- 1. Pull the plug out of the socket or switch off the mains supply.
- 2. Place memory stick in the side wall.
- 3. Put the plug in the socket ore switch on the mains supply. Now the new software will be loaded inside the CPU board.
- 4. You will be asked to remove the stick and when done the unit switches on. (the existing parameters will remain).

**Updating system software (firmware).** Only in case the unit has older software!! This software, supplied by Fri-Jado comes in a "zip" file with the version number of the software, for example "V1\_4\_09.zip". The file needs to be copied on a USB stick. (disk "USB drive (F:)" in the example).

After unpacking it, the folder named "42-P+CPU" needs to be moved or copied to the root of the USB stick as shown below.

After unpacking.

Move the "42-P+CPU" folder to the root.



fri-jado



### READ AND STORE RECIPIES IN THE MANAGER MENU

#### Recipies can be read and stored from both the Manage. menu and the Service menu.

Recipies can only be read to, or stored from the CPU board by means of a memory stick. The transfer is always done out of a folder called "Programs". This folder has to be placed direct on the memory stick and cannot be placed in another folder, otherwise it will not work. The folder can contain several files with programs. The name of a file may exist of maximum 8 characters, otherwise it will not be read or stored.

When reading a new program to the CPU board the old program will be deleted. So it's adviseable to store the old program first on your memory stick. **How to read and store recepes see also USB on page 24.** 

To read a program from a memory stick to the CPU board is done as follows:

- 1. Place the memory stick and go to the manager menu choose "USB" and confirm with OK.
- 2. Go to "read" and confirm with "OK".
- 3. Go to "read stick" and confirm with "OK".
- 4. Choose file name, with "other file", and confirm with "OK".
- 5. Now go to "read file" and confirm with "OK".

Now the new program will be loaded inside the CPU board.

To store programs from the CPU board to the memory stick is done as follows:

- 1. Place the memory stick and go to the manager menu choose "USB" and confirm with "OK".
- 2. Go to "store" and confirm with "OK".
- 3. Now choose a file name and confirm with "OK".
- 4. Go to "save file" and confirm with "OK".

Now the program will be written on the memory stick.

#### Notes:

- When the message "files not found" is indicated on the display try to reset the machine by pulling the plug out for 5 seconds.
- The name of a file may not exist of more than 8 characters and can't have a space between the characters. Check this in the program list on the memory stick.
- It is not allowed to have a open line in the recipie list. Remove the open line and try again.
- If the reset doesn't work try to load the software again.
- All recipe names must have the extension .csv.

# READ AND STORE RECIPIES AND PARAMETERS IN THE SERVICE MENU

#### Recipies can be read and stored from both the Manager nenu and the Service menu.

Recipies can only be read to, or stored from the CPU board by means of a memory stick. The transfer is always done out of a folder called "Programs". This folder has to be placed direct on the memory stick and cannot be placed in another folder, otherwise it will not work. The folder can contain several files with programs. The name of a program file may exist of maximum 8 characters and can't have a space between the characters, otherwise it will not be read or stored.

When reading a new program to the CPU board the old program will be deleted. So it's adviseable to store the old program first on your memory stick. **How to read and store recepes see also USB on page 24.** 

To read a recipe program from a memory stick to the CPU board is done as follows:

- 1. Place the memory stick and go to the Service menu (pincode 4878), choose "USB" and confirm with OK.
- 2. Go to "read" and confirm with "OK".
- 3. Choose "recipies" and confirm with "OK".
- 4. Go to "read stick" and confirm with "OK".
- 5. Choose file name, with "other file", and confirm with "OK".
- 6. Now go to "read file" and confirm with "OK".

Now the new program will be loaded inside the CPU board.

To store recipe programs from the CPU board to the memory stick is done as follows:

- 1. Place the memory stick and go to the Service menu (pincode 4878) choose "USB" and confirm with "OK".
- 2. Go to "store" and confirm with "OK".
- 3. Choose "recipies" and confirm with "OK".
- 4. Now choose a file name and confirm with "OK".
- 5. Go to "save file" and confirm with "OK".

Now the program will be written on the memory stick.

#### Notes:

- When the message "files not found" is indicated on the display try to reset the machine by pulling the plug out for 5 seconds.
- The name of a file may not exist of more than 8 characters and can't have a space between the characters. Check this in the program file on the memory stick.
- It is not allowed to have a open line in the recipie list. Remove the open line and try again.
- If the reset doesn't work try to load the software again.
- All recipe names must have the extension .csv.

fri-jado

#### PARAMETERS

# 🗲 fri-jado

Зип Общепит

Parameters can only be read to, or stored from the CPU board by means of a memory stick. The transfer is always done out of a folder cailed "EPRAMS". This folder has to be placed direct on the memory stick and cannot be placed in another folder, otherwise it will not work. The folder can contain several parameter files. The name of a file may exist of maximum 8 characters and can't have a space between the characters, otherwise it will not be read or stored.

When reading a new parameter file to the CPU board the old parameters will be deleted. So it's adviseable to store the old program first on your memory stick.

To read a parameter list from a memory stick to the CPU board is done as follows:

- 1. Place the memory stick and go to the service menu (pincode 4878), choose "USB" and confirm with OK.
- 2. Go to "read" and confirm with "OK".
- 3. Choose "parameters" and confirm with "OK".
- 4. Go to "read stick" and confirm with "OK".
- 5. Choose file name, with "other file", and confirm with "OK".
- 6. Now go to "read file" and confirm with "OK".

Now the new parameters will be loaded inside the CPU board.

To store parameters from the CPU board to the memory stick is done as follows:

- 1. Place the memory stick and go to the Service menu (pincode 4878) choose "USB" and confirm with "OK".
- 2. Go to "store" and confirm with "OK".
- 3. Choose "parameters" and confirm with "OK".
- 4. Now choose a file name and confirm with "OK".
- 5. Go to "save file" and confirm with "OK".

Now the parameters will be written on the memory stick.

#### Notes:

- When the message "files not found" is indicated on the display try to reset the machine by pulling the plug out for 5 seconds.
- The name of a parameter file may not exist of more than 8 characters and can't have a space between the characters.
- Check if there is a folder on the memory stick with the name "parameters".
- If it still doesn't work try to load the software again.
- All parameter name files must have the extension .csv.

PARAMETERS

54



# PARAMETER LIST P p.ru

ип Общепит

		Parameters P Gas software	e version 1.04.09
Level 1	Level 2	Level 3 Default	) A Possibilites - 8
Information		1.04.09	software version
Manager	A to the second second	1111	
	Preheat allowed	yes	yes - no
	Preheat temp	210	50 - 250
1.1.1.1.1.1.	Holding allowed	no	yes - no
	Holding temp	85	50 - 250
	Cook Correction 1	yes	yes - no
	Eco function <sup>2</sup>	Ves	ves - no
			English - Nederlands - Deutsch - Francais -
	Language	English	Espanol - Russian
	Big Digits	yes	yes - no
	Sound preheat	11, 880	T1 - T2 - T3
- P.	Sound step	Τ2, ■□Γ	T1 - T2 - T3
	Sound done	13, 888	T1 - T2 - T3
1.			
Service		4878	
	Preheat allowed	yes	yes - no
1.	Preheat temp	210	50 - 250
	Holding allowed	no	yes - no
1.	Holding temp	85	50 - 250
	Cook corr. Option	yes	yes - no
	Cook corr. factor	3	1 - 6
	Ecocook option	yes	yes - no
	Ecocook var	6	1 - 9
	And an an an and a second s		English - Nederlands - Deutsch - Francais -
	Language	English	Espanol - Russian
	Big Digits	yes	yes - no
	Sound preheat	11, ##	T1 - T2 - T3
	Sound step	12, ■□	T1 - T2 - T3
	Sound done	13, 💵	T1 - T2 - T3
	Temp unit	°C	°C - °F
	Boost allowed	no	yes - no
P	User pin in use	no	yes - no
	Lights out	yes	yes - no
	Key beep	no	yes - no
	Temp offset	0	-50 - +50 ℃ or -100-+100 ℉
	Key sense	7	1 - 11
	Temp grad <sup>3</sup>	3	0 - 19
	Second Display	0	0-1-2-3
C	Thermistor 4	no	yes - no

<sup>1</sup> Only visible when "Cook Corr. option" in Service Menu is set on "yes"

<sup>2</sup> Only visible when "Ecocook option" in Service Menu is set on "yes"

<sup>3</sup> If set to "0" then the error 55 function is not active.
<sup>4</sup> Has to be set on "no" for gas rotisseries.



TROUBLESHOOTING

# Зип Общепит GENERAL TROUBLESHOOTING LIST

# TROUBLESHOOTING FOR **HSEZID** TH BOTISSERIES

Symptom	Possible causes		
No power to oven controls.	<ol> <li>Main breaker open.</li> <li>Fuse (125 mA) on power and I/O board burned.</li> <li>Wiring loose.</li> </ol>		
Main fuse or breaker blows.	<ol> <li>Wiring incorrectly.</li> <li>Drive motor, blower or contactor switch shorted.</li> <li>Wiring shorted.</li> </ol>		
Drive motor does not run during cook cycle.	<ol> <li>Capacitor malfunction.</li> <li>Power and I/O board malfunction. Also check relay X12.</li> <li>Motor malfunction.</li> <li>Wiring loose.</li> </ol>		
Drive motor stops and runs again after a certain period.	<ol> <li>Thermal protection activated (105°C). This shuts off after the tem- perature is below 105°C.</li> </ol>		
Blower motor does not run.	<ol> <li>Capacitor malfunction.</li> <li>Motor inoperative.</li> <li>Power and I/O board malfunction. Also check relay X6.</li> <li>Wiring loose.</li> </ol>		
Blower motor stops and runs again after a certain period.	<ol> <li>Thermal protection activated (150°C). This shuts off after the tem- perature is below 150°C.</li> </ol>		
Oven temperature differs from temperature setting in program mode.	<ol> <li>Safety thermostat malfunction.</li> <li>Blower motor(s) inoperative (turning direction?)</li> <li>Electronic control inoperative.</li> <li>PT-1000-sensor malfunction.</li> <li>Dirty fan guard or fan blade(s).</li> </ol>		
Oven temperature does not reach desired temperature in program mode.	<ol> <li>Safety thermostat malfunction.</li> <li>PT-1000-sensor malfunction.</li> <li>Electronic control inoperative.</li> <li>Contactor inoperative.</li> </ol>		
No display and/or keypad does not function.	<ol> <li>Main breaker open.</li> <li>Remove plug out of socket and connect plug again (reset of key sensitivity).</li> <li>Loose flat cable from CPU/display to power and I/O board.</li> <li>Fuse (125 mA) on power and I/O board burned.</li> <li>Power and I/O board malfunction.</li> <li>Loose flatcable from CPU/display to keypad.</li> <li>Keypad malfunction. Check also the adhesive of the keypad.</li> <li>Earth wire on CPU board makes contact with the solder point on the board (see CPU board page 28).</li> </ol>		
Blue LED light On/Off key is fading in and out. Keypad does not function.	<ol> <li>Flatcable from keypad on the operation panel is connected incor- rectly. Must be connected to "Touchpanel 1" connector of CPU board (see CPU board page 28).</li> </ol>		
No ignition / no spark (reset light is burning).	<ol> <li>Check polarity of plug.</li> <li>Gas burner safety control malfunction.</li> <li>Distance (4 mm/ 1/6") between ignition pins not in order.</li> <li>Wiring loose.</li> </ol>		
No ignition of the gas in the bur- ner (reset light is burning).	<ol> <li>Reset switch malfunction.</li> <li>Gas supply closed.</li> <li>Gas block malfunction.</li> <li>Gas burner safety control malfunction.</li> <li>Burner control measures wrong speed of gas mixture blower (change blower). Also see working on page 37.</li> <li>Wiring loose.</li> </ol>		

37 Ofmenter 🗲 fri-jado					
Symptom	Possible causes				
No ignition of the gas in the bur- ner (reset light is <b>not</b> burning).	<ol> <li>Reset switch malfunction.</li> <li>Reset light on operation panel broken.</li> <li>Reset on gas control block is on. Press this to reset.</li> <li>Gas burner safety control malfunction.</li> <li>Wiring locse.</li> </ol>	See page 44.			
Reset light is burning continu- ous.	<ol> <li>Safety thermostat tripped. Reset the thermostat wi (only for serial nrs. 100064637+638 and 100064776</li> <li>Too many resets made (more than 4 and also red in ner control is flashing). Pull the plug out and in age</li> <li>Reset switch malfunction. See also page 44.</li> </ol>	ith red button till 779. ndication on bur- ain.			
Burner switches on and off inter- mittently during operation.	<ol> <li>Reset switch malfunction.</li> <li>Adjustment of ionisation pin.</li> <li>Gas pressure too low (under 15 mbar).</li> <li>Gas burner safety control malfunction.</li> </ol>				
Gas ignites in burner but cuts off after a short time. (reset light is burning).	<ol> <li>Ionization pin malfunction.</li> <li>Adjustment of ionization pin.</li> <li>Loose wiring of ionization pin.</li> <li>Gas burner safety control malfunction.</li> </ol>				
Burner stops during operation.	<ol> <li>Gas supply blocked.</li> <li>Adjustment of ionization pin.</li> <li>Ionization pin malfunction.</li> <li>Gas burner safety control malfunction.</li> <li>Safety thermostat tripped. Reset the thermostat wi (only for serial nrs. 100064637+638 and 100064776</li> <li>Wiring ionization pin.</li> </ol>	ith red button. till 779.			
Gas mixture blower only runs in high speed.	<ol> <li>Gas burner safety control malfunction.</li> <li>Gas mixture blower malfunction.</li> <li>Wiring loose.</li> </ol>				
Error 11.	<ol> <li>PT sensor malfunction.</li> <li>Wiring PT sensor shortened.</li> </ol>				
Error 33.	<ol> <li>PT sensor malfunction.</li> <li>Wiring PT sensor loose.</li> </ol>				
Error 55. See also extra explanation on next page.	<ol> <li>P.T. sensor malfunction.</li> <li>Parameter setting of "temp.grad" is not on value 3. (see page 52).</li> <li>Setting of temp. in cooking program is too high (solved in software version V11.03.07 and higher). Load latest software.</li> <li>Safety thermostat malfunction.</li> </ol>				
Error 77. See also extra explanation on page 41.	<ol> <li>Check heat number in cooking program.</li> <li>Cooking program malfunction. Erase program, create new program, run a reference batch and run a second batch for verification.</li> </ol>				
Error 88. See also extra explanation on page 41.	<ol> <li>Check heat number in cooking program.</li> <li>Heating element malfunction.</li> <li>Cooking program malfunction. Erase program, creat run a reference batch and run a second batch for verif</li> </ol>	e new program, ication.			
Application error. A: No standard screen when switching on. B: APP. error on screen.	<ul> <li>A1. Make a complete reset by pulling out the plug for</li> <li>A2. CPU board malfunction.</li> <li>B1. Memory stick failure.</li> <li>B2. Load latest software version. (solved in V1.03.08 or</li> </ul>	1 sec. higher).			



Note: 1. Measuring starts 5 minutes after beginning of a heating step.

- 2. Duration is 5 periods of 2 minutes.
- 3. Measuring stops at 150°C/302°F or when temp. in cabinet is < 30°C than the set temperature.

Necessary line currents:

TDR8 with neutral 3x 16A. Without neutral 3x 27A. TDR5 with neutral 3x 8,5A. Without neutral 3x 14A.

Possible cause	Caused by	Explanation	Solution
Energy supply pro-	Safety thermostat	Not adjusted to it's maximum	Fully turn clock-wise (cw)
blem		Broken thermostat.	Replace thermostat
	Broken temperature sensor	Sensor gives a wrong value	Replace sensor
	Wrong setting of "temp grad" parameter	Default setting is 3,> 0.5° per 2 minutes	Check setting
Too much loss of	Inner door removed		Put inner door back in.
energy			Put "tem grad"setting on 2 or 1.
Too much energy absorption	Products are stuffed with a very humid substance		Put "temp grad"setting on 2 or 1.



# vsezip.ru +7(812)987-08-81

Зип Общепит

# EMPTY PAGE



#### **ЗИП Общенит** EXPLODED VIEWS & PARTLISTS

# TDR 8 P GAS - SHESTERZEIPL MUDRK



Зип Общепит



ltem	Part number	Qty.	Description VSezin.ru	
1		1	Frame, ass.	
2	9171125	4	Leg, rubber 50 mm	
3	9294180	1	Side panel, Teft (812)98/-08-8	
4	9294018	1	Side panel, right	
5	9294160	1	Top cover	
6	9294032	1	Top plate	
7	9294422	1	Cover, removeable	
8	9174485	1	Cover, exhaust	
9	9174408	1	Plate, air guide	
10	9170568	1	Mounting plate, blowers	
11	9290528	1	Air guide plate	
12	9294485	1	Cover, top	
13	9292118	1	Insulation top, large	
14	9292119	1	Insulation top, small	
15	9294404	2	Reinforcement, top plate	
16	9294405	1	Reinforcement, side plate, left	
17	9294406	1	Reinforcement, side plate, right	
18	9294415	1	Cover plate, machine components	
19	9172053	8	Nut M5	
20	9170444	1	Support, gear motor	
21	9294479	1	Air guide plate	
22	9174417	1	Plate, air guide	
23	9174427	1	Plate, air guide	
24	9294014	8	Bottom plate, stainless steel	
25	9290405	1	Drawer	
26	9171008	1	Drain-tap with handle	
27	4288322	8	Screw M5x10	
28	9294025	1	Mounting plate	
29	9294019	1	Spark catcher	
30	9222076	1	Strain relief M20	
31	9222077	1	Connector M20	
32	9123439	1	Indication plate	
33	9294065	2	Bracket, door switch	
34	9174154	2	Adjusting bracket	



# TDR 8 P GAS - ELECTRICAL PARTS





Item	Part number	Qty.	Description	
40	9172274	1	Rotorset ass., stainless steel	
40-1	9070272	1	Rotor shaft	
40-2	9174623	2	Rotor disc 3 mm	
40-3	4288231	12	Tensilock bolt M5 x 10-	
40-4	9172169	14	Support pin	
40-5	0142056	14	Spring washer M8	
40-6	0141547	14	Nut M8	
41	9172063	1	Steel bearing 14 mm	
42	9172153	8	Meatfork 8 mm SS	
43	9140027	2	Blower	
43-1	9141934	2	Fan blade	
43-2	9073150	2	Wing nut, left hand threaded	
44	9174161	1	Protection support	
45	92930025	1	Gear motor, complete with drive head	
46	2000072	1	Fanblade Ø 150 mm, gearmotor	
47	9110797	1	Sealring, drive head	
48	9073131	1	Sealing ring, Teflon	
49	37012335	2	Door switch	
50	9291010	1	Cover USB adapte	
51	9291011	1	USB adapter	
52	0141050	2	Screw M3x10	
53	4285010	2	Nut M3	
54	9291012	1	USB cable	
55	9291024	1	Reset switch	
56	9123417	1	Sticker, reset	
57	9291025	1	Signal light, red	
58	9298542	1	Operation panel, Glass + back- plate + keypad with flatcable	
58-1	9292041	1	Keypad + flatcable	
59	9298531	1	Back panel, ass. Glass + backplate	
60	92920405	1	CPU board + LCD	
61	9192202	1	Power & I/O board	
62	9172314	1	Flatcable 14 pins	
63	9290219	1	Electric panel, ass.	
63-1	9040970	1	Safety thermostat with automatic reset 100-300°C	
63-1	3500037	1	Safety thermostat with manual reset 100-300°C	
63-2	9077088	2	Rail	
63-3	9191222	2	End cap	
63-4	9261032	2	Socket	
63-5	9261031	2	Relay	
63-6	9261030	2	Clamp	
63-7	9110030	1	Capacitor 1.5 uF	
63-8	9077101	1	Capacitor 2.5 uF	
63-9	8033659	1	Connecting block 9-pole	
63-10	9070840	1	Grommet	
63-11	0166555	1	Earth symbol	
63-12	9172371	1	Connecting block, ass.	
63-13	9294416	1	Panel	

	o III (e) II			
Item	Part number	Qty.	Description	
64	9172310	1	Temperature sensor PT 1000	
sez.	9044140	1	Sensor cable	
66	91711355	6	Lamp holder, incl. glass	
66-1	9171136	6)_(	G' ss lamp holder	
67 / 3	3701052	6	Lamp 20W, 12V/300°C	
68	9171049	1	Ring core transformer, secundair 2x12V	
69	9151010	1	Connecting block 6-pole	
70	9091383	1	Connecting cable with plug	
71	9172326	1	Buzzer 12V	

Note item 63-1: The thermostat with manual reset is only used for the following 6 serial numbers. 100064637 and 638 + 100064776 until 779. all other units have a thermostat with automatic reset.

#### ЗИП ООЩЕПИТ TDR 8 P GAS - DOORS



Item	Part number	Otv	Description	
		1 QIY.		
80.5	92985105			veezin ru
80-1	4280558	2	Screw IVIS X 16 SS	rsezip.iu
80-2	3702342	8	Flange bush, PTFE 3 mm	
80-3	9294049	1	Protection profile	12)987-08-81
80-4	9294048	1	Hinge profile	
80-5	9172054	2	Brass bearing 8 mm	
80-6	9172122	2	Brass bearing 8 mm, adjusted	
80-7	4311110	2	Washer M5	
80-8	0144359	2	Nut M5, self locking	
80-9	4288320	2	Screw M5 x 50 SS	
80-10	9294035	1	Fastening, door handle	
80-11	9294034	1	Magnet holder profile	
80-12	9174680	2	Washer	
80-13	9070141	12	Magnet block	
80-14	9293010	2	Spacing pin	
80-15	9293008	1	Door handle	
80-16	2103209	2	Plug, door handle	
80-17	4302141	2	Таре 20 х 0.8	
80-18	9294229	1	Blocking bracket	
81.C	92985115	1	Door customer side, ass.	
81-1	4280558	4	Screw M5 x 16 SS	
81-2	3702342	8	Flange bush, PTFE 3 mm	
81-3	9294049	1	Protection profile	
81-4	9294048	1	Hinge profile	
81-5	9172054	2	Brass bearing 8 mm	
81-6	9172122	2	Brass bearing 8 mm, adjusted	
81-7	9174680	4	Washer	
81-8	0144359	4	Nut M5, self locking	
81-9	9070141	12	Magnet block	
81-10	9294035	1	Fastening, door handle	
81-11	9294034	1	Magnet holder profile	
81-12	4302141	2	Таре 20 х 0.8	
81-13	9294229	2	Blocking bracket	
82	92985125	2	Door inside, ass.	
82-1	9292013	2	Glass, inside door	
82-2	9290406	2	Hinge profile	
82-3	9191050	4	Bolt M5 x 18 SS	
82-4	3702341	16	Flange bush, PTFE 2 mm	
82-5	9294037	4	Cover profile	
82-6	0142315	8	Nut M5 SS	
82-7	9294038	2	Holder, magnet	
82-8	9294039	2	Profile	
82-9	9070141	20	Magnet block	
82-10	9172291	4	Spacing pin	
82-11	9174680	12	Washer	
82-17	4302141	2	Tape 20 x 0.8	
83	9290409	1	Hinge left	
84	9290410	1	Hinge right	
5-	5250410			

**Fri-jado** 



			EXPLODED VIEWS AND PARTLISTS			
		0	<u>. Зи</u>	п Общепит		
Item	Part number	Qty.	Description			
90	9290550	1	Heat exchanger			
91	9292106	1	Insulation, heat exchanger	vsezip.ru		
92	9292109	1	Insulation board, heat exchanger			
93	9290221	1	Insulation + sheet left ass.	19\007_00_01		
94	9290222	1	Insulation + sheet right ass.	12/90/-00-01		
95	9070793	7	3d nut M6			
96	9292107	1	Insulation exhaust pipe			
97	9291018	2	Spring for insulation exhaust pipe			
98	9281034	1	Gas mixture blower, 230V			
99	92901135	1	Coupling piece, universal + igni- tion set, ass.			
99-1	9292102	1	Gasket for coupling piece			
99-2	9292103	1	Gasket, blower flange			
99-3	92921135	1	Ignition/ionisation set , incl. gasket			
99-3-1	9292108	1	Gasket, ignition set			
100	9171094	1	Venturi tube, incl. gasket			
101	9171099	1	Holder, orifice			
102	9174498	1	Orifice 4,2 mm (G20/25)			
102	9292128	1	Orifice 3,2 mm (G31)			
103	9171092	3	Flange + gasket			
104	9292120	1	Gas hose with coupling 1/2"			
105	92910335	1	Gas control block 230V Natural gas			
105	9291023	1	Gas control block 230V Propane gas			
106	9293042	1	Gas burner safety control Natural gas			
106	9293043	1	Gas burner safety control <b>Propane gas</b>			
107	9292116	1	Gas tube 1/2"			
108	9171053	1	Knee joint 1/2"			
109	9173077	1	Gas tube 1/2"			
110	9291029	2	Bracket for tube			
111	9294482	1	Mounting plate for gas tube			
112	9293046	1	Safety plug, adjustment screw			
113		1	Clamp, tube			
114		1	Silencer			
	1			]		

🗲 fri-jado



Зип Общепит

# ELECTRICAL DIAGRAMS

# CIRCUIT DIAGRAM TOR 8 P GAS







siz A3



# Зип Общепит vsezip.ru +7(812)987-08-81

# EMPTY PAGE


## Зип Общепит vsezip.ru +7(812)987-08-81

Зип Общепит vsezip.ru +7(812)987-08-81



Fri-Jado B.V. • P.O. Box 560 • 4870 AN • Etten-Leur • The Netherlands • tel +31 76 50 85 400 • fax +31 76 50 85 444 • info@frijado.com • www.frijado.com