

Зип Общепит

vsezip.ru

+7(812)987-08-81




P5

Edition 19980306-

Зип Общепит

vsezip.ru

+7(812)987-08-81



Pos	Code	Description	Info
001	30W3130	CUP BOARD	06/03/1998-
002	3150790	THERMOSTAT PROTECT.	06/03/1998-
003	32M0650	MOTOR	06/03/1998-
004	32Z5560	TIMER	06/03/1998-
005	35V6370	MICRO HOLD. BRACKET	06/03/1998-
006	35X2330	PIPE	06/03/1998-
007	36D6040	PAWL	06/03/1998-
008	37M4770	CONTROL PANEL	06/03/1998-
009	35V6381	BRACKET	06/03/1998-
010	3600310	MAGNET	06/03/1998-
011	3128960	WASHER	06/03/1998-
012	36D9550	BUSHING	06/03/1998-
013	32W3240	MICROSWITCH	06/03/1998-
014	36G2040	PIN	06/03/1998-
015	33Q5180	HOSE SUPPORT	06/03/1998-
016	33Q6040	"ELBOW MF 1/4\''''''	06/03/1998-
017	33Q6210	REDUCING	06/03/1998-
018	3128840	WASHER	06/03/1998-
019	3117580	LOCK NUT	06/03/1998-
020	3140460	HOSE CLAMP	06/03/1998-
021	3151300	WASHER	06/03/1998-
022	36G6590	TRANSMISSION SHAFT	06/03/1998-
023	3190830	WASHER	06/03/1998-
024	36F0090	BEARING	06/03/1998-
025	36G5950	BEARING	06/03/1998-
026	36G6600	PULLEY	06/03/1998-
027	36G6610	BELT	06/03/1998-
028	36G6620	PULLEY	06/03/1998-
029	35V1230	SUPPORT	06/03/1998-
030	36Z6501	COVER	06/03/1998-
031	3151750	"O" RING Ø 400	06/03/1998-
032	37Q7330	GASKET	06/03/1998-
033	36M5090	HANDLE	06/03/1998-
034	6005380	WELL LID ASS. Y	06/03/1998-
035	3600870	CHAMBER BOTTOM	06/03/1998-
036	35X1150	DRAIN PIPE	06/03/1998-
037	35D7790	BOTTOM PLATE	06/03/1998-
038	36C0800	FOOT	06/03/1998-
039	35M0850	BOTTOM PLATE	06/03/1998-
040	35S8400	SAFETY THERM.	06/03/1998-
041	36C0011	SUPPORT FRAME	06/03/1998-
042	37Q7860	DOOR GASKET	06/03/1998-
043	36Z6531	DOOR	06/03/1998-
044	35G4730	HATCH CLOSING DEVICE	06/03/1998-
045	37M7870	PANEL	06/03/1998-
046	3600160	MAGNET	06/03/1998-
047	32Q0510	EL. CABLES	06/03/1998-
048	6005400	HANDLE	06/03/1998-
049	6000930	DOOR UNIT	06/03/1998-
050	3201600	SWITCH COVERING	06/03/1998-
051	32W2960	SWITCH	06/03/1998-

Pos	Code	Description	Info
052	32W2760	CONTACT ELEM.	06/03/1998-
053	32W2750	CONTACT ELEMENT	06/03/1998-
054	32W2970	LAMP	06/03/1998-
055	32W3280	LAMP	06/03/1998-
056	32D0630	"OMEGA" BRACKET	06/03/1998-
057	32D1050	PLATE	06/03/1998-
058	32D1020	THREE-POLE CONNECTOR	06/03/1998-
059	32D1010	THREE-POLE CONNECTOR	06/03/1998-
060	32Z4840	RELAY	06/03/1998-
061	32D0610	GROMMET	06/03/1998-