

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
1	SL3334	(25CN-FN)	Cover	
1	SL0062	(38CN-FN)	Cover	
2	SL0076		Pivot	
+	3	SL3365	1/2"x5/16" (25CN-FN)	Chain
+	3	SL3438	1/2"x5/16" (38CN-FN)	Chain
3	SL2684	01/04/07 f.p.(*)(38CN-FN)	Chain	
4	SL3264		Spacer	
5	SL0118	6205 2RS	Bearing	
6	SL0241	6005 2RS	Bearing	
7	SL3261		Support	
8	SL0035		Stop	
9	SL0036		Cam	
+	10	SL0885	CE norms	Microswitch
10	SL2701	without CE norms	Microswitch	
11	SL0397	CE norms	Bracket	
12	SL0084	1/2"x5/16" Z=29	Pinion	
13	SL0086	UCF205	Support	
14	SL3335	(25CN-FN)	Cover	
14	SL3441	(38CN-FN)	Cover	
14	SL2606	01/04/07 f.p.(*)(38CN-FN)	Cover	
+	15	SA1210	400V/3Ph/50Hz	Electric installation
+	15	SA1220	230V/1Ph/50Hz	Electric installation
16	SL3367	(25CN-FN)	Cover	
16	SL2849	(38CN-FN)	Cover	
17	SL3265	1/2"x5/16" Z=15	Pinion	
18	SL1056	6x6x25	Key	
19	SL3410	8x7x40	Key	
20	SA1024		Shaft	
20	SA1025	01/04/07 f.p.(*)(38CN-FN)	Shaft	
21	SL3338		Gear box	
22	SL3311	400V/3Ph/50Hz	Motor	
22	SL3214	230V/1Ph/50Hz	Motor	

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
22	SL3315	400V/3Ph/50Hz (2 speed)	Motor
23	SL1668	PG11	Cable clamp
24	SL1841	3Ph+Gnd	Electric cable
24	SL1671	1Ph+N+Gnd	Electric cable
+	25	SL3361	Foot
26	SL3332	(25CN-FN)	Base
26	SL3437	(38CN-FN)	Base
26	SL3359	01/04/07 f.p.(*)(38CN-FN)	Base
27	SL0937		Box
28	SL0396		Gasket
+	29	SL0807	Stop Push button
+	30	SL1049	Start Push button
31	SL0100	3/8"x7/32" Z=85	Crown
+	32	SL3366	3/8"x7/32" Chain
+	32	SL2686	01/04/07 f.p.(*)(38CN-FN) Chain
33	SL3371		Rod
34	SL0072		Shaft
35	SL0073	6004 ZZ	Bearing
36	SL0074		Support
37	SL0103	3204	Bearing
38	SL0075	ø20	Seeger
39	SA1030	Assembly	Spiral
40	SL2604	(25CN-FN)	Bracket
40	SL2605	(38CN-FN)	Bracket
41	SL1090		Spacer
+	42	SL2655	Wheel
43	SL2625		Pivot
+	44	SL2630	Lever
45	SL3333	(25CN-FN)	Head
45	SL3435	(38CN-FN)	Head
45	SL2577	01/04/07 f.p.(*)(38CN-FN)	Head
46	SA1031	Assembly	Support

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
47	SL1616	∅25	Seeger
48	SL2057	8x7x20	Key
49	SL2677	(25CN-FN)	Protection
49	SL2678	(38CN-FN)	Protection
50	SL2627		Support
51	SA1006	Plastic (25CN-FN)	Cover
51	SA1007	Plastic (38CN-FN)	Cover
52	SA1170	(25CN) Assembly	Pan
52	SL0067	(25FN)	Pan
52	SA1180	(38CN) Assembly	Pan
52	SL0068	(38FN)	Pan
53	SL2623	(25-38CN)	Pivot
54	SL1034	(25CN)	Gasket
54	SL1334	(38CN)	Gasket
55	SL2637	(25CN)	Flange
55	SL2634	(38CN)	Flange
56	SL2621	(25-38CN)	Flange
56	SL2867	(25-38FN)	Flange
57	SL2636	(25-38CN)	Flange
58	SL2668		Spring
59	SA1047	Assembly	Support
60	SL3206		Joint
61	SL3204		Shaft
62	SL1632	1/2"x5/16"	Joint
63	SL1629	3/8"x7/32"	Joint
64	SL3482	∅95 M10x30	Fixed wheel
65	SL3483	∅95 M10x30	Revolving wheel
66	SA1800	Assembly	Support
67	SL1401	CE norms	Microswitch
68	SL2743	2 speed (CE norms)	Speed changeover switch
68	SL3760	2 speed (without CE norms)	Speed changeover switch
69	SL3266		Shaft

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
+	70	SL0069	Spiral
	71	SL3404	400V/3Ph/50Hz
	71	SL3405	230V/1Ph/50Hz
	71	SL3406	400V/3Ph/50Hz (2 speed)
	72	SL3419	Stainless steel (25CN-FN)
	72	SL3420	Stainless steel (38CN-FN)
	73	SL0054	Switch

