


Зип Общепит

vsezip.ru  
**МБМ**  
+7 (812) 987-08-81

**SPARE PARTS CATALOGUE  
ERSATZTEILKATALOG  
CATALOGUE PIECES DETACHEES  
CATALOGO PARTI RICAMBIO  
CATALOGO DE PIEZAS DE RECAMBIO  
CATALOGO PEÇAS DE REPOSIÇÃO**


**LF50-LF55**

**2001**





vsezip.ru

+7(812)987-08-81




\* OPTIONAL



vsezip.ru






+7(812)987-08-81





# 3а Зип-Общепит

vsezo.ru

+7(812)987-08-81



TAV.6-7




\* OPTIONAL

3и4 **Общепит**

vsezip.ru




+7(812)987-08-81



# 5 Зип-Общепит

vsezip.ru

+7(812)987-08-81








# B. 237

13 01 09 (230V- 50Hz)

13 01 19 (230V- 60Hz)





# T. 173



13 01 26 (230V- 50Hz)

13 01 33 (230V- 60Hz)



**T. 175**