



+7(812)987-08-81



Зип Ощепит

vsezip.ru


+7(812)987-08-81









Зип Общепит

vsezip.ru

+7(812)987-08-81





Зип Общепит

Position	Code	description
	6913210021	E.VALVE BRACKET 2WAY(S.VAP) DEGREASED
	6913210031	E.VALVE BRACKET 3WAY DEGREASED MCSA
	6932103900	GRID
	5332250300	GUIDE LIGHT
	7313234261	STG INSTALL SPACER + SCREWS
	5313239751	PANEL
	5332238300	TUBE 90°
001	5332143500	COVER
002	5332143400	COVER
003	5313212451	INSERT
004	5332262600	CLOSURE
005	7013210661	SIDE LEFT
006	5913210471	KNOB
007	5532146600	TANK
008	7032113300	REAR PANEL
009	7032113100	SIDE RIGHT
010	5332275700	GLASS
011	VI000	SEE TECNICAL INFORMATION
012	7332216800	DOOR ASSY
013	5332142600	HOOK
014	5332226800	TANK COVER
015	7332199300	WATER TANK
016	5332248500	PROFILE
017	6032119000	CUP PLATE
018	5313211571	TRAY
019	5332275200	SUPPORT
020	5332266300	FLOAT
021	5332169200	MEASURING SPOON
022	5313212011	FRAME
023	5132114600	VENTILATOR
024	5332248600	TRAY
025	5332248700	TRAY
026	5132112500	SWITCH
027	5532151500	TUBE
028	6132101300	CLIP
030	5032526800	WIRING TCO
031	5332142200	SUPPORT

Зип Общепит

vsezip.ru

7(812)987-08-81

032	5132104100	MICROSWITCH
033	6132104700	SPRING
034	5217100200	SENSOR NTC
035	7313219431	VALVE
036B	5232119600	POWER BOARD
037	5313216501	SUPPORT
038	5113211281	PUMP
039	5232103200	PROTECTOR
040	5513212881	TUBE PTFE DI2-DE4 L=270 2BUSHES
043	5113210421	MICROSWITCH
050A	5132105400	MICROSWITCH
051	5513220521	FILTER
053	5213213971	HALL SENSOR
054	5213214671	FLOWMETER
055	5232104600	SENSOR REED
062B	5513227971	COMPLETE GRINDER
063	5313217751	O-RING
064	5513227881	GENERATOR
065	5332213000	PIN
066	5332144900	GASKET
067	5332139200	FILTER
068B	5513227951	TRANSMISSION KIT
069	5332148400	VALVE
070	6132106900	SPRING
071	5332142300	BUSH
072	5332142400	BUSH
073	5313243071	BELT
075	6132103500	SPRING
076	5332139800	LEVER
078	9812631250	SCREW
079	6013213181	FILTER
080	5332149100	O-RING
081	5332139600	STOPPER
082	5332139500	VALVE
083	6132106700	SPRING
084	5332140300	PISTON
088B	5213212381	MOTOR BOARD (ECM)
089	5332251200	COVER

Зип Общепит

090	534848	SUPPORT
091	5513227871	DIFFUSER KIT
092	5232105000	TCO
094	5513225701	KIT SOLENOID VALVE 2V
095	IT0286	SEE TECNICAL INFORMATION
096	7332217100	TAP
097	5513213471	TUBE
098	5313217761	O-RING
099	533135	O-RING
100	5332113800	TUBE LOWER
101	5332229600	COVER
105	5313217701	O-RING D=3,85
113	7332222400	RUNNER LEFT
114	7332222300	RUNNER RIGHT
115	7332222000	FRAME ASSEMBLY
116	5232117700	CONTROL BOARD
117	5232117600	BOARD LED
118	7032116400	BASE
119	5332276100	SPACER
120	5532151300	KNOB
121	5332275500	FRAME
122	5332172100	PUSH BUTTON
123	5932113200	PUSH BUTTON
124	5932113300	PUSH BUTTON
125	5932113700	PUSH BUTTON
126	5932113600	PUSH BUTTON