

# Spare parts catalogue

SF. 500 base unit


vsezip.ru

+7(812)987-08-81

| Ref | Description                          |
|-----|--------------------------------------|
| 1   | Extension for lower table            |
| 2   | Lower table                          |
| 3   | Conveyor belt                        |
| 4   | Table                                |
| 5   | Waste drawer                         |
| 6   | Belt stretching cylinder             |
| 7   | Fork for rolling pin                 |
| 8   | Spacer                               |
| 9   | Lower table locking handwheel        |
| 10  | Table supports                       |
| 11  | Electric box cover                   |
| 12  | Electric box                         |
| 13  | Frame                                |
| 14  | Foot adjustment                      |
| 15  | Foot adjustment wheel                |
| 16  | Wheel                                |
| 17  | Wheel spacer                         |
| 18  | Belt tension rod                     |
| 19  | Motor support                        |
| 20  | Electric motor                       |
| 21  | Motor fulcrum pin                    |
| 22  | Motor pulley                         |
| 23  | Side closing panel                   |
| 24  | Pedal                                |
| 25  | Pedal lever                          |
| 26  | Microswitch to invert pedal movement |
| 27  | Table fulcrum rod                    |
| 28  | Pedal control guard                  |
| 29  | Side closing panel                   |

vsezip.ru

+7(812)987-08-81



SF. 500 head unit

vsezip.ru

| Ref | Description                   | Ref | Description                         |
|-----|-------------------------------|-----|-------------------------------------|
| 1   | Right hand frame              | 36  | Left connecting rod                 |
| 2   | Left hand frame               | 37  |                                     |
| 3   | Right hand panel              | 38  | Lifting shaft                       |
| 4   | Left hand panel               | 39  | Connecting movement rod             |
| 5   | Flange                        | 40  | Bushing for connecting rod          |
| 6   | Bearing 6004 2RS              | 41  | Spring                              |
| 7   | Seeger ring                   | 42  | Seeger ring                         |
| 8   | Spacer                        | 43  | Bearing 6005 2RS                    |
| 9   | Freewheel Z=16 1/2" x 1/8"    | 44  | Double crown Z=35                   |
| 10  | Threaded pinion               | 45  | Chain tightener                     |
| 11  | Double screw                  | 46  | Lifting shaft bushing               |
| 12  | Double crown Z=16 1/2" x 1/8" | 47  | Spacer                              |
| 13  | Washer                        | 48  | Grid closing microswitch            |
| 14  | Spacer                        | 49  | Spring                              |
| 15  | Rubber gasket                 | 50  | Microswitch plate                   |
| 16  | Bushing for connecting rod    | 51  | Manual movement reverse microswitch |
| 17  | Lifting shaft                 | 52  | Limit switch lever                  |
| 18  | Cylinder movement lever       | 53  | Handwheel                           |
| 19  | Grid rod                      | 54  | Toothed sector                      |
| 20  | Bushing                       | 55  | Handle                              |
| 20b | Eccentric bushing             | 56  | Lever                               |
| 21  | Right hand connecting rod     | 57  | Handle spring                       |
| 22  | Upper scraper shaft holder    | 58  | Microswitch spacer                  |
| 23  | Upper scraper                 | 59  | Manual movement reverse control rod |
| 24  | Lifting shaft protection      | 60  | Manual control knob                 |
| 25  | Spacer                        | 61  | R.H belt drive cylinder             |
| 26  | Bowl support                  | 62  | L.H belt drive cylinder             |
| 27  | Protection grid               | 63  | Mobile cylinder                     |
| 28  | Fixed cylinder                | 64  | Idle pinion                         |
| 29  | Lower scraper                 | 65  | Limit switch sector lever           |
| 30  | Lower scraper tension spring  |     |                                     |
| 31  | Scraper location sector       |     |                                     |
| 32  | Spacer                        |     |                                     |
| 33  | Pinion Z=16 3/8"              |     |                                     |
| 34  | V belt A58                    |     |                                     |
| 35  | Pulley                        |     |                                     |

