

# Зип Общепит

vsezip.ru

## SM-120a SPIRAL MIXER PARTS LIST

| Parts Number | Parts Code       | Parts Name                       |
|--------------|------------------|----------------------------------|
| SM120a001    | 16JCQCN25-1      | Electromagnetic Contactor        |
| SM120a002    | 16JCQCN18-1      | Electromagnetic Contactor        |
| SM120a003    | 16JCQCN11-1      | Electromagnetic Contactor        |
| SM120a004    | 16JDQJZX-18FF    | Relay                            |
| SM120a005    | 16JDQJZX-18FF-1  | Auxiliary Relay                  |
| SM120a006    | 16BXSZD          | Fuse                             |
| SM120a007    | 16ZLQQS          | Rectifier                        |
| SM120a008    | 16BYQJBK100-1    | Transformer                      |
| SM120a009    | 16JDQ-H3B/A      | Timing Relay                     |
| SM120a010    | 16DZP280101      | Plate                            |
| SM120a011    | 16JDQRHN10A-2    | Thermal Relay                    |
| SM120a012    | 16JDQRHN10A-3    | Thermal Relay                    |
| SM120a013    | 16LSLCI-18       | Mechanical-interlock             |
| SM120a014    | 16JDQRHN10A-5    | Thermal Relay                    |
| SM120a015    | 16JDQRHN80A2-1   | Thermal Relay                    |
| SM120a016    | 14RB180-04       | Drive Belt Wheel                 |
| SM120a017    | 15PDL1950        | Belt                             |
| SM120a018    | 14M370-12T       | Main Shaft                       |
| SM120a019    | 14RB265-01       | Axes                             |
| SM120a020    | 16MBOMX-005      | Control Panel(Two-Timer Model)   |
| SM120a020-1  | 16MBLOMX-019-01  | Control Panel(Three-Timer Model) |
| SM120a021    | 16MBOMX-005      | Printed Circuit Board 1          |
| SM120a022    | 16MBOMX-005      | Printed Circuit Board 2          |
| SM120a023    | 16KGLAR22PR-322B | Switch                           |
| SM120a024    | 16KGLBE101       | Button                           |
| SM120a025    | 16KGLLE3-63      | Power Switch                     |
| SM120a026    | 16KGLZA2-BS54    | Emergency Switch                 |
| SM120a027    | 16KGLZA2-BS55    | Emergency Switch                 |
| SM120a028    | 16KGLZA2-BS56    | Emergency Switch                 |
| SM120a029    | 14RB220-02       | Safety Cover Holder              |
| SM120a030    | 14RB220-02       | Safety Cover Holder              |
| SM120a031    | 13RB210-02       | Safety Cover                     |
| SM120a032    | 13M640-12T       | Fixture Block                    |
| SM120a033    | 13RB215-02       | Safety Cover                     |
| SM120a034    | M620-12T         | Bowl                             |
| SM120a035    | Y605             | Truckle                          |
| SM120a036    | RB110-01         | Handlebar                        |
| SM120a037    | 14M630-12T       | Hook                             |
| SM120a038    | M650-12T         | Center Pillar                    |
| SM120a039    | 16MDL120TS-1     | Top Motor                        |
| SM120a040    | 16MDL120aFX-1    | Bottom Motor                     |
| SM120a041    | 11RB350-01       | Oil Tank                         |
| SM120a042    | 15ZCL6304VV      | Bearing                          |
| SM120a043    | 14M840-05        | Assistant Wheel                  |

# Зип Общепит

|           |                |                              |
|-----------|----------------|------------------------------|
| SM120a044 | 15LZLZ4        | Active Wheel                 |
| SM120a045 | 14RB175-04     | Bearing Housing              |
| SM120a046 | 14RB080-02     | Shaft of Assistant Wheel     |
| SM120a047 | RB067-01       | Adjusting Plate              |
| SM120a048 | 14RB031-04     | Friction Gear                |
| SM120a049 | 13RB205-02     | Guide Rod                    |
| SM120a050 | 15ZCL6205VV    | Bearing                      |
| SM120a051 | 15ZCL32211     | Bearing                      |
| SM120a052 | 15ZCL6310VV    | Bearing                      |
| SM120a053 | 15ZCL6310VV    | Bearing                      |
| SM120a054 | 15ZCL6210VV    | Bearing                      |
| SM120a055 | 14RB195-04     | Drive Shaft                  |
| SM120a056 | 14RB185-04     | Friction-gear Of Drive Shaft |
| SM120a057 | 16TYF-200a     | Preddure Regulating Valve    |
| SM120a058 | 16JLF-200a     | Throttle Valve               |
| SM120a059 | 16YB-200a      | Oil Gauge                    |
| SM120a060 | 16ZZF-200a     | Needle Valve                 |
| SM120a061 | 15YYG-200a     | Hydraulic Cylinder           |
| SM120a062 | 16BP-200a      | Motor                        |
| SM120a063 | 16DCF-200a     | Electromagnetic Valve        |
| SM120a064 | 16ZLF-200a     | Check Valve                  |
| SM120a065 | 16ZTDXF-200a   | Straight Rebound Valve       |
| SM120a066 | 15GLQ-200a     | Filter                       |
| SM120a067 | 15HPF3H3H0HM   | Oil Pump                     |
| SM120a068 | 15HPF3H3H01M   | Oil Pump                     |
| SM120a069 | 15HPB3T3HI     | Pump Connector               |
| SM120a070 | 15HPB3T3HL     | Right-angle Connector        |
| SM120a071 | 15HPB3T3TI     | Straight Connector           |
| SM120a072 | 15HPB4T3HL     | Right-angle Connector        |
| SM120a073 | 16YYMD-1       | Hydraulic Motor              |
| SM120a074 | 15MFQP9        | O Ring                       |
| SM120a075 | 15MFQ50×3.1    | O Ring                       |
| SM120a076 | 15MFUN40/50    | O Ring                       |
| SM120a077 | 15MFQUN28/35.5 | O Ring                       |
| SM120a078 | 15MFQDH28/36   | O Ring                       |
| SM120a079 | 11RB310-02     | Fixed Clasp                  |
| SM120a080 | 14RB345-01     | Fixed Mandrel                |
| SM120a081 | RB310-01D      | Axes                         |
| SM120a082 | 14V783-02      | Tension Spring               |