

Зип Общепит

vsezip.ru

+7(812)987-08-81




091FR1G

Edition 20131016-

Зип Общий

vsezip.ru

+7(812)987-08-81





Зип Общепит

vsezip.ru

+7(812)987-08-81

Зип Общепит
vsezip.ru
+7(812)987-08-81



| Page | Pos | Code | Description | Info |
|------|-----|---------|------------------------------------|-------------|
| 002 | 001 | 3010573 | HANDLE | 04/10/2013- |
| 002 | 002 | 6029110 | HINGE ASSEMBLY | 19/05/2010- |
| 002 | 003 | 6029110 | HINGE ASSEMBLY | 19/05/2010- |
| 002 | 004 | 3015831 | EL. CONTROL ASS.Y | 13/12/2007- |
| 002 | 005 | 3051310 | UPPER CONTROL BOARD | 01/03/2006- |
| 002 | 006 | 3057951 | GAS TOP C/WELL ASS. Y | 19/09/2011- |
| 002 | 007 | 30Q1810 | EXT FLUE ASS. Y | 01/03/2006- |
| 002 | 008 | 3152240 | THERMOSTAT PROTECT. | 01/03/2006- |
| 002 | 009 | 3106730 | ORANGE LIGHT 230V | 23/05/2007- |
| 002 | 010 | 3106710 | GREEN LIGHT 230V | 23/05/2007- |
| 002 | 011 | 6300738 | THERMOSTAT REPLACING KIT | 29/09/2009- |
| 002 | 012 | 6024400 | ASSEMBLY COCK | 15/03/2007- |
| 002 | 013 | 3104520 | LID + HANDLE | 13/04/2007- |
| 002 | 014 | 3111500 | COCK HANDLE | 15/03/2007- |
| 002 | 015 | 3600090 | MAGNET PLATE | 01/03/2006- |
| 002 | 016 | 36A2320 | BOTTOM PLATE | 01/03/2006- |
| 002 | 017 | 36A2340 | BASKET 370X150X120 | 01/03/2006- |
| 002 | 018 | 36C2680 | FLUE GUARD | 01/03/2006- |
| 002 | 019 | 36M5430 | HANDLE | 01/03/2006- |
| 002 | 020 | 3212440 | DRAIN PIPE | 26/07/2012- |
| 002 | 021 | 6029880 | DOOR ASS.Y | 20/06/2012- |
| 002 | 022 | 3151080 | "O" RING Ø 29.80 | 01/03/2006- |
| 002 | 023 | 35R1452 | PROFILE OMEGA | 01/03/2006- |
| 003 | 001 | 3007720 | BURNER 8 KW | 01/03/2006- |
| 003 | 002 | 3066050 | FLEXIBLE PIPE DN12 L=600 | 01/03/2006- |
| 003 | 003 | 3072140 | SUPPORT BURNER | 01/03/2006- |
| 003 | 004 | 3079320 | FLEXIBLE PIPE L=750 | 25/05/2007- |
| 003 | 005 | 3072800 | GAS MANIFOLD | 01/03/2006- |
| 003 | 006 | 32A2361 | CABLE "HF" 1200MM | 16/10/2013- |
| 003 | 007 | 3232960 | IGNITION PLUG | 16/10/2013- |
| 003 | 008 | 33A0020 | COMPL. VALVE | 01/03/2006- |
| 003 | 009 | 33A0460 | "GAS THERMOST. NOVASIT 820 1/2"" | 01/03/2006- |
| 003 | 009 | 33A1640 | "GAS THERMOST. NOVASIT 820 1/2"" | 01/03/2006- |
| 003 | 010 | 33A0690 | PILOT BURNER BODY | 01/03/2006- |
| 003 | 011 | 33A0950 | Ø0,40 REAR BRACKET | 01/03/2006- |
| 003 | 012 | 33A0970 | RING NUT | 01/03/2006- |
| 003 | 013 | 33A1081 | THREE-FLAME BURNER | 24/04/2008- |
| 003 | 014 | 6021770 | INTERRUPTED THERMOC. M9X1X1000 CAB | 07/05/2006- |
| 003 | 015 | 33Q2571 | "REDUCTION MF 3/8""-1/2"" | 01/03/2006- |
| 003 | 016 | 36Q0030 | BICONE Ø12X8 | 01/03/2006- |
| 003 | 017 | 36Q0050 | BICONE NUT Ø 12 | 01/03/2006- |
| 003 | 018 | 36Q0710 | BICONE SCREW Ø 12 | 01/03/2006- |
| 003 | 019 | 36Q0740 | PLUG | 01/03/2006- |
| 003 | 020 | 36M5430 | HANDLE | 01/03/2006- |
| 003 | 021 | 36Q1000 | CLOSING BICONE NUT Ø4 | 25/05/2007- |
| 003 | 022 | 36Q1040 | BICONE Ø4 | 25/05/2007- |
| 004 | 001 | 32A1640 | CABLE "HF" 150MM | 01/03/2006- |
| 004 | 002 | 32D0171 | TERMINAL BOARD | 01/03/2006- |
| 004 | 003 | 32D0830 | FAIRLEAD Ø 8 | 01/03/2006- |
| 004 | 004 | 32T0210 | SPARK IGNITION DEVICE | 01/03/2006- |
| 004 | 005 | 32X0130 | GROMMET Ø29-Ø37 | 01/03/2006- |

| Page | Pos | Code | Description | Info |
|------|-----|---------|-------------------|-------------|
| 004 | 006 | 32X0140 | GROMMET Ø13,5-Ø25 | 01/03/2006- |
| 004 | 007 | 32Z5612 | SAFETY THERMOSTAT | 04/12/2008- |
| 004 | 008 | 37Q3270 | SWITCH COVER | 01/03/2006- |
| 004 | 009 | 35N1612 | BOTTOM PLATE | 01/03/2006- |

+7(812)987-08-81