

Зип Общепит
vsezip.ru
+7(812)987-08-81



IS101LR

Edition 20130701-

vsezip.ru

This exploded view diagram illustrates the assembly of a refrigerator. The main components are shown in their relative positions, with parts numbered 1 through 70. Callouts provide detailed views of specific sub-assemblies:

- Top Left Callout:** Shows the compressor and fan assembly, including parts 29, 33, 7, 50, 39, 14, 43, 26, 41, 57, 43, 41, 50, 7, 63, 34, and 47.
- Bottom Left Callout:** Shows the base panel assembly, including parts 10, 22, 27, 36, 45, 8, 45, 67, and 6.
- Bottom Center Callout:** Shows the bottom drawer assembly, including parts 12, 31, 16, 19, 68, 69, 23, 24, 25, 9, 32, 20, 11, 2, 44, 58, 65, 61, 64, and 66.

The main diagram shows the refrigerator body (1) with the door (5) and inner door panel (62). The door is equipped with a handle (2) and a lock (4). The interior features shelves (48) and a crisper drawer (6). The bottom section includes a base panel (6) and a bottom drawer (37) with a handle (38). The compressor and fan assembly (29) is mounted at the bottom left, and the condenser coils (64) are located at the bottom right.

Pos	Code	Description	Info
001	6014910	DOOR UNIT	01/03/2005-
002	3049200	ELECTRONIC CARD	01/03/2005-
003	3192250	FRONT PANNEL	19/07/2011-
004	3186790	FRAME	19/07/2011-
005	30F1140	DOOR	01/03/2005-
006	30G3710	PLUG	01/03/2005-
007	30T2690	BRACKET	01/03/2005-
008	30W4600	TRAY X ASSEMBLY	01/03/2005-
009	32D0220	CABLE CLAMP Ø 16	01/03/2005-
010	32D0710	THREE-POLE CONNECTOR	01/03/2005-
011	32D0761	TERMINAL BOARD	01/03/2005-
012	32D1350	CABLE CLAMP	01/03/2005-
013	32G2280	HEATING ELEMENT	01/03/2005-
014	32M6850	FAN	01/03/2005-
015	32V3730	NTC PROBE	01/03/2005-
016	32V5170	CONDENSER	01/03/2005-
017	32V6010	EVAPORATOR PROBE NTC	01/03/2005-
018	32V7960	PIN PROBE	01/03/2005-
019	32V8100	PART.MODULE	01/03/2005-
020	32V8320	TRANSFORMER	01/03/2005-
021	32W3460	MICROSWITCH	08/06/2006-
022	32Z2750	COIL	01/03/2005-
023	32Z9500	FUSE-HOLDER	01/03/2005-
024	32Z9730	SWITCH	01/03/2005-
025	32Z9890	FUSE	01/03/2005-
026	33A2110	THERMOST. VALVE	01/03/2005-
027	33G0070	VALVE	01/03/2005-
028	33Q4390	COUPLING TUBES	01/03/2005-
029	34D6380	EVAPORATOR	01/03/2005-
031	35L0840	PANEL BOARD	01/03/2005-
032	35L5190	COVER	01/03/2005-
033	3136180	EVAP. HEAD	19/02/2008-
034	3136170	BOTTOM EVAP. HEAD	19/02/2008-
036	35R1500	SUPPORT	01/03/2005-
037	35R8420	""""S""""FRAME"	01/03/2005-
038	3057470	CONDENS. DRAIN	01/07/2006-
039	35Y2000	SUPPORT	01/03/2005-
040	35Y2550	PLATE	01/03/2005-
041	35Y3790	PROTECTION MOTOR	01/03/2005-
042	3082260	TOP BRACKET	19/07/2011-
043	36A4280	FRIDGE FAN GUARD	01/03/2005-
044	36C2750	SPACER	01/03/2005-
045	3137690	FOOT	26/04/2010-
046	36C5620	PLUG	01/03/2005-
047	36C5700	PROTECT GRID	01/03/2005-
048	3217460	RH RACK	01/07/2013-
049	3217470	LH RACK	01/07/2013-
050	36E0410	BUSHING	01/03/2005-
051	3186970	FRAME TRIM	19/07/2011-
052	3186960	FRAME TRIM	19/07/2011-
053	3059930	BOTTOM BRACKET	16/06/2006-

Pos	Code	Description	Info
054	36G6520	HINGE	01/03/2005-
055	36M7820	PIN	10/06/2010-
056	36G9410	PIN	01/03/2005-
057	36M3200	HANDLE	01/03/2005-
058	36G9570	PIN	19/07/2011-
059	36Z0300	COND. TRAY	01/03/2005-
060	36Z2260	CARD PROTECTION	01/03/2005-
061	3178830	SILK-SCREE.PANEL	25/11/2009-
062	37Q5340	GASKET	01/03/2005-
063	3221910	EVAP. GUARD	28/03/2013-
064	3198650	PROTECTION	19/07/2011-
065	3078190	HOLE PLUG	16/06/2006-
066	3069890	PIPE KRYSTAL	02/07/2006-
067	35X1640	DRAIN TRAP	01/07/2006-
068	32D1570	LIVE TERMINAL	03/07/2006-
069	32D1580	TERMINAL END COVER	03/07/2006-
070	36G1140	PIN	19/07/2011-