

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
+	1	SL2924	Knob	
	2	SL2528	Shaft	
+	3	SL2917	Tap	
	4	SL2526	Calotte	
	5	SL2591	ø25xø47x7	Oil seal
	6	SL3125	6204 2RS	Bearing
	7	SL0082	ø47	Seeger
	8	SL2593	ø20xø47x7	Oil seal
	9	SL0130	Gear	
	10	SA2500	Assembly	Calotte
	11	SL0125	Gear	
	12	SL2589	Shaft	
	13	SA1016	400V/3Ph/50Hz	Stator
	13	SA1017	230V/1Ph/50Hz	Stator
	14	SL0128	Gear	
	15	SL0127	ø17xø40x7	Oil seal
	16	SL0131	6203 2RS	Bearing
	17	SL2598	400V/3Ph/50Hz	Rotor
	17	SL2599	230V/1Ph/50Hz	Rotor
	18	SL0121	ø5x10	Pin
	19	SL0119	ø52	Seeger
	20	SL0118	6205 2RS	Bearing
	21	SL0117	Calotte	
	22	SL1841	3Ph+Gnd	Electric cable
	22	SL1671	1Ph+N+Gnd	Electric cable
	23	SL1668	PG11	Cable clamp
+	24	SL0106	Grip	
	25	SA1113	Lever press	
	26	SL3140	Washer	
	27	SL3138	Covering	
+	28	SL0885	Microswitch	
	29	SL0258	Stud	

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
30	SL0108		Nut	
31	SL2833		Cover	
32	SL2573		Tap	
33	SA1012	Assembly	Casing	
34	SA2800		Roller	
35	SL0174		Container	
36	SL2988		Base	
+	37	SL0134	Pusher	
	38	SL0136	Hopper	
	39	SL3986	Stainless-steel	Sleeve
	39	SL2523R0	Food stuff treated cast-iron (without CE norms)	Sleeve
	39	SL3987	Unger	Sleeve
	40	SL0180		Container
+	41	SA5500	Stainless-steel	Screw shaft
	41	SA5400	Food stuff treated cast-iron (without CE norms)	Screw shaft
	41	SA5700	Unger	Screw shaft
	42	SL0823		Pivot
	42	SL0824	Unger	Pivot
+	43	////////		Cutter
+	44	////////		Plate
	45	SL0197	Stainless-steel	Handwheel
	45	SL3328R0	Aluminium (without CE norms)	Handwheel
+	46	SL0891	Start-stop	Push button
	47	SL0177	16µF	Condenser
	48	SL0176		Bracket
+	49	SL0883		Electronic card
	50	SL2651		Bottom
	51	SL0235		Foot
	52	SL0054		Switch
	53	SA1119	Assembly - 15/05/05 f.p.(*)	Casing

vsezip.ru

+7(812)987-08-81

