

Rif./Ref.	Codice/Code	Sigla / Features	Descrizione/Descr
+ 1	CO6595		Cap
2	CO6596		Cover
3	CO7077		Nut
4	3120070	sx ø5	Washer
5	CO7078		Blade
6	CO7079		Whisk
7	CO7080	Lame	Base
8	CO7081		Gasket
9	CO7082		Dragging
+ 10	CO7083	Lexan	Container
+ 10	CO7084	Inox	Container
11	CO7085		Cap
12	CO7086		Magnet
13	CO7087		Rod
14	CO7088		Rod
15	CO7089		Support
16	CO7090		Gasket
17	CO7091		Locking ring
18	CO7092		Insert
19	CO7093		Support
20	CO7094		Washer
21	CO7095	FR150	Casing
21	CO7096	FR2150	Casing
+ 22	CO7026		Push button
23	CO7097		Support
+ 24	CO7098		Microswitch
25	CO7099		Motor
26	CO6481	FR150	Bottom
26	CO7101	FR2150	Bottom
27	CO7063		Foot
28	CO6482	FR150	Cover

+ : ricambio consigliato / spare part suggested

vsezip.ru

+7(812)987-08-81

