

Exploded diagram and spare parts list

Зип Общепит Large contact grills L518, L519 & L530

vsezip.ru

For machines with digital timer:

Click here

+7(812)987-08-81

For machines without digital timer:

Click here

Exploded diagram and spare parts list


For machines with digital timer:

Зип Общепит

Large contact grills L518, L519 & L530











vsezip.ru

+7(812)987-08-81



## Exploded diagram and spare parts list

## Зип Общепит Large contact grills L518, L519 & L530

| Machine   | Explode | Code  | Description             |
|---|---------|---|-------------------------|
| L518 L519 & L530 – Large Contact Grill with Timer | 1       |  | Top Cover               |
| L518 L519 & L530 – Large Contact Grill with Timer | 2       | N482  | main Handle             |
| L518 L519 & L530 – Large Contact Grill with Timer | 3       |  | Mica Plate Upper        |
| L518 L519 & L530 – Large Contact Grill with Timer | 4       |  | Rear Cover              |
| L518 L519 & L530 – Large Contact Grill with Timer | 5       | N154  | Heating Element Upper   |
| L518 L519 & L530 – Large Contact Grill with Timer | 6       |  | Cast Plate Upper        |
| L518 L519 & L530 – Large Contact Grill with Timer | 7       |  | Cast Plate Lower        |
| L518 L519 & L530 – Large Contact Grill with Timer | 8       |  | Hinge                   |
| L518 L519 & L530 – Large Contact Grill with Timer | 9       |  | Plate Connecting Spring |
| L518 L519 & L530 – Large Contact Grill with Timer | 10      | N155  | Heating Element Lower   |
| L518 L519 & L530 – Large Contact Grill with Timer | 11      |  | Insulation Plate Lower  |
| L518 L519 & L530 – Large Contact Grill with Timer | 12      | N126  | Thermal Cut Out         |
| L518 L519 & L530 – Large Contact Grill with Timer | 13      |  | Main Body               |
| L518 L519 & L530 – Large Contact Grill with Timer | 14      |  | Plug & Lead             |

Exploded diagram and spare parts list


For machines without digital timer:

Зип Общепит

Large contact grills L518, L519 & L530

vsezip.ru

+7(812)987-08-81



## Exploded diagram and spare parts list

## Зип Общепит Large contact grill set L518, L519 & L530

| Machine                                | Explode | Code  | Description             |
|--|---------|---|-------------------------|
| L518 L519 & L530 – Large Contact Grill | 1       |  | Top Cover               |
| L518 L519 & L530 – Large Contact Grill | 2       | N482  | main Handle             |
| L518 L519 & L530 – Large Contact Grill | 3       |  | Mica Plate Upper        |
| L518 L519 & L530 – Large Contact Grill | 4       |  | Rear Spring             |
| L518 L519 & L530 – Large Contact Grill | 5       | N154  | Heating Element Upper   |
| L518 L519 & L530 – Large Contact Grill | 6       |  | Cast Plate Upper        |
| L518 L519 & L530 – Large Contact Grill | 7       |  | Cast Plate Lower        |
| L518 L519 & L530 – Large Contact Grill | 8       |  | Hinge                   |
| L518 L519 & L530 – Large Contact Grill | 9       | N480  | Plate Connecting Spring |
| L518 L519 & L530 – Large Contact Grill | 10      | N155  | Heating Element Lower   |
| L518 L519 & L530 – Large Contact Grill | 11      |  | Insulation Plate Lower  |
| L518 L519 & L530 – Large Contact Grill | 12      | N126  | Thermal Cut Out         |
| L518 L519 & L530 – Large Contact Grill | 13      |  | Main Body               |
| L518 L519 & L530 – Large Contact Grill | 14      | N150  | Plug & Lead             |