


Зип Общепит

vsezip.ru

7(812)987-08-81



Зип Общепит

Machine	Explode	Code	Description	Stocked Line
U627	1-7	AB784	Sharpening Stone 1 & 2 with Cover	✓
U627	8	AC323	Tie Bar Knob	✓
U627	8	AC324	Tie Bar	✓
U627	9	n/a	Locking Plate	n/a
U627	10	n/a	Locking Plate Holder	n/a
U627	11	n/a	Screw	n/a
U627	12	AB782	On-Off Switch	✓
U627	13	AC325	Electrical Box	✓
U627	14	n/a	Screw	n/a
U627	15	AB788	Thickness Adjuster Knob	✓
U627	16	AB832	Scale	✓
U627	17	n/a	Dowel	n/a
U627	18	n/a	Cams	n/a
U627	19	n/a	Screw	n/a
U627	20	AC327	Shaft	✓
U627	21	AC328	Slide	✓
U627	22	n/a	Work Table	n/a
U627	23	AC330	Bottom Plate	✓
U627	24	AB763	Rubber Leg	✓
U627	25	AC332	Square Orbit	✓
U627	26	n/a	Shaft	n/a
U627	27	AC335	Cicle Orbit	✓
U627	28	n/a	Slide Core	n/a
U627	29	AC609	Slide Bracket	✓
U627	30	AB770	Handlebar	✓
U627	30	AB773	Handle Spring	✓
U627	31	n/a	Screw	n/a
U627	32	AC339	Protect Circle	✓
U627	33	AB839	Blade Protection Plate with Circle Bolt	✓
U627	33	AC763	Blade Protection Plate with Square Bolt	✓
U627	34	AB767	Blade Removal Tool	✓
U627	34	AB769	Blade	✓
U627	35	n/a	Screw	n/a
U627	36	n/a	Wire	n/a
U627	37	AC341	Blade Shaft	✓
U627	38	AB765	Belt	✓
U627	39	AB781	Motor	✓
U627	40	n/a	Bolt	n/a
U627	41	n/a	Screw	n/a
U627	42	AC342	Handlebar	✓