



RC14 12-02/2000

B

RC14 FR0200

Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes
0001	0U0678	22052			D			HOPPER COMPLETE (RC14)	
0002	0U0640	20897			D			KNOB BLOCK RC14	
0003	0U0646	20931						LOCKING KNOB RC14	
0004	0U0642	20906						ROTOR RC14	
0005	0D5940	23407						CHAMBER; COUPE RC14	
0006	0U0639	20886						LOCKING PEG	
0007	0KJ586	23393		S				CONTROL BOARD; WITH PUSH-BUTTONS	
0008	099313	22203						PANEL; FRONT	
0009	0U0711	23620			A			SAFETY SWITCH	
0010	0U0645	26026						SEAL; 5 PCS	
0011	0KQ395	3042		S	A			BEARING; 6204 2RS	
0012	0U0677	22051			A			SHAFT CPL.	
0014	0U0641	20900			D			DRIVEN PULLEY RC14	
0015	0U0644	20929			A			BELT RC14	
0016	0U0676	22050			D			S/S BOX	
0017	000000	2204							
0018	0KJ778	23395	0D7962		A			POWER BOARD; 3-PHASE	
0018	0KQ429	23394		S	A			POWER BOARD; 1-P 220/240V-50/60HZ	
0019	0D2360	22049						MOTOR 3 380/415 50 ASSY RC14	
0019	0U0675	22048			D			MOTOR	
0020	0D2576	23623			A			BLADE SAFETY ASSY RC14	
0021	0U0679	22053			A			HINGE RC14	
0022	653018	19542						CHIPPING BLOCK 14X14 MM FOR FRENCH FRIES	
0022	653022	19539						CHIPPING BLOCK 8X8 MM FOR FRENCH FRIES	
0022	653023	19540						CHIPPING BLOCK 10X10 MM FOR FRENCH FRIES	
0022	653024	19541						CHIPPING BLOCK 12X12 MM FOR FRENCH FRIES	
0022	653503	19543						CUTTING BLOCK 4MM FOR POTATO CHIPPER	
0022	653504	19544						CUTTING BLOCK 6MM FOR POTATO CHIPPER	
0022	653505	19545						CUTTING BLOCK 8MM FOR POTATO CHIPPER	
0023	0D0715	22402						BLADE RC14	