

Зип Общепит



Spare parts for:

vsezip.ru

Laundry machines 17(812)987-08-81



Suitable for:

PRIMUS



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.

*Suitable **universal spare parts** may not be included*






Suitable for:

3786155 DOOR GASKET
for Dryer (POLIMATIC) T24 - T35
for Dryer (PRIMUS) T24 - T35



PRIMUS 525107

3786571 DOOR GASKET
ø 580 mm



PRIMUS RSPM406129

3786142 DOOR GASKET ø 560 mm
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55
for Washing machine (WHIRLPOOL) WACS35 - WACS45
WACS55




PRIMUS F02107003214

PRIMUS 273115021915

PRIMUS

Suitable for:

3786156 DOOR GASKET
for Dryer (POLIMATIC) T11 - T13 - T16 - T9
for Dryer (PRIMUS) T11 - T13 - T16 - T9



PRIMUS 519933

3786154 DOOR GASKET ø 530 mm
for Washing machine (GRANDIMPIANTI) WR37
for Washing machine (POLIMATIC) RS35
for Washing machine (PRIMUS) RS35



PRIMUS R35108001814

PRIMUS 273112001766

3186024 DOOR GLASS GASKET ø 325 mm
for Washing machine (GRANDIMPIANTI) WFM11 - WFM6
WFM6S - WFM8 - WF11 - WF8 - WR11 - WR8
for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P65 - P75 - RS10 - RS6 - RS7
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F10 - F6 - F7 - P6 - P7 - RS10 - RS6
RS7
for Washing machine (WHIRLPOOL) LW100 - LW70
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC8



PRIMUS PRI503000004

3186113 DOOR TANK GASKET

external $\varnothing$ 400 mm internal $\varnothing$ 270 mm
 for Washing machine (DANUBE) GF11 - GF18 - GF8
 for Washing machine (GRANDIMPIANTI) WFC8E - WFP6E
 WF11 - WF18 - WF8 - WMC11000 - WMC6000
 WMC8000
 for Washing machine (IPSO) HF110 - HF165 - HF55
 HF65 - HF76 - HF95 - HW131 - HW132 - HW164
 HW165 - HW55 - HW64 - HW72 - HW75 - HW94
 H132
 for Washing machine (POLIMATIC) C6 - C8 - FS10
 FS6 - FS7 - F10 - F6 - F7 - P65 - P75
 for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
 FS7 - F10 - F16 - F6 - F7 - P6 - P7
 for Washing machine (WHIRLPOOL) WACS11 - WACS17
 WACS6 - WACS7 - WACS8




PRIMUS PRI505000045

PRIMUS 526344

3786432 TENSIONING STRIP

for gasket
 for Washing machine (DANUBE) GF11 - GF18 - GF8
 for Washing machine (GRANDIMPIANTI) WFC8E - WFP6E
 WF11 - WF18 - WF8 - WMC11000 - WMC6000
 WMC8000
 for Washing machine (IPSO) HF55 - HW131 - HW164
 HW64 - HW72 - HW75 - HW94
 for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7
 for Washing machine (WHIRLPOOL) WACS11 - WACS6
 WACS7 - WACS8



PRIMUS PRI185000112

3786568 EXTERNAL DOOR GASKET

for Dryer (ASKO) TDC44
 for Dryer (IMESA) ES55 - ES75
 for Dryer (PRIMUS) DAM5
 for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206
 AGB207 - SACE5



PRIMUS 8061815

3786570 EYEHOLE GASKET

$\varnothing$ 430 mm
 for Washing machine (PRIMUS) FS16 - FS22 - LH165
 RS13 - RS22
 for Washing machine (WHIRLPOOL) LWS220



PRIMUS 273112994945

PRIMUS 529575

3186111 EYEHOLE GASKET $\varnothing$ 420 mm

for Washing machine (GRANDIMPIANTI) WMC17 - WMC23
 WM17 - WM23 - WR18 - WR24
 for Washing machine (PRIMUS) RS16 - RS22
 for Washing machine (WHIRLPOOL) WAC17 - WAC23



PRIMUS PRI505000041

3786437 EYEHOLE GLASS GASKET

for Dryer (GIRBAU) SEI12
 for Dryer (IPSO) DR25 - DR35
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - D14 - D25
 for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE15
 SACE17 - SACE25 - SWE131 - SWE140 - SWE151
 SWE251



PRIMUS RSP70030901

PRIMUS RSP70211901



Suitable for:

PRIMUS



Suitable for:

3786143 GASKET FOR DOOR GLASS ø 435 mm

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40 WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55
for Washing machine (WHIRLPOOL) LWS330 - LWS440 LWS550



PRIMUS 273115021905

3786415 GASKET FOR EYEHOLE


for Washing machine (PRIMUS) F5 - P5
for Washing machine (WHIRLPOOL) LWS50



PRIMUS BLO0002401903

3786419 GASKET FOR EYEHOLE

for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - WMC55
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB201 - AGB202 AGB203



PRIMUS 8064025

3786427 GASKET FOR EYEHOLE

for Dryer (GIRBAU) SE112
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA25
for Dryer (WHIRLPOOL) DA11 - DA13 - DA15 - DA25
SACE11 - SACE13 - SACE17 - SWE111 - SWE131
SWE151 - SWE251



PRIMUS RSP70131601

PRIMUS RSP70211601

3786572 LOWER GASKET

length 425 x width 30 mm



PRIMUS 8061980

3786573 SIDE GASKET

length 490 x width 30 mm



PRIMUS 8061616


3786575 TANK DOOR GASKET



PRIMUS BLO002133500

3786434 TANK GASKET - 12 HOLES

for Washing machine (PRIMUS) P6 - P7 - RS10 - RS7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC11 - WAC8



PRIMUS PRI505000001



Suitable for:

PRIMUS ЗИП Общепит



Suitable for:

Bearings

3063087 BEARING FOR TANK

for Washing machine (PRIMUS) F6 - RS6 - RS7
for Washing machine (WHIRLPOOL) LWS70 - LW70
WAC8



PRIMUS PRI608000004

PRIMUS ROULE6206


3063088 BEARING FOR TANK

for Washing machine (PRIMUS) LWS100 - LWS70
LV100 - LW70 - RS7 - WAC11 - WAC17
for Washing machine (WHIRLPOOL) F10 - F6 - F7
RS10 - RS16 - RS6 - WAC8



PRIMUS PRI608000002

3063094 BEARING HOLDER PLATE 6204



PRIMUS RSP70013901

3063044 BEARING 3305A 2RS


for PRIMUS WASHING MACHINE P7-C8
for POLIMATIC WASHING MACHINE P75
for Washing machine (POLIMATIC) P75
for Washing machine (PRIMUS) C8 - P7
for Washing machine (WHIRLPOOL) WACS7



PRIMUS 510904

3063045 BEARING 3307A 2RS

for Washing machine (POLIMATIC) P75
for Washing machine (PRIMUS) C8 - P7
for Washing machine (WHIRLPOOL) LWS160 - WACS7
WAC17



PRIMUS 510903

3063048 BEARING 6209 2Z

for Washing machine (DOMUS) DFI9 - W10 - W9
for Washing machine (FAGOR) LA-10M - LB-10M - LC-8
LF-8
for Washing machine (PRIMUS) F10 - F7 - RS10
RS16
for Washing machine (WHIRLPOOL) LWS100 - LW100
WAC11 - WAC17



PRIMUS PRI608000067

3063093 BEARING 6306 2RS

for Washing machine (PRIMUS) F5 - P5
for Washing machine (WHIRLPOOL) LWS50 - LWS51




PRIMUS BLO0008003000

PRIMUS BLO00080030000

3063002 BEARING 6307 2RS

for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P65 - RS13
for Washing machine (PRIMUS) C6 - FS10 - FS6 - FS7
P5 - P6 - RS13
for Washing machine (WHIRLPOOL) LWS51 - WACS11
WACS6 - WACS8
for Washing machine (ZANUSSI)



PRIMUS BLO0008003100

PRIMUS BLO00080031000


PRIMUS PRI608001048



Suitable for:

3063013 BEARING 6310 2Z

for Washing machine (DANUBE) GF23 - GF26
for Washing machine (GIRBAU) HS6017 - WR23 - WR26
for Washing machine (GRANDIMPIANTI) GF23 - GF26
WR26
for Washing machine (IPSO) WFF135 - WFF150
WFF165 - WFF185 - WFF235 - WF135 - WF150
WF165 - WF185 - WF235
for Washing machine (MARENO) FM12 - FM18E - FM18G
FM18V - FM8
for Washing machine (POLIMATIC) FS16 - RS18 - RS22
for Washing machine (PRIMUS) FS16 - RS18 - RS22
for Washing machine (WHIRLPOOL) LWS160 - WACS17
WAC17/23



PRIMUS PRI608002048

PRIMUS

Suitable for:

5044505 BEARING 6312 2RS1


for Washing machine (PRIMUS) F22 - WACS17



PRIMUS PRI608000080

3063108 KIT PIN FOR DRUM

for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SWE111 - SWE131 - SWE151




PRIMUS RSP70244701P

PRIMUS 70244701P


5044504 ROLLER BEARING NU2215 ECP

for Washing machine (PRIMUS) F22 - WACS17



PRIMUS PRI608000079

3063095 SPACER



PRIMUS RSP430352

3063106 WHEEL FOR BASKET SUPPORT

for Dryer (IMESA) ES5
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB205 - AGB207 - SACES



PRIMUS 8052622

Belts

3062087 BELT IMESA A 049



PRIMUS RSP70298701

5042708 BELT XPZ 1950LW

for Washing machine (IPSO) WE234 - WE245



PRIMUS PRI607000072

3062064 BELT 0209Y09B17 2350 mm

length 2375 mm
for DRYER DANUBE DD8
for DRYER FAGOR SE/7
for DRYER IPSO DD8
for DRYER GIRBAU SDE7
for DRYER PRIMUS D9-DA9-DAM/S9
for DRYER WHIRLPOOL SACE8-SACE86-SACE8T-SWE90-SWE290-SWE390-SW91-SW291-SW391
for Dryer (DANUBE) DD8
for Dryer (FAGOR) S/E-7
for Dryer (GIRBAU) SDE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8C - SACE8T
SWE290 - SWE291 - SWE390 - SWE391 - SWE90



PRIMUS RSP510178

PRIMUS RSP511255P

PRIMUS RSP591174

3062022 MULTIGRIP BELT J 1209 H12 4 GROOVES

for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (GRANDIMPIANTI) WFEC5
for Washing machine (IMESA) LM5
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB201
AGB202 - AGB203



PRIMUS 8061682

3062032 MULTIGRIP BELT J 1549 H14 5 GROOVES

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (POLIMATIC) P65 - P75 - RS10
RS6 - RS7
for Washing machine (PRIMUS) P6 - P7 - RS10 - RS6
RS7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC11 - WAC23 - WAC8



PRIMUS 509940

3062023 MULTIGRIP BELT 7PH 1970 H11 6 GROOVES

with belt tightening spring kit
for Dryer (ASKO) TDC44 - TD33
for Dryer (IMESA) ES5
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206
AGB207 - SACE5



PRIMUS 8061961

PRIMUS 8065710

PRIMUS 8801267

3062067 SMOOTH BELT V TT138

for Dryer (PRIMUS) D15 - D25 - D35
for Dryer (WHIRLPOOL) SACE25 - SWE150 - SW25



PRIMUS RSPM401182

3062066 TOOTHED BELT MULTIV J8 1165

for Dryer (PRIMUS) D15
for Dryer (WHIRLPOOL) SWE150



PRIMUS RSP56095

3062071 TOOTHED BELT POLY V 1150J

for Dryer (PRIMUS) D14 - D15 - D25 - D35
for Dryer (WHIRLPOOL) SACE25 - SWE150 - SW25



PRIMUS RSPM411425



Suitable for:

3062069 TOOTHED BELT POLY V 2391 J

for Dryer (GIRBAU) ST112
for Dryer (IPSO) DR25
for Dryer (PRIMUS) DA11 - DA13
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SWE111
SWE131



PRIMUS RSP70053105

3062065 TOOTHED BELT POLY V 2606J

for Dryer (IPSO) DR35
for Dryer (PRIMUS) DA15
for Dryer (WHIRLPOOL) SACE17 - SWE151



PRIMUS RSP70053104

3062098 TOOTHED BELT SPZ 1562 LW



PRIMUS PRI607000093

3062106 TOOTHED BELT SPZX 1512

for Washing machine (AGA) 520/16



PRIMUS PRI607000110

3062036 TOOTHED BELT XPA 2650

for double-motor machines
for Washing machine (POLIMATIC) FS40 - FS55
for Washing machine (PRIMUS) FS40 - FS55



PRIMUS PRI607000095

PRIMUS 272111002650

PRIMUS

Suitable for:

3053552 BELT TENSIONING ROLLER



PRIMUS RSP70050401

PRIMUS 70050401

3053552 BELT TENSIONING ROLLER



PRIMUS RSP70050401

PRIMUS 70050401

3062111 TOOTHED BELT SPZ 2037



PRIMUS COURROIEXPZ2030

PRIMUS PRI607000099

5041457 TOOTHED BELT TM M406386 DF

height 12 mm - length 1600 mm
for Dryer (PRIMUS) D14
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM406386

3062035 TOOTHED BELT XPA 2582

for single-motor machines
for Washing machine (GRANDIMPIANTI) WFM40 - WFM55
for Washing machine (POLIMATIC) FS40 - FS55
for Washing machine (PRIMUS) FS40 - FS55



PRIMUS 503526

PRIMUS 529776



3062031 TOOTHED BELT XPZ 1000

for double-motor machines
for Washing machine (GRANDIMPIANTI) WM40000
for Washing machine (IPSO) HF205
for Washing machine (POLIMATIC) FS40 - FS55
for Washing machine (PRIMUS) FS40 - FS55



PRIMUS PRI607000096

PRIMUS 272111001000

3062105 TOOTHED BELT XPZ 1137 LW

vsezip.ru

+7(812)987-08-81



PRIMUS PRI607000092

3062024 TOOTHED BELT XPZ 1587

for Washing machine (GRANDIMPIANTI) WFM11
for Washing machine (POLIMATIC) FS6
for Washing machine (PRIMUS) FS6
for Washing machine (WHIRLPOOL) WACS11



PRIMUS 101175

3062070 TOOTHED BELT XPZ 1600

width 9mm



PRIMUS COURR1575

PRIMUS PRI607000075

PRIMUS 102350

3062107 TOOTHED BELT XPZ 2160



PRIMUS 272111002160

3062109 TOOTHED BELT XPZ 2187



PRIMUS COURR2187XPZ

PRIMUS PRI607000070

3062034 TOOTHED BELT XPZ 2280

for double-motor machines
for Washing machine (POLIMATIC) FS33
for Washing machine (PRIMUS) FS33



PRIMUS PRI607000065

3062033 TOOTHED BELT XPZ 2360

for single-motor machines
for Washing machine (GRANDIMPIANTI) WFM33
for Washing machine (POLIMATIC) FS33
for Washing machine (PRIMUS) FS33



PRIMUS 515454

3062037 TOOTHED BELT XPZ 987

for double-motor machines
for Washing machine (POLIMATIC) FS33
for Washing machine (PRIMUS) FS33



PRIMUS PRI607000080

3062068 V TOOTHED BELT 5PJ1956

for Dryer (PRIMUS) D5
for Dryer (WHIRLPOOL) SWE50 - SWE51



PRIMUS BLO2603700



Suitable for:

PRIMUS Общепит



Suitable for:

3062110 V-BELT XPZ 1320

for Washing machine (PRIMUS) F22 - F22S
for Washing machine (WHIRLPOOL) LWS220 - WAC23



vsezip.ru


+7(812)987-08-81

PRIMUS PRI607000085

Castors

3062080 WHEEL FOR MANIFOLD

for Dryer (DANUBE) DD8
for Dryer (GIRBAU) SE/7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE90



PRIMUS RSP510708P

3062075

AXIS

for pulley



PRIMUS RSP56461

PRIMUS RSP56461P

3062084 CLAMP



PRIMUS RSP23748

3062082

WASHER

for Dryer (DANUBE) DD8
for Dryer (FAGOR) SE/7
for Dryer (GIRBAU) SDE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8T - SACE86
SWE290 - SWE390 - SWE90 - SW291 - SW391 - SW91



PRIMUS RSP52549

Circlips

3391029 CLAMP

for bearing



PRIMUS PRI242000008

3391030

CLAMP

for bearing
for Washing machine (POLIMATIC) RS10 - RS16
for Washing machine (PRIMUS) F10 - F7 - RS10
RS16
for Washing machine (WHIRLPOOL) LWS100 - LW100
WAC11 - WAC17



PRIMUS PRI242000009



Suitable for:

3002010 SEEGER RING



PRIMUS 307732030080

PRIMUS

Suitable for:

3002011 SEEGER RING ø 100 mm



PRIMUS 307732030100

Contact thermostats

3744089 CONTACT THERMOSTAT FOR ELEMENT



PRIMUS BLO001406000

PRIMUS BLO01406000

3744090 CONTACT THERMOSTAT FOR ELEMENT



PRIMUS RSPM401404

5041552 CONTACT THERMOSTAT L340-50F 140°C


for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D14
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SWE111 - SWE131 - SWE151



PRIMUS RSPM409433

3744038 CONTACT THERMOSTAT 150° C

mounting distance 40 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



PRIMUS 8008487

3744033 SAFETY THERMOSTAT

for Dryer (FAGOR) S/E-7
for Dryer (GIRBAU) SE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP510183

PRIMUS RSP511412

PRIMUS RSP62600

3744035 SAFETY THERMOSTAT

for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SWE111 - SWE131 - SWE151



PRIMUS RSPM411307






Suitable for:

PRIMUS



3744037 SAFETY THERMOSTAT

for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SWE111 - SWE131 - SWE151 - SWE250



PRIMUS RSPM410220

5043418 SAFETY THERMOSTAT

for Dryer (PRIMUS) D14
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM406413

3744076 SAFETY THERMOSTAT KIT 350°C

for Dryer (PRIMUS) D25
for Dryer (WHIRLPOOL) SACE25 - SWE250



PRIMUS M4347P3

PRIMUS RSPM4347P3

3744036 SAFETY THERMOSTAT 225°C

for Dryer (FAGOR) S/E-7
for Dryer (GIRBAU) SE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE390
SWE90 - SWE91



PRIMUS RSP510701

PRIMUS RSP62641

5054352 SAFETY THERMOSTAT 230°C


for Dryer (PRIMUS) T11 - T13 - T24 - T9



PRIMUS 514127

3744029 SAFETY THERMOSTAT 300°C

for Dryer (PRIMUS)
for Dryer (WHIRLPOOL)



PRIMUS RSP56082

Contactors

3454025 CONTACTOR MOD. LC1 D32

for heating 220-230V-50Hz-7.5Kw
for Washing machine (GRANDIMPIANTI) WFP120
for Washing machine (PRIMUS) FS10 - FS120 - FS16
FS23 - FS7 - MB140 - MB180 - MB26 - MB33
MB44 - MB66 - MB90 - RS10 - RS16 - RS22 - RS7
XS22
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS28AE - WACS28AV - WACS35AE - WACS35AV
WACS46AE - WACS46AV - WACS70AE - WACS70AV
WACS8 - WAC11 - WAC17 - WAC23 - WAC8




PRIMUS PRI345002019

PRIMUS 345002019

3454024 CONTACTOR 4S - MOD. TP3250

'16A 250V - 10A 400V
'50/60Hz
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



PRIMUS 8009148

PRIMUS 8064179



Suitable for:

3454027 3-PHASE CONTACTOR

for motor 24V-2.2Kw

for Dryer (PRIMUS) DA11 - DA13 - DA15

for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17

SWE111 - SWE131 - SWE151



PRIMUS RSPM413614

PRIMUS ЗИП-Общепит

Suitable for:

vsezip.ru

+7(812)987-08-81



Door catches

3242625 DOOR HOOK

for Washing machine (PRIMUS) P5

for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0005407800

3242637 PLASTIC FINGER


for hook



PRIMUS BLO0003851300

7104461 MECHANICAL DOOR LOCK

for Dryer (PRIMUS) T24



PRIMUS 514530

3242638 HOOK PRESSURE SPRING



PRIMUS BLO0008126400

PRIMUS BLO0008126400

7104465 LOCK PLATE

for Dryer (PRIMUS) T24



PRIMUS 524366



Suitable for:

PRIMUS Зип Общепит



Suitable for:

Drain hoses

3450165 CONNECTION SLEEVE

total length 150 mm
internal ø 110 mm



PRIMUS 101076

5045876 DRAIN PIPE

length 65 mm
for Washing machine (GRANDIMPIANTI) WFM8 - WF8 WR8
for Washing machine (PRIMUS) F6 - F7 - RS6 - RS7
for Washing machine (WHIRLPOOL) LW70 - WACS8 WAC8



PRIMUS 101044

3450164 SLEEVE

overall length 170 mm



PRIMUS PRI5400000032

PRIMUS PRI5400000032

Drain tanks

3527013 TANK FOR CONDENSATE

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5
for Dryer (WHIRLPOOL) AGB205 - AGB207



PRIMUS 8061941

3527014 INJECTOR FOR TANK

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5
for Dryer (WHIRLPOOL) AGB205 - AGB207



PRIMUS 8053077

Electrical gas valves and accessories

7104436 GAS VALVE HONEYWELL VR4605AB1027 230V


for DRIER PRIMUS T24



PRIMUS 102000

3121020 COMPLETE DOOR LOCK WITHOUT DELAYER


for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WF18E
for Washing machine (POLIMATIC) FS16 - FS22 - FS23
FS23PR
for Washing machine (PRIMUS) FS16 - FS22 - FS23
FS23PRO
for Washing machine (WHIRLPOOL) 016004-WACS17



PRIMUS 509473

3242633 COMPLETE LOCK 220V

for washing machine Whirlpool 7.5 KG
mod. WACS8 - 016002 - 10 kg mod. WACS11 016003
Primus 7.5 kg mod. FS7 - 10 kg mod. FS10



PRIMUS PRI610060077

PRIMUS 528054


3242626 KEY LOCK PIN

placed in the locks



PRIMUS PRI610000134


3242636 COMPLETE LOCK 220V



PRIMUS PRI610057077

3803013 DOOR CONTACT

110-240V
for lock mod.682-P10



PRIMUS PRI346000003

PRIMUS 34600003

3240777 MICROSWITCH 8A 250V

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) 016002-WACS8
016003-WACS11 - 016013-WAC8 - 016014-WAC11
016015-WAC17 - 016016-WAC23



PRIMUS PRI610032077

3242652 CONTROL ARM

for lock




PRIMUS PRI610000135



Suitable for:

3803013 DOOR CONTACT
110-240V
for lock mod.682-P10



PRIMUS PRI346000003

PRIMUS 34600003


3240777 MICROSWITCH 8A 250V

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) 016002-WACS8
016003-WACS11 - 016013-WAC8 - 016014-WAC11
016015-WAC17 - 016016-WAC23



PRIMUS PRI610032077

3242631 DOOR LOCK



PRIMUS 8061679

5041476 DOOR LOCK STRIKE

for WASHING MACHINE ASKO WMC55
for WASHING MACHINE IMESA LM5P
for WASHING MACHINE PRIMUS PW5
for WASHING MACHINE WHIRLPOOL AGB200-201-202-203



PRIMUS ASK8061798

PRIMUS

Suitable for:

3242626 KEY LOCK PIN
placed in the locks

+7(812)987-08-81



PRIMUS PRI610000134

3803015 DOOR LOCK CONTACT

for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8061680



3121022 DOOR LOCK 220/240V 50Hz

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (MIELE)
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) C6 - C8 - MB16 - MB16.6
MB33 - MB44 - MB66 - P6 - P7
for Washing machine (WHIRLPOOL) 016017-WACS28AE
016018-WACS28AV - 016019-WACS35AE
016020-WACS35AV - 016021-WACS46AE
016022-WACS46AV - 016023-WACS70AE
016024-WACS70AV



PRIMUS PRI610000075

3121023 DOOR OPENING ELECTROMAGNET 205V

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22



PRIMUS PRI610012077

3121024 DOOR OPENING ELECTROMAGNET 205V

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117001814


3242648 MAGNET FOR DOOR

for door lock



PRIMUS 8061878

3242651 MAGNET SUPPORT 60 x 27 mm



PRIMUS 8061886

Electronic boxes

3091038 FLAME CONTROLLER MOD.MICRO56N24

24V - 50/60Hz
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM413433

PRIMUS RSP70367401P



Suitable for:

PRIMUS


Suitable for:



Electronic printed circuit boards

5048147 CONTROLLER BOARD

for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS33 - FS40 - FS55 - FS6 - FS7 - WACS8



PRIMUS 526008

7104466 ELECTRIC PLATE WITH DISPLAY


for Dryer (PRIMUS) T24



PRIMUS 102459

7104452 LCD SCREEN PROTECTION RUBBERPIECE


for Dryer (PRIMUS) T24



PRIMUS 101275

3390284 ELECTRONIC BOARD

for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SWE111 - SWE131 - SWE151 - SWE250




PRIMUS RSPM413498P

PRIMUS RSPM513498

PRIMUS RSP70228401P

7104499 CONTROL PUSH-BUTTON PANEL


for Dryer (PRIMUS) T24



PRIMUS 547081

3322328 CONTROL KEYBOARD


OPL electronic control
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SWE111 - SWE131 - SWE151



PRIMUS RSP70115801

3390301 ELECTRONIC BOARD MCB FC

for Washing machine (PRIMUS) FS10 - FS16 - FS22
FS33 - FS40 - FS55 - FS6 - FS7 - MB16 - MB26
MB33 - MB44 - MB66 - RS10 - RS13 - RS16 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22 - XS35
XS43
for Washing machine (WHIRLPOOL) LWS220 - WACS11
WACS16AE - WACS17 - WACS23 - WACS28AE
WACS28AV - WACS35 - WACS35AE - WACS35AV
WACS42 - WACS46AE - WACS46AV - WACS55
WACS70AE - WACS70AV - WACS8 - WAC11 - WAC17
WAC23 - WAC8



PRIMUS 100986

PRIMUS 516696

3390283 ELECTRONIC POWER BOARD

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



PRIMUS 8077348

3390336 POWER ELECTRONIC BOARD

mod. EL 101K



PRIMUS 745895

PRIMUS 771985008277

3390282 POWER SUPPLY BOARD PWR

for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16
FS7 - RS10 - RS13 - RS16 - RS18 - RS22 - RS27
RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8 - WAC11 - WAC17 - WAC23 - WAC8



PRIMUS PRI343000212

PRIMUS 516694

3322230 CONTROL KEYBOARD MCB LC

for Washing machine (PRIMUS) FS10 - FS16 - FS22
FS33 - FS40 - FS55 - FS6 - FS7 - MB16 - MB26
MB33 - MB44 - MB66 - RS10 - RS13 - RS16 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22 - XS35
XS43
for Washing machine (WHIRLPOOL) LWS220 - WACS11
WACS16A - WACS17 - WACS23 - WACS28A - WACS28AE
WACS28AV - WACS35A - WACS35AE - WACS35AV
WACS42 - WACS46A - WACS46AE - WACS46AV
WACS55 - WACS70A - WACS70AE - WACS70AV - WACS8
WAC11 - WAC17 - WAC23 - WAC8



PRIMUS 100521

3340065 MOTOR CONTROL UNIT

for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WACS5 - WES5GP - WES5GV
WES5IP - WES5IV



PRIMUS 8061399

3319718 KEY BOARD EASY CONTROL




PRIMUS PRI348000123



Suitable for:

3322327 PROGRAMMER MCBLC

for Washing machine (PRIMUS) FS10 - FS16 - FS7
P6 - P7 - RS10 - RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8 - WAC11 - WAC17 - WAC23 - WAC8



PRIMUS 100984


PRIMUS 516695

PRIMUS

Suitable for:

7104444 TEMPORIZATION PLATE


for Washing machine (PRIMUS) FS10 - FS6 - FS7
WACS8 - W10



PRIMUS 526004

Filters

3160492 COMPLETE FILTER SUPPORT



PRIMUS 8061811

PRIMUS 80797500

3786569 FILTER HOLDER GASKET



PRIMUS 8065274

3160433 FILTER

for Dryer (PRIMUS) D9
for Dryer (WHIRLPOOL) SWE90



PRIMUS RSP500025

PRIMUS RSP502140

PRIMUS RSP502140PV

3160436 FILTER


for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



PRIMUS 8061812

3123129 FILTER FOR CONDENSER

length 360 mm/width.240 mm
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC
for Dryer (PRIMUS) DAMC5
for Dryer (WHIRLPOOL) AGB205 - SACE5



PRIMUS 8063752

3160428 FILTER 510 x 510 mm



PRIMUS RSPM400523



Suitable for:

3160430 FILTER 610 x 610 mm
for Dryer (PRIMUS) D14 - D25
for Dryer (WHIRLPOOL) SACE25 - SWE250
for Washing machine (GIRBAU) SMI12E



PRIMUS RSPM400522

PRIMUS



Suitable for:

3160429 FILTER 620 x 620 mm
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE15
SWE111 - SWE131 - SWE151



PRIMUS RSP70019201

PRIMUS RSP70229101

3160493 GAUZE FILTER



PRIMUS RSP503980

3160494 PILE FILTER



PRIMUS BLO0003831601

Gaskets and seals

3786440 COPPER GASKET 14x20x2 mm STUFFING GLAND



PRIMUS PRI524000001

PRIMUS PRI52400001

3786566 FELT GASKET

for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) BWE111 - SWE111 - SWE131



PRIMUS 70066002

3786429 FELT STRIP
ø 470 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5



PRIMUS 8052649

3391028 FELT STRIP CLAMP
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



PRIMUS 8055054



Suitable for:

PRIMUS



Suitable for:

3786431 GASKET FOR MANIFOLD

ext.ø 410 mm - int.ø 380 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE - ES55 - ES75
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



PRIMUS 8061821

3786423 MANIFOLD GASKET

SWE390-SWE91-SWE291-SWE391
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SE/7
for Dryer (IFSO) DD8
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501801

PRIMUS RSP510207

5043175 RING SUPPORT GASKET

for WASHING MACHINE PRIMUS FS16



PRIMUS F01104000514

PRIMUS PRI505002042

3786418 SELF ADHESIVE FELT SHIM

length 47 mm
for Dryer (PRIMUS) DA9
for Dryer (WHIRLPOOL) 016025-SACE8



PRIMUS RSP501121


PRIMUS RSP58049

3786439 SPACER GASKET



PRIMUS RSP70193801

3786574 TANK GASKET ø 630 mm



PRIMUS PRI505010001

Gears

3212012 CHAIN TENSIONING PINION



PRIMUS RSPM401369

7102433 TRANSMISSION CHAIN

for Dryer (PRIMUS) D14 - SWE140
for Dryer (WHIRLPOOL) SWE140



PRIMUS RSPM401425



Suitable for:

PRIMUS

Suitable for:



Glasses

7104435 DOOR GLASS ø 725 mm

for DRIER PRIMUS T24

5047834 DOOR GLASS
for WASHING MACHINE WFEC 5
for WASHING MACHINE PRIMUS PW5



PRIMUS ASK8061685



PRIMUS 512052

3520012 FRONT DOOR GLASS
for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7
for Washing machine (WHIRLPOOL) WACS11 - WACS6
WACS7 - WACS8



PRIMUS PRI505000044

Handles

3242504 DOOR HANDLE
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02107300024

3242505 DOOR HANDLE PIN
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02107500014

3242506 PIN BUSHING FOR DOOR HANDLE
ø external 20 mm - ø internal 14 - height 20 mm
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS 323622641243

3242507 SCREW BUSHING FOR DOOR HANDLE
ø external 30 mm - ø internal 18 mm - height 45 mm
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02107002315



Suitable for:

3242493 SHAFT CAM

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40

WFM55


for Washing machine (POLIMATIC) FS33 - FS40 - FS55

for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117001214

3242715 DOOR HANDLE



PRIMUS RSP503646

3453020 DRUM PLATE

for Dryer (FAGOR) SE-7

for Dryer (GIRBAU) SE7

for Dryer (IPSO) DD8

for Dryer (PRIMUS) DA9 - D9

for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291

SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501676

PRIMUS RSP501087

3453025 BRACKET

for Dryer (FAGOR) SE-7


for Dryer (GIRBAU) SE7

for Dryer (IPSO) DD8

for Dryer (PRIMUS) DA9 - D9

for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291

SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501554

3242649 ROLL HOLDER - 10 PCS

for Dryer (IMESA) DAM5 - ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE



PRIMUS 8061953-33

PRIMUS

Зип Общепит

Suitable for:

vsezip.ru

77(812)987-08-81



3242491 ROUND DOOR HANDLE

for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS6 - RS7
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS6 - RS7



PRIMUS PRI610011085

3242492 BACKING SPRING


for Washing machine (GRANDIMPIANTI) WFM18 - WFM22
WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS6 - RS7 - XS22
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS6 - RS7 - XS22



PRIMUS PRI611000045

3242490 HANDLE FIXING PLATE

for GRANDIMPIANTI WASHING MACHINE
WFM18-WFM22-WR8
WR11-WR37
for PRIMUS WASHING MACHINE RS6-RS7-RS10-RS13-RS18
RS22-RS27-FS6-FS7-FS10-FS16-FS23-FS23PRO-XS22
for POLIMATIC WASHING MACHINE RS6-RS7-RS10-RS13
RS18-RS22-RS27-FS6-FS7-FS10-FS16-FS23-FS23PRO-XS22




PRIMUS PRI610000082

PRIMUS 223107300013

3242499 ALUMINIUM HANDLE FOR ROUND DOOR

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS6 - RS7
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS6 - RS7



PRIMUS 100219

3242508 FIXING PLATE

ø 10 mm - length 64 mm
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM22 - WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) RS10 - RS13 - RS18
RS22 - RS27 - RS6 - RS7
for Washing machine (PRIMUS) RS10 - RS13 - RS18
RS22 - RS27 - RS6 - RS7



PRIMUS PRI610000089



Suitable for:

PRIMUS

Suitable for:



Heating Elements

3355869 HEATING ELEMENT PROTECTION

flange 80x22 mm
 for Washing machine (IMESA) LM18
 for Washing machine (POLIMATIC) FS10 - FS16 - FS23
 FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7 - P65
 P75 - RS13 - RS27 - RS35
 for Washing machine (PRIMUS) FS10 - FS16 - FS23
 FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7
 MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS13
 RS27 - RS35
 for Washing machine (WHIRLPOOL) WACS11 - WACS28AE
 WACS28AV - WACS35 - WACS35AE - WACS35AV
 WACS42 - WACS46AE - WACS46AV - WACS55 - WACS6
 WACS7 - WACS70AE - WACS70AV - WACS8 - WAC11
 WAC17 - WAC23 - WAC8



PRIMUS PRI342001016

3455344 HEATING ELEMENT GROUP WITH KLIXONS

2400W 400V
 for Dryer (PRIMUS) D45
 for Dryer (WHIRLPOOL) SWE51 - SWE51M



PRIMUS BLO0001622500

3455260 HEATING ELEMENT 10 KW

length 500 mm
 for Dryer (PRIMUS) D25
 for Dryer (WHIRLPOOL) SACE25 - SWE250



PRIMUS RSPM410941

3455262 HEATING ELEMENT 1000 W - 230 V

blue and red
 overall length 265 mm - width 30 mm
 for Washing machine (ASKO) WMC55
 for Washing machine (IMESA) LM5 - LM5EGDP
 LM5EGDV - LM5EIDP - LM5EIDV
 for Washing machine (PRIMUS) PW5
 for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
 AGB201 - AGB201/WP - AGB202 - AGB202/WP
 AGB203 - AGB203/WP - WACS5



PRIMUS 8061704

3355868 HEATING ELEMENT 2x2000W 230V

length 470 mm - width 65 mm
 flange 82x28 mm
 for Washing machine (GRANDIMPIANTI) WFM18 - WFM33
 WR18 - WR24
 for Washing machine (POLIMATIC) FS10 - FS16 - FS33
 FS6 - FS7 - RS10 - RS13 - RS27 - RS35 - RS6
 RS7
 for Washing machine (PRIMUS) FS10 - FS16 - FS33
 FS6 - FS7 - RS10 - RS13 - RS16 - RS22 - RS27
 RS35 - RS6 - RS7
 for Washing machine (WHIRLPOOL) WACS17 - WAC17
 WAC23



PRIMUS PRI342000027

PRIMUS PRI342030027

3355873 HEATING ELEMENT 2000W 230V

length 260 mm - width 65 mm
 flange 80x28 mm
 for Washing machine (FAGOR) LAC-7 - LC-7 - LC/AC-7
 LC/E-7 - LF-7
 for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
 WFM8 - WR11 - WR37 - WR8
 for Washing machine (POLIMATIC) FS10 - FS6 - FS7
 P65 - P75 - RS10 - RS13 - RS6 - RS7
 for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
 FS7 - F10 - F6 - F7 - P6 - P7 - RS10 - RS13
 RS6 - RS7
 for Washing machine (WHIRLPOOL) LSW100 - LWS70
 WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC8



PRIMUS PRI342000011

3455263 HEATING ELEMENT 2000W 230V

white and red
overall length 355 mm - width 30 mm
flange 54x27 mm
for WASHING MACHINE ASKO WMC55
for WASHING MACHINE IMESA LM5
for WASHING MACHINE PRIMUS PW5
for WASHING MACHINE WHIRLPOOL AGB200 A 203-WAC55
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WAC55



PRIMUS 8061703

3355892 HEATING ELEMENT 2750W 230V

length 270 mm - width 65 mm
flange 81x28 mm
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7



PRIMUS 100383

3355894 HEATING ELEMENT 4500W 230/400V

dimensions 360x90x50 mm
for Dryer (IPSO) CD165 - CD220 - CD350
for Dryer (POLIMATIC) T11 - T13 - T16 - T24 - T35
T9
for Dryer (PRIMUS) T11 - T13 - T16 - T24 - T35
T9




PRIMUS 510985

Suitable for:

3455264 HEATING ELEMENT 2500W 230V CONDENSER

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM/C5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE - 016064 - 016066



PRIMUS 8063808

3455257 HEATING ELEMENT 4000W 220V

for Dryer (GIRBAU) SE112
for Dryer (IPSO) DR25
for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA25
for Dryer (WHIRLPOOL) SACE11 - SWE111



PRIMUS RSP70034415

PRIMUS RSP70034416

3455265 HEATING ELEMENT 4500W 380V

for DRIER FAGOR SE-7
for DRIER GIRBAU SE7-SDE7
for DRIER PRIMUS DA9-D9
for DRIER WHIRLPOOL SACE8-SWE90-SWE290-
SWE390-SWE91-SWE291-SWE391
for Dryer (DANUBE) TD8
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SDE7 - SE7
for Dryer (PRIMUS) DA9 - D8 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91




PRIMUS PRI342100053

PRIMUS RSPS11014



Suitable for:

5041537 HEATING ELEMENT 6000W 220V
length 350 mm - flange 95x65 mm
for DRIER PRIMUS D14-DE14-SWE140
for DRIER WHIRLPOOL AGB204 A 207-SACES



PRIMUS RSPM410946

3355874 HEATING ELEMENT 6000W 230V
length 475 mm- width 65 mm
flange 80x28 mm
for Washing machine (GRANDIMPIANTI) WFM40 - WFM55
for Washing machine (POLIMATIC) FS16 - FS23
FS23PRO - FS40 - FS55 - RS27 - RS35 - XS22
for Washing machine (PRIMUS) FS16 - FS23 - FS23PRO
FS40 - FS55 - MB44 - MB66 - RS16 - RS22 - RS27
RS35 - XS22
for Washing machine (WHIRLPOOL) WACS17 - WACS42
WACS46AE - WACS46AV - WACS55 - WACS70
WACS70AE - WACS70AV - WAC17 - WAC23



PRIMUS PRI342000032

PRIMUS 540132

3455252 HEATING ELEMENT 7000W 240V
for DRIER PRIMUS D25
for DRIER WHIRLPOOL SWE250-SACE25
for Dryer (PRIMUS) D25
for Dryer (WHIRLPOOL) SACE25 - SWE250




PRIMUS RSPM405253

PRIMUS Общепит



Suitable for:

3355893 HEATING ELEMENT 6000W 230/400V
dimensions 360x90x50 mm
for Dryer (IPSO) CD165 - CD220 - CD350
for Dryer (POLIMATIC) T11 - T13 - T16 - T24 - T35
for Dryer (PRIMUS) T11 - T13 - T16 - T24 - T35
T9



PRIMUS 510984

3455256 HEATING ELEMENT 7000W 230V
for Dryer (IPSO) DR35
for Dryer (PRIMUS) DA13
for Dryer (WHIRLPOOL) SACE13 - SWE111



PRIMUS RSP70034402

PRIMUS RSP70034403

PRIMUS 70034402

3455255 HEATING ELEMENT 8000W 220V
length 50 mm
flange 95x54 mm
for DRIER PRIMUS DA15
for DRIER WHIRLPOOL SWE151-SACE17
for Dryer (PRIMUS) DA15
for Dryer (WHIRLPOOL) SACE17 - SWE151



PRIMUS RSP70034405

PRIMUS RSP70034406



Suitable for:

PRIMUS



3455261 HEATING ELEMENTS SET 4500 W 380 V

with contactor and klixon
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SDE7 - SE7
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91



PRIMUS PRI342000053

PRIMUS 102730

3355970 HEATING ELEMENT 3000W 230V

length 265 mm - width 65 mm
flange 80x28 mm
for Washing machine (AGA) SUPER25 - SUPER33
for Washing machine (FAGOR) LAC-10 - LC-10
LC/E-10 - LF-10
for Washing machine (GRANDIMPIANTI) WFM11 - WR37
for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P5 - P6 - P65 - P75 - RS10 - RS13 - RS18
RS22 - RS6 - RS7
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F6 - F7 - P6 - P7 - RS10 - RS13 - RS16
RS18 - RS22 - RS6 - RS7
for Washing machine (WHIRLPOOL) LSW100 - LWS70
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17
WAC23 - WAC8



PRIMUS PRI342000028

PRIMUS 540128

Hinges

3053486 COMPLETE HINGE

for round door
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F10 - F6 - F8 - P6 - P7
for Washing machine (WHIRLPOOL) FS16 - LWS70
LW100 - RS16 - SR22 - WACS11 - WACS17 - WACS6
WACS7 - WACS8



PRIMUS 500080

3053494 HINGE FLAP



PRIMUS PRI610000126

3053490 COMPLETE HINGE


for corner door
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16
FS6 - FS7 - F10 - F6 - F8 - P6 - P7 - RS16
SR22
for Washing machine (WHIRLPOOL) LWS70 - LW100
WACS11 - WACS17 - WACS6 - WACS7 - WACS8



PRIMUS PRI155014019

PRIMUS 101377

3053494 HINGE FLAP



PRIMUS PRI610000126



Suitable for:

PRIMUS



Suitable for:

3053484 COMPLETE TOP HINGE

for dryer door 5 kg
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EIC - ES5EIE
RS5EGC
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



PRIMUS 8101803-26

3053485 COMPLETE BOTTOM HINGE

for dryer door 5 kg
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



PRIMUS 8061807-26


3053546 DOOR HINGE



PRIMUS 8061686-42

3053487 HINGE

for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0005326400

3053491 BEARING FOR HINGE

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



PRIMUS 8061865-33

3053550 HINGE PIN

ø 5 x length 135 mm



PRIMUS 8061687

3053492 AXIS

for hinge



PRIMUS BLO0004131702



Suitable for:

3053551 HINGE PIN



PRIMUS PRI610010126

PRIMUS ЗИП Общепит

Suitable for:

vsezip.ru

+7(812)987-08-81



Interference suppression filters

3454019 TRAP CAPACITOR 0.47μF - 16A-275V

50/60 Hz

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (PRIMUS) DAM5

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE

for Washing machine (IMESA) LM5EGDP - LM5EGDV

LM5EIDP - LM5EIDV

for Washing machine (PRIMUS) PW5

for Washing machine (WHIRLPOOL) AGB200/WP

AGB201/WP - AGB202/WP - AGB203/WP - WACS5

WACS5M - WES5GP - WES5GV - WES5IP - WES5IV



PRIMUS 8058558

Ironmongery (screws,nuts,washers)


3063099 NUT

for bearing



PRIMUS RSPM412986

3063098 WASHER FOR BEARING



PRIMUS RSPM400991

Lamps

3221598 LAMP BUSHING

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (PRIMUS) DAM5

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE



PRIMUS 8061887

3221597 LAMP SUPPORT

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC

ES5EIE

for Dryer (PRIMUS) DAM5

for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP

AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE

SE5IC - SE5IE



PRIMUS 8061932



Suitable for:

3221596 WHITE INDICATOR LIGHT
220 V - ø 13 mm



PRIMUS PRI349000032

PRIMUS PRI349000032

PRIMUS **Общепит**



Suitable for:

vsezip.ru

+7(812)987-08-81

Microswitches

3803021 DOOR MAGNETIC CONTACT

for product dispenser
for Washing machine (PRIMUS) MB16 - MB26 - MB33
MB44 - MB66
for Washing machine (WHIRLPOOL) 016017-WACS28AE
016018-WACS28AV - 016019-WACS35AE
016020-WACS35AV - 016021-WACS46AE
016022-WACS46AV - 016023-WACS70AE
016024-WACS70AV



PRIMUS PRI346000030

PRIMUS PRI346000030

3803014 DOOR MICRO CONTACT

5A - 250 V
for Dryer (PRIMUS) DA11 - DA17
for Dryer (WHIRLPOOL) 016028-SACE11
016032-SACE17



PRIMUS RSP70125101

PRIMUS RSR70125101

3803016 DOOR MICRO CONTACT

10 A - 250 V
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE13 - 016028-SACE11
016032-SACE17




PRIMUS RSP70107001

PRIMUS RSR70107001

3803011 DOOR SAFETY DEVICE

for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51



PRIMUS BLO001727000

3803012 MICRO SWITCH

5 A - 250 V
for Dryer (IMESA) ES5EGC - ES5EIC
for Dryer (WHIRLPOOL) AGB205/WP - AGB207/WP
016066-SE5GC - 016066-SE5IC



PRIMUS 8052643

3803023 FLOAT FOR MICRO SWITCH ø 45 mm

for Dryer (IMESA) ES5EGC - ES5EIC
for Dryer (WHIRLPOOL) AGB205/WP - AGB207/WP
016066-SE5GC - 016066-SE5IC



PRIMUS 8053056

3803020 MICRO SWITCH

0.1 A - 250 V

for Washing machine (PRIMUS) P6 - P7

for Washing machine (WHIRLPOOL) 016001-WACS6

016071-WACS7



PRIMUS PRI610028077

3803022 MICRO SWITCH SET for Dryer (PRIMUS) DA13



PRIMUS EXRSP70267301

PRIMUS RSP70267301+...

PRIMUS RSP70266201+...

PRIMUS RSP70270901P

PRIMUS RSP70266301+...

3803044 MICROSWITCH



PRIMUS BLO0001725101

PRIMUS BLO001725101

3803046 MICROSWITCH DOOR 3SE4 300

16(4) A - 380 V



PRIMUS BLO001706600

PRIMUS BLO1706600

7104456 MICROSWITCH U83161.3 4A 250V



PRIMUS 517484

3240795 MICROSWITCH 10A 250V

for Washing machine (GIRBAU) HS5008 - HS6008

HS6017

for Washing machine (PRIMUS) DAMS9



PRIMUS RSP504570

3240778 MICROSWITCH 12A 250V

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55

for Washing machine (POLIMATIC) FS33 - FS40 - FS55

for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117002114

1240014 MICROSWITCH 16A 250V

for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55

for Washing machine (POLIMATIC) FS33 - FS40 - FS55

for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS F02117002224

PRIMUS G.R.CRO831613AR



+7(812)987-08-81



Suitable for:


PRIMUS Общепит



Suitable for:

3240136 MICROSWITCH 16A 250V

for Washing machine (DOMUS) DFI27 - W10
for Washing machine (FAGOR) LA-10M - LA-13M
LA-18M - LA-25M - LB-10M - LB-13M - LB-18M
for Washing machine (GRANDIMPIANTI) WFEC1
WFEC18 - WFEC6 - WFEC8 - WFP50 - WFP63 - WF11
WF18 - WF23 - WF26 - WF33 - WF8 - WR11 - WR18
WR26 - WR33 - WR8
for Washing machine (IPSO) HC100 - HC135 - HC165
HC60 - HC65 - HC75 - HF110 - HF132 - HF145
HF150 - HF165 - HF176 - HF185 - HF205 - HF235
HF245 - HF304 - HF450 - HF55 - HF570 - HF65
HF75 - HF95 - HW131 - HW164 - HW55 - HW64
HW72 - HW94 - WE110 - WE132 - WE165 - WE176
WE181 - WE234 - WE245 - WE304 - WE55 - WE73
WE95 - WFF100 - WFF135 - WFF150 - WFF165



PRIMUS 8053107

Motors

3340031 MOTOR AHV

2-42-P-09 380 HZ / 250V
max room temperature 60°C
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7




PRIMUS 102035

3340026

MOTOR AND MOTOR CONTROL BOARD SET

mod. AHV 2-42-P-09 - 0-380
380 HZ / 250V
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC17 - WAC8



PRIMUS 509820

3340122 MOTOR JQA48T17D11001AP 1/4HP 60Hz

TS.80.S4.4000 - 0256014
for Dryer (PRIMUS) DA13 - D11
for Dryer (WHIRLPOOL) SWE111 - SWE131



PRIMUS RSP70062802

3340067

MOTOR LM5

for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WES5GP - WES5GV - WES5IP
WES5IV




PRIMUS 8063734

3340117 MOTOR WEG AL80-04 THREE-PHASE
 0.75Kw 230/400V 50Hz 2.97/1.71A
 1400 motor revolutions
 for Washing machine (PRIMUS) FS6 - FS7
 for Washing machine (WHIRLPOOL) WACS8



PRIMUS PRI320000012

7104470 MOTOR 220/230V-380/415V
 power 0.65/0.55kW
 rpm 720/430
 axle ø 24x60 mm
 for Washing machine (PRIMUS) F22 - F33



PRIMUS PRI325001037

7104473 MOTOR 220/230V-380/415V 3000W
 WEG type 100L-04
 motor revolutions 1410
 for Washing machine (PRIMUS) F22



PRIMUS 338400100032

7104472 MOTOR 220/380V 1500W
 shaft ø 24x54 mm
 for Washing machine (PRIMUS) FS10 - WACS11



PRIMUS PRI320000013

7104471 MOTOR 220/380V 2200W
 WEG type AL100L-04
 motor revolutions 1410
 for Washing machine (PRIMUS) FS16




PRIMUS PRI320000009

3340032 SINGLE-PHASE CONVEYOR MOTOR SC5
 220 / 240 V - 50 Hz - 1425 rev./min
 for Dryer (GIRBAU) SE112
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA17
 DA25
 for Dryer (WHIRLPOOL) SACG11 - SACG13 - SACG15
 SACG17 - SWG111 - SWG131 - SWG151



PRIMUS RSP70171601

3340033 SINGLE-PHASE MOTOR
 220 V - 50 Hz - 1425 rev./min
 for Dryer (FAGOR) SE-7
 for Dryer (GIRBAU) SE7
 for Dryer (PRIMUS) DA9 - D9
 for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
 SWE390 - SWE391 - SWE90 - SWE91



PRIMUS RSP501212

PRIMUS RSP505843P




Suitable for:

PRIMUS



3340029 SINGLE-PHASE MOTOR VENTILATOR
220/240 V - 8 μ F - 50 Hz
2850 RPM - 1.1 A - 270 W
for Dryer (IMESA) ES5EGC - ES5EIC
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205/WP
AGB207/WP - SE5GC - SE5IC



PRIMUS 8061824

3340037 MOTOR VENTILATOR IMPELLER
 $\varnothing$ 115 mm - thickness 43 mm



PRIMUS 8055200

PRIMUS 8065305

Suitable for:

3340038 FRONT FAN FOR MOTOR VENTILATOR
 $\varnothing$ 115 mm / thickness 53 mm




PRIMUS 8061960

3340036 MOTOR VENTILATOR REAR CASE



PRIMUS 8052636

3340028 THREE-PHASE MOTOR HANNING
230/400 V - 50 Hz
for Washing machine (PRIMUS) F10 - RS10
for Washing machine (WHIRLPOOL) LW100 - WAC11



PRIMUS PRI320000063

Outlet solenoid valves and accessories

3120299 DRAIN SOLENOID VALVE MDB-0-2
normally OPEN - 220/240V 50/60Hz 24AMP
inlet $\varnothing$ 50 mm - outlet $\varnothing$ 50 mm
for Washing machine (FAGOR) LC/AC-7 - LC/E-10
LC/E-14 - LC/E-7



PRIMUS ASK8008365

3120146 DRAIN SOLENOID VALVE MDB-0-3RA
normally OPEN - 230V 50/60Hz 18AMP
inlet $\varnothing$ 76 mm - outlet $\varnothing$ 78 mm
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM22 - WFM33 - WFM40 - WFM55 - WFM8 - WF11
WF18 - WF8
for Washing machine (POLIMATIC) FS10 - FS23
FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7
RS10 - RS13 - RS18 - RS22 - RS27 - RS35 - RS6
RS7 - XS22
for Washing machine (PRIMUS) FS10 - FS23 - FS23PRO
FS33 - FS40 - FS55 - FS6 - FS7 - RS10 - RS13
RS18 - RS22 - RS27 - RS35 - RS6 - RS7 - XS22
for Washing machine (WHIRLPOOL) 016002-WACS11
016004-WACS17



PRIMUS PRI340055051

PRIMUS 101014



Suitable for:

3120295 DRAIN SOLENOID VALVE MDP-0-2RA

normally OPEN - 220/240V 50/60Hz 24AMP
inlet ø 50 mm - outlet ø 50 mm
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7



PRIMUS 101783

PRIMUS



Suitable for:

3248144 DRAIN VALVE COUPLING

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) C6 - C8 - P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS 101750

Pins

3324033 PIN

ø 380 mm



PRIMUS RSP70017701

Portholes

5027105 COMPLETE WASHING MACHINE DOOR

external ø 350 mm
for Washing machine (IMESA) LM5




PRIMUS 8061650-42

PRIMUS 8064906-85

5041476 DOOR LOCK STRIKE


for WASHING MACHINE ASKO WMC55
for WASHING MACHINE IMESA LM5P
for WASHING MACHINE PRIMUS PW5
for WASHING MACHINE WHIRLPOOL AGB200-201-202-203



PRIMUS ASK8061798

3386037 FRONT DOOR

for Washing machine (PRIMUS) P6 - P7



PRIMUS 500087



Suitable for:

PRIMUS

Suitable for:



Pressure switches

3320218 PRESSOSTAT 230V 16(4)A
3 levels: 70/25 - 100/50 - 140/90



PRIMUS BLO001757300

3320220 PRESSOSTAT 230V 16A
3 levels: 150/70 - 185/80 - 200/90



PRIMUS PRI340000076

PRIMUS PRI340000076


3320219 PRESSOSTAT 250V 16A
3 levels: 150/80 - 240/100 - 285/160



PRIMUS PRI340000075


PRIMUS PRI340001075

3320162 PRESSURE SWITCH 520/370-445/350-210/160
16A 250V
for Washing machine (GRANDIMPIANTI) WM22000
for Washing machine (POLIMATIC) FS33 - FS40 - FS55 XS22
for Washing machine (PRIMUS) FS33 - FS40 - FS55 XS22



PRIMUS PRI340000074


3320158 PRESSURE SWITCH 87/35-310/265
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (GRANDIMPIANTI) WFEC5
for Washing machine (IMESA) LM5EGDP - LM5EGDV LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8064275

PRIMUS 8064348

3320209 SAFETY PRESSURE SWITCH
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (GRANDIMPIANTI) WFEC5
for Washing machine (IMESA) LM5EGDP - LM5EGDV LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8061664

Probes

3397135 HUMIDITY PROBE
cable length 4400 mm - probe $\varnothing$ 27 mm
for Dryer (POLIMATIC) T11 - T13 - T16 - T24 - T35 T9
for Dryer (PRIMUS) T11 - T13 - T16 - T24 - T35 T9



PRIMUS 102456

3397169 HUMIDITY PROBE
cable length 1250 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE SE5IC - SE5IE



PRIMUS 8061855



Suitable for:

PRIMUS Зин Общепит



3397170 PROBE

cable length 1340 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



PRIMUS 8061900

3445255 TANK TEMPERATURE PROBE

cable length 2000 mm - bulb $\varnothing$ 6x60 mm
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) FS10 - FS16 - FS7
MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS10
RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS28AE - WACS28AV - WACS35AE - WACS35AV
WACS46AE - WACS46AV - WACS6 - WACS7 - WACS70AE
WACS70AV - WACS8 - WAC11 - WAC17 - WAC23
WAC8



PRIMUS PRI340015019

3744039 STUFFING GLAND $\varnothing$ 6 mm


for probe
for Washing machine (PRIMUS) FS10 - FS16 - FS7
MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS10
RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS28AE - WACS28AV - WACS35AE - WACS35AV
WACS46AE - WACS46AV - WACS6 - WACS7 - WACS70AE
WACS70AV - WACS8 - WAC11 - WAC17 - WAC23
WAC8



PRIMUS PRI614000047

3744040 NUT M14

for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16
FS6 - FS7 - MB16 - MB22 - MB33 - MB44 - MB66
P6 - P7 - RS16 - RS22 - RS6 - RS7
for Washing machine (WHIRLPOOL) LW100 - LW70
WACS11 - WACS16E - WACS17 - WACS28A - WACS35A
WACS46A - WACS6 - WACS7 - WACS70A - WACS8
WAC11 - WAC17 - WAC23 - WAC8



PRIMUS PRI614000048



Suitable for:

5045222 TEMPERATURE PROBE PT1000

cable length 3 m
for Dryer (PRIMUS) T24 - T9



PRIMUS 516092


PRIMUS



Suitable for:

3307171 THERMISTOR FOR TEMPERATURE PROBE

for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA9
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE8 - SWE111 - SWE131 - SWE151



PRIMUS RSPM411758

PRIMUS RSPM414704

Pulleys

3318010 BELT PULLEY

for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8C - SACE8T



PRIMUS RSP500269

PRIMUS RSP510158

3062084 CLAMP



PRIMUS RSP23748

3062075

AXIS

for pulley



PRIMUS RSP56461

PRIMUS RSP56461P

3062082

WASHER

for Dryer (DANUBE) DD8
for Dryer (FAGOR) SE/7
for Dryer (GIRBAU) SDE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8T - SACE86
SWE290 - SWE390 - SWE90 - SW291 - SW391 - SW91



PRIMUS RSP52549

3318025 DOUBLE PULLEY ø 380 mm

for Washing machine (PRIMUS) F10 - F6 - F7
for Washing machine (WHIRLPOOL) LWS100 - LWS70



PRIMUS PRI606000001

3318012

PULLEY ø 297 mm

for washing machine drum
for Washing machine (GRANDIMPIANTI) WFM6
for Washing machine (PRIMUS) C6 - C8 - P6 - P7
RS10 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC11 - WAC8



PRIMUS PRI606000012



Suitable for:

PRIMUS Зип Общепит



Suitable for:

3318011 PULLEY ø 380 mm

for washing machine drum
for Washing machine (GRANDIMPIANTI) WFM6
for Washing machine (PRIMUS) C6 - C8 - P6 - P7
RS10 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC11 - WAC8



PRIMUS 509819

vsezip.ru

+7(812)987-08-81

Pumps

3122471 DRAIN PUMP FE30B4

230V 50Hz 90W
for Washing machine (GIRBAU) HS6008
for Washing machine (GRANDIMPIANTI) WACS6 - WACS7
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS PRI333000017

3353003

SLEEVE

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (PRIMUS) C6 - C8 - P6 - P7
for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



PRIMUS PRI503000045

3122704 DRAIN PUMP HANNING DPS25-047

30 W - 220 V - 50 Hz
for Washing machine (IMESA) LM5EGDP - LM5EIDP
PLM6
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB202/WP - WACS5 - WACS5M - WES5GP - WES5IP



PRIMUS 8801166

PRIMUS 8801263



Suitable for:

PRIMUS

Зин Общепит



Suitable for:

Rating plates

726zip.ru

+7(812)984-08-81

3786411 BLACK PVC PANEL

for Dryer (ASKO) TDC44 - TD33
for Dryer (IMESA) ES5
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206
AGB207 - SACE5
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (IMESA) LM5
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB201
AGB202 - AGB203



PRIMUS 806547869

7104437 CONTROL PANEL MEC5EC GREY

for Washing machine (PRIMUS) FS10 - FS6 - FS7
WACS8



PRIMUS 527273

3319643 UNIT DISPLAY KEYBOARD

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP



PRIMUS 8063991-33

3322329 UNIT DISPLAY KEYBOARD

for Dryer (ASKO) - Series ES5 - TDC44
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP
WES5GV - WES5IP - WES5IV



PRIMUS 8063990-33

Relays

3351055 RELAY LY2F

for Dryer (PRIMUS) DA11 - DA13 - DA17
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17



PRIMUS RSPM412534

PRIMUS RSP412534



Suitable for:

PRIMUS Зин Общепит


Suitable for:



Reversing switches

3210023 REVERSING SWITCH PR1840

for Washing machine (PRIMUS) F10 - F6 - F7 - RS10
RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WAC11 - WAC17
WAC23 - WAC8




PRIMUS PRI343000057

Rinse aid containers and accessories

3066035 DETERGENT TANK

for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP
WES5GV - WES5IP - WES5IV



PRIMUS 8061661

3449274 SLEEVE

for detergent dispenser
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP
WES5GV - WES5IP - WES5IV



PRIMUS 8061628

3066044 DETERGENT TANK




PRIMUS 8061630

3066046 EXTERNAL TANK



PRIMUS PRI505040027

3066043 INTERNAL DETERGENT TANK



PRIMUS 505041027



Suitable for:

3066037

LID FOR PRODUCT DISPENSER

for Washing machine (PRIMUS) FS10 - FS16 - FS7
RS10 - RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) 016002-WACS8
016003-WACS11 - 016004-WACS17 - 016013-WAC8
016014-WAC11 - 016015-WAC17 - 016016-WAC23




PRIMUS PRI505038027

3066032

PRODUCT TANK

for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7




PRIMUS BLO003999400

3066038

CONTAINER PLATE

for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



PRIMUS 500099

3528065

SCREW M4x12 FOR HANDLE



PRIMUS 309933240412

PRIMUS

Suitable for:

3066034

WASHING TANK

for Washing machine (PRIMUS) FS22 - FS33 - FS40
FS55
for Washing machine (WHIRLPOOL) 016005-WACS23
016006-WACS23V - 016007-WACS35
016008-WACS35V - 016009-WACS42
016010-WACS42V - 016011-WACS55
016012-WACS55V



PRIMUS 321848223000

3242623

CONTAINER HANDLE

for Washing machine (GRANDIMPIANTI) WFM11 - WFM6
WFM8
for Washing machine (PRIMUS) F5 - P5 - P6 - P7
for Washing machine (WHIRLPOOL) LWS50 - LWS51M
WACS6 - WACS7



PRIMUS 101161

3066039

CONTAINER SUPPORT PLATE

for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



PRIMUS 500100

3353002

SLEEVE

for product dispenser
for Washing machine (GRANDIMPIANTI) WFM6
for Washing machine (PRIMUS) F5 - P5 - P6 - P7
for Washing machine (WHIRLPOOL) LWS50 - LWS51M
016001-WACS6 - 016071-WACS7



PRIMUS BLO002319100



Suitable for:

PRIMUS Зин-Общепит



Suitable for:


Rotary switches

3057310 POTENTIOMETER 120/240V
50/60 Hz - 2.5W



PRIMUS RSP431353

3057309 TEMPERATURE SELECTOR SWITCH
25A 240V



PRIMUS RSP61512

3057287 VIBRATION SELECTOR SWITCH MOD. 63.731

5A-250V

for Washing machine (GIRBAU) AS26 - AS33 - AS44

AS66 - WFM33 - WFM40 - WFM55

for Washing machine (PRIMUS) MB16 - MB26 - MB33

MB44 - MB66

for Washing machine (WHIRLPOOL) WACS16AE - WACS28

WACS28AE - WACS28AV - WACS35 - WACS35AE

WACS35AV - WACS46 - WACS46AE - WACS46AV

WACS70 - WACS70AE - WACS70AV



PRIMUS PRI345000068

Sensors

7104462 INFRARED CELL
for Dryer (PRIMUS) SWE140



PRIMUS RSP56231

Shock absorbers

3007023 COMPLETE SHOCK ABSORBER TYPE 006
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
for Washing machine (PRIMUS) FS10 - FS16 - FS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8



PRIMUS 510899

3007026 RING FOR SHOCK ABSORBER
for shock absorber



PRIMUS PRI611007025

PRIMUS 611007025



Suitable for:

3007025 RUBBER RING FOR SHOCK ABSORBER
for shock absorber



PRIMUS PRI611008025

PRIMUS 611008025

3007038 SPRING FOR SHOCK ABSORBER
for 6-7 Kg yellow
ø external 38-49 mm - ø internal 28-38 mm
length 138 mm - ø thread 5 mm



PRIMUS PRI611029025

3002003 ELASTIC RING FOR SHOCK ABSORBER ø 55 mm
ø 55 mm - height 30 mm
for Dryer (GRANDIMPIANTI) CE10 - CE15



PRIMUS NYB489624541

3007037 SHOCK ABSORBER COMPLETE TYPE 006 51/09
total length 360 mm



PRIMUS 517895

3007025 RUBBER RING FOR SHOCK ABSORBER
for shock absorber



PRIMUS PRI611008025

PRIMUS 611008025

PRIMUS 311008025

Suitable for:

3007027 SHOCK ABSORBER SPRING
length 135 mm - ø 38-27 mm



PRIMUS PRI611028025

3007030 WASHER ø 35 mm



PRIMUS PRI611009025

3007026 RING FOR SHOCK ABSORBER
for shock absorber



PRIMUS PRI611007025

PRIMUS 611007025

3007027 SHOCK ABSORBER SPRING
length 135 mm - ø 38-27 mm



PRIMUS PRI611028025





Suitable for:

3007038 SPRING FOR SHOCK ABSORBER
for 6-7 Kg yellow
ø external 38-49 mm - ø internal 28-38 mm
length 138 mm - ø thread 5 mm



PRIMUS PRI611029025

3007035 SHOCK ABSORBER R1064 B10C08
overall length 395 mm



PRIMUS 326270001064

3007010 SHOCK ABSORBER TYP 012 140N
for Washing machine (DANUBE) GF10 - GF15 - GF18
GF8
for Washing machine (GRANDIMPIANTI) WFEC11
WFEC18 - WFEC8 - WFM11 - WFM18 - WFM6 - WFM6S
for Washing machine (IPSO) HF150 - HF185 - HW131
HW164 - HW64 - HW72 - HW75 - HW94
for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7
for Washing machine (WHIRLPOOL) WACS11 - WACS6
WACS7 - WACS8



PRIMUS PRI611000025

PRIMUS 611000025


PRIMUS

Suitable for:

3007030 WASHER ø 35 mm

vsezip.ru

+7(812)987-08-81



PRIMUS PRI611009025

3007013 SHOCK ABSORBER SPRING TYP006
overall length 355 mm
for Washing machine (DANUBE) GF10 - GF15 - GF6
GF8 - HF65 - HF76 - HF95
for Washing machine (GRANDIMPIANTI) WFEC11
WFEC18 - WFEC8 - WFM11 - WFM18
for Washing machine (IPSO) HC100 - HC135 - HC165
HC60 - HC65 - HC75 - HF110 - HF132 - HF165
HM165 - HW131 - HW164 - HW55 - HW64 - HW72
HW75 - HW94
for Washing machine (PRIMUS) FS10 - FS16 - FS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8



PRIMUS PRI611001025

5043707 BUSHING FOR SHOCK ABSORBERS
for WASHING MACHINE WHIRLPOOL LWS220



PRIMUS 223102100515





Suitable for:

3242506 PIN BUSHING FOR DOOR HANDLE

ø external 20 mm - ø internal 14 - height 20 mm
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS 323622641243

5043706 SPRING HOLDER HOSE

for Washing machine (PRIMUS) F22
for Washing machine (WHIRLPOOL) LWS220



PRIMUS 223102100714

5050500 SHOCK ABSORBER TYPE 012 250N

distance between holes 183 mm closed
for Washing machine (FAGOR) LA-25M



PRIMUS 326269185250

PRIMUS

Suitable for:

7102075 PLIERS 155x36 mm

for Washing machine (PRIMUS) F22 - F23
for Washing machine (WHIRLPOOL) WACS23



PRIMUS 223102100314

Sleeves

3248145 DRAIN ELECTROPUMP COUPLING

for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7



PRIMUS 521550

3248147 DRAIN VALVE COUPLING

ø external 83 mm
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
for Washing machine (PRIMUS) FS33 - FS40 - FS55



PRIMUS 273238425503



Suitable for:

PRIMUS

Зипи Общепит



3248146 SIPHON FOR SETERGENT TANK

for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7

vsezip.ru

+7(812)987-08-81



PRIMUS 102341

3353004 SLEEVE

for product dispenser
for Washing machine (GRANDIMPIANTI) WR11 - WR18
WR24 - WR37 - WR8
for Washing machine (PRIMUS) RS10 - RS16 - RS22
RS7
for Washing machine (WHIRLPOOL) 016013-WAC8
016014-WAC11 - 016015-WAC17 - 016016-WAC23



PRIMUS PRI540000031

3394333 HOSE CLAMP ø 90-110 mm

for Washing machine (GRANDIMPIANTI) WR11 - WR18
WR24 - WR37 - WR8
for Washing machine (PRIMUS) RS10 - RS16 - RS22
RS7
for Washing machine (WHIRLPOOL) WAC11 - WAC17
WAC23 - WAC8



PRIMUS PRI240000005

Solenoid valves

3120297 SOLENOID VALVE 230V ø 10 mm

solenoid valve 90° - 230V 50Hz - max 90°C
inlet 3/4" -dual outlet ø 10 mm
with inlet flowrate reducer
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7



PRIMUS 101834

3120298 SOLENOID VALVE 230V ø 10 mm

solenoid valve 90° - 230V 50Hz - max 90°C
inlet 3/4" - triple outlet ø 10 mm
with brown inlet flowrate reducer
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) P6 - P7



PRIMUS 101832



Suitable for:

PRIMUS Общепит



Suitable for:

3120166 SOLENOID VALVE 263A 220/240V ø 14 mm

solenoid valve 90° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - triple outlet ø 14 mm
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55 - WR11 - WR18 - WR24 - WR26 - WR37 - WR48
for Washing machine (IMESA) RS10 - RS16 - RS22
RS7
for Washing machine (POLIMATIC) RS10 - RS35 - RS6
RS7
for Washing machine (PRIMUS) FS10 - FS6 - FS7
PS7 - RS10 - RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS23 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17
WAC23 - WAC8



PRIMUS PRI340030038


PRIMUS 101832

vsezip.ru

+7(812)987-08-81

Sparking plugs

3806012 IGNITION WITH BRACKET



PRIMUS 510184

3806011 SPARKING PLUG

ø 9 x length 65 mm - bracket 50x22 mm



PRIMUS RSP70032801

3806014 SPARKING PLUG

ø 9x99 mm - flange 48x22 mm
for Dryer (PRIMUS) T11 - T13 - T16



PRIMUS 357375100500

7104440 SPARKING PLUG


for DRIER PRIMUS SWE140 - D14



PRIMUS RSP55438

7104454 SPARKING PLUG SUPPORT

for DRIER SWE140/D14



PRIMUS RSPM402745



Suitable for:

PRIMUS

Suitable for:



Spring

3250228 SUSPENSION SPRING
overall length 150 mm - $\varnothing$ 30 mm



PRIMUS PRI61000056

3250229 SUSPENSION SPRING
overall length 155 mm - $\varnothing$ 30 mm



PRIMUS PRI611000056

Supports

3391061 SPACER



PRIMUS 509922

Switches

7104459 BIPOLAR REVERSING SWITCH
for DRIER PRIMUS T24




PRIMUS 100388

5054351 BIPOLAR SWITCH
mounting hole 14x28 mm
for DRIER PRIMUS T9-11-13




PRIMUS 506045

3319640 DOOR OPENING SWITCH
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0001726500

3319641 SWITCH KNOB
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0003851200

PRIMUS BLO0003851203

5048146 FULL CONTROL KEYBOARD GRAPHITRONIC
for Washing machine (PRIMUS) FS16 - FS23 - FS33
FS40 - FS55




PRIMUS 520681



Suitable for:

3319590 PUSH-BUTTON PANEL 6 BUTTONS
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0001725800

5009287 PUSH-BUTTON PANEL 6 BUTTONS
for WASHING MACHINE PRIMUS WACS8-FS6-FS7-FS10-W10



PRIMUS PRI348011091

3319596 START/STOP SWITCH - 4 FASTON
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS 100195

5041498 STOP BUTTON
for WASHING MACHINE GRANDIMPIANTI WFP120-AS26-AS33-AS44-AS66
for WASHING MACHINE PRIMUS MB26-MB33-MB44-MB66-FS16
for WHIRLPOOL WASHING MACHINE WACS28AE-WACS28AV-WACS35AE-WACS35AV-WACS46AE-WACS46AV-WACS70AE-WACS70AV
for DRIER PRIMUS T24



PRIMUS 102259

PRIMUS


Suitable for:

3319591 PUSH-BUTTON KNOB
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



PRIMUS BLO0003852203

3319598 START POWER SWITCH
for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8
for Washing machine (PRIMUS) P5




PRIMUS RSP55882

3319597 SEALING CAP
for switch
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7



PRIMUS PRI543000003

3319642 SWITCH CASE
for Dryer (PRIMUS) T24
for Washing machine (GRANDIMPIANTI) AS26 - AS33-AS44 - AS66 - WFP120
for Washing machine (PRIMUS) FS16 - MB26 - MB33-MB44 - MB66
for Washing machine (WHIRLPOOL) WACS28AE-WACS28AV - WACS35AE - WACS35AV - WACS46AE-WACS46AV - WACS70AE - WACS70AV



PRIMUS 102260




+7(812)987-08-81



Suitable for:

3319593 SWITCH 4591 W2 - START/STOP - 6 FASTONS


for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - WACS5 - WACS5M
WES5GP - WES5GV - WES5IP



PRIMUS 8061875

3319600 PUSH-BUTTON SPRING

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IE
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WACS5
WACS5M - WES5GP - WES5GV - WES5IP - WES5IV



PRIMUS 8061857

5041503 WHITE BUTTON SWITCH 40x14 mm

snap-in
16A 3/4HP 125/250VAC
for DRIER PRIMUS SWE140-D14



PRIMUS RSPM406103

PRIMUS

Suitable for:

3319599 PUSH-BUTTON LAMP

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SECE5 - SE5GC - SE5GE - SE5IC
SE5IE
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WACS5 - WACS5M - WES5GP



PRIMUS 8064069





Suitable for:

PRIMUS

Suitable for:




Thermostats

7104441 RANCO ADJUSTABLE THERMOSTAT 88°C÷135°C
bulb ø 8x195 mm - capillary length 295 mm
for Dryer (PRIMUS) D14 - SWE140



PRIMUS RSPM400780

7104463 THERMOSTAT PUSH-BUTTON
for Dryer (PRIMUS) D14 - SWE140



PRIMUS RSPM400777

3444825 THERMOSTAT PSP01 230V 50Hz
frame dimensions 95x95 mm
for Washing machine (POLIMATIC) FS33 - FS40 - FS55
XS22
for Washing machine (PRIMUS) FS33 - FS40 - FS55
XS22



PRIMUS 506500

3444006 THERMOSTAT TR2 0-210°C
D-shaped pin ø 6x4.6 mm
capillary length 1000 mm - 15A 250V
bulb ø 5x140 mm



PRIMUS GMP100021

3444328 THERMOSTAT 30-40-60-90°C
4 set temperatures 30°-40°-60°-90°C
capillary 1050 mm
bulb ø 6x125 mm
16A 250V
for Washing machine (PRIMUS) RS10 - RS16 - RS22
RS7
for Washing machine (WHIRLPOOL) WAC11 - WAC17
WAC23 - WAC8



PRIMUS PRI340001012

Timers

3446210 TIMER M460-G
1/3HP 240V 50Hz 25A



PRIMUS RSP500400

PRIMUS RSP510525

3446211 TIMER M481
3/4HP 20/10A 125/250V 50Hz



PRIMUS RSPC70131801

PRIMUS RSPM412079

3446196 TIMER 60 MINUTES - 24V

for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25 - D35
D55 - D77
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SACE35 - SACE55 - SWE111 - SWE131
SWE151 - SWE251 - SWE351 - SWE551



PRIMUS RSPM412080

PRIMUS RSPM412080P

3446194 60 MINUTE TIMER

3/4 HP - 20/10 A - 125/250 V - 50 Hz
25 A - 250 V - 50Hz
for Dryer (PRIMUS) D25
for Dryer (WHIRLPOOL) SACE25



PRIMUS RSPM410903P

Water tight seals

3453014 COUNTER-SEAL RING ø 75x58x7 mm

for GRANDIMPIANTI WASHING MACHINE
WFEC18-WR18-WR26
for IPSO WASHING MACHINE HF145-HF176-HF205-HF150
HF185-HW131-HW164-WE110-WE132-WE165-WE176-WE234
WE181-WF135-WF165-WF150-WF185-WF235-WFF135-WFF165
WFF150-WFF185-WFF235



PRIMUS PRI530030013

3453013 RETAINER RING ø 58x88x18 mm

sealing ring:

internal ø 58 mm
external ø 88 mm
thickness 18 mm

for GRANDIMPIANTI WASHING MACHINE WFM18
for IPSO WASHING MACHINE HF110-HF132-HF165-HF145
HF176-HF205-HF234-HW131-HW164-WE110-WE132-WE165
WE176-WE234-WE181-WF135-WF165-WF150-WF185-WF235
WFF135-WFF165-WFF150-WFF185-WFF235



PRIMUS PRI530030012

3453037 SEALING RING


PRIMUS 8801211

3453030 SEALING RING ø 40x68x12 mm

sealing ring:

internal ø 40 mm
external ø 68 mm
thickness 12 mm

for GRANDIMPIANTI WASHING MACHINE
WFEC8-WFEC11-WR8
WR11-WFM6-WFM6S
for PRIMUS WASHING MACH. P6-P7-RS6-RS7-RS10-F6-C6
for POLIMATIC WASHING MACHINE P65-P75-RS6-RS7-RS10
for IPSO WASHING MACHINE HC60-HC65-HC75-HC100-HF55
HF65-HF75-HF95-HW64-HW72-HW94-WE55-WE73-WE95-WF65
WF75-WF100-WFF65-WFF75-WFF100
for IMESA WASHING MACHINE LK8



PRIMUS PRI530000012



Suitable for:

PRIMUS

Зини общепит



Suitable for:

3453005 SEALING RING $\varnothing$ 50x80x13 mm

sealing ring:
internal $\varnothing$ 50 mm
external $\varnothing$ 80 mm
thickness 13 mm
for GRANDIMPIANTI WASHING MACHINE
WFM8-WFM11-WR11
WR18
for PRIMUS WASHING MACHINE FS6-FS7-FS10-RS13
for POLIMATIC WASHING MACHINE FS6-FS7-FS10-RS13



PRIMUS PRI530020012

3453039 COUNTER-SEAL RING $\varnothing$ 50x70x5 mm

for PRIMUS F7-F10-RS10-RS16
for WHIRLPOOL LW100-LWS100-WAC11-WAC17



PRIMUS PRI530020013

3453006 SEALING RING $\varnothing$ 60x88x18 mm


sealing ring:
internal $\varnothing$ 58 mm
external $\varnothing$ 88 mm
thickness 18 mm
f/ GRANDIMPIANTI WASHING MACHINE
WFM18-WFEC18-WR18
WR26
for PRIMUS WASHING MACHINE FS16-RS18-RS22
for POLIMATIC WASHING MACHINE FS16-RS18-RS22
for IPSO WASHING MACHINE HC135-HC165-HF234-WE181
WE234



PRIMUS PRI530030012

3063097 SEALING RING WITH GASKET

dimensions 40x58x5 mm



PRIMUS PRI530001013

3786438 TANK SEALING GASKET



PRIMUS BLO0008203000

+7(812)987-08-81

Зип Общепит

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.

+7(812)987-08-81



LF SpA

via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com

FRANCE



EPGC Sas

13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH

Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro

Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.

Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tlf. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.

A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk

RUSSIA



000 LF

ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru

CHINA



LF China

Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com