

Зип Общепит
vsezip.ru
+7(812)987-08-81



ART1L

Edition 20020119-

vsezip.ru

This exploded view diagram illustrates the assembly of the Zipporah ZP-1000 refrigerator. The main components shown include the top panel (6), the main body (4), the door (5), and the internal shelving system (98). The diagram is annotated with numerous numbered callouts (1-110) corresponding to specific parts and fasteners. Key assembly areas are highlighted with callouts such as 18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0, -1, -2, -3, -4, -5, -6, -7, -8, -9, -10, -11, -12, -13, -14, -15, -16, -17, -18, -19, -20, -21, -22, -23, -24, -25, -26, -27, -28, -29, -30, -31, -32, -33, -34, -35, -36, -37, -38, -39, -40, -41, -42, -43, -44, -45, -46, -47, -48, -49, -50, -51, -52, -53, -54, -55, -56, -57, -58, -59, -60, -61, -62, -63, -64, -65, -66, -67, -68, -69, -70, -71, -72, -73, -74, -75, -76, -77, -78, -79, -80, -81, -82, -83, -84, -85, -86, -87, -88, -89, -90, -91, -92, -93, -94, -95, -96, -97, -98, -99, -100, -101, -102, -103, -104, -105, -106, -107, -108, -109, -110. The diagram also includes a small inset showing the internal wiring and components of the door (3) and a detailed view of the door handle assembly (101, 102, 103, 104, 105, 106, 107, 108, 109, 110).

Pos	Code	Description	Info
002	3178300	PLUG	15/12/1997-
003	35P6010	PANEL BOARD	21/12/2001-
004	30D5690	FRAME	15/12/1997-
005	30F0860	DOOR	26/10/2001-
006	6006830	TOP ASS. Y	15/12/1997-
007	30T2680	BOTTOM BRACKET	15/12/1997-
008	30T2690	BRACKET	15/12/1997-
009	30W4140	TRAY ASS.Y	19/01/2002-
010	32V5160	CONDENSER	21/12/2001-
011	36G9570	PIN	16/03/2001-
012	32A2200	POWER SUPPLY CABLE	15/12/1997-
017	32M1550	FAN	15/12/1997-
018	32M6870	FAN MOTOR	07/12/2001-
019	32M6610	FAN	21/12/2001-
022	32X0140	GROMMET Ø13,5-Ø25	21/12/2001-
030	32V0330	RELAY	15/12/1997-
031	32Z9710	CONDENSER	15/12/1997-
032	32Z9580	CONDENSER	15/12/1997-
037	33A0330	FILTER	15/12/1997-
038	33A1200	AUXIL.VALVE	15/12/1997-
043	34D5920	COMPRESSOR	15/12/1997-
044	34D3260	CONDEN.+BAFFLE	15/12/1997-
045	34D5220	EVAPORATOR	15/12/1997-
046	34E0430	MOTOR UNIT	19/01/2002-
049	36C4020	LH RACK	15/11/1999-
051	3AA4400	EVAP. GUARD	31/05/2001-
054	35C5940	"OMEGA" BRACKET	15/12/1997-
056	35C7560	"S"FRAME	15/12/1997-
061	35X3860	DRAIN PIPE	07/05/1999-
063	36C2390	TRIM FRAME	15/12/1997-
064	36C2401	TRIM FRAME	15/12/1997-
065	36C4770	FOOT	19/01/2002-
066	36E1440	PROTECT GR	05/07/1999-
070	36D9490	TOP BRACKET	15/12/1997-
075	36E0410	BUSHING	15/12/1997-
077	36G6520	HINGE	15/12/1997-
078	36G8140	PIN	15/12/1997-
079	36G9560	HANDLE	16/03/2001-
081	36Z0300	COND. TRAY	15/12/1997-
084	37Q3810	GASKET	15/12/1997-
085	3AA4750	CONTROL BOARD	21/12/2001-
086	30G3710	PLUG	15/12/1997-
087	6013320	DOOR ASS.Y	26/10/2001-
088	32Q4380	CABLE ASS.Y	15/12/1997-
090	36Z0490	ENGINE CUTO	05/02/1999-
091	32D0750	TERMINAL BOARD	21/12/2001-
093	32D0220	CABLE CLAMP Ø 16	05/02/1999-
094	32D0680	CABLE CLAMP	05/02/1999-
096	35Y1220	PLATE	07/01/1999-
097	32V0370	ENGINE CUTO	15/12/1997-
098	36C4010	RH RACK	15/11/1999-

Pos	Code	Description	Info
099	33Q4390	COUPLING TUBES	12/11/1999-
100	35Y2550	PLATE	15/06/2001-
101	32V3720	RELAY	21/12/2001-
102	32V0150	TEMP. PROBE	21/12/2001-
103	32V6470	ELECTRONIC CARD	21/12/2001-
104	36E0340	SPACER	21/12/2001-
105	37N3860	SILK-SCREE.PANEL	21/12/2001-