


Зип-Общепит

vsezip.ru


+7(812)987-08-81



[illegible]

Зип Общепит

+7(812)987-08-81



TAV.3 (DGT)

Зип Общепит

vsezip.ru

25192225 - D45

00014985

00014920 D

+7(812)987-08-81

00014336

28100011

03100003

00014984

25192030

005900021 - D45

25190104 - D45

25190103

2519010

06140047

06150012

*20161501 50Hz

20161004

*20160062 50Hz
20160068 60Hz

27100002

05110001

00003750

00014081

25130100

29120007

22100002

25130037 25A*
25130038 32A
00006220 40A

00014932

00013733

25190105

25192040

00014328


00014933

TAV.3 (ELT.BT-BA)

Зип Общепит

vsezip.ru

+7(812)987-08-81



*20160062 50Hz
20160068 60Hz

20161004

*20161501 50Hz

06150012

06140047

24100102

00014081

29120007

25192050

22100002

24100100

*25130037 25A
25130038 32A

00014932

00014328

25192010

00014118

25192400


ТАВ.4 (DGT)

Зип Общепит


vsezip.ru

+7(812)987-08-81

00003270 (kW5,2 230V)



00203091 (kW2 230V)*
00003278 (kW1,3 115V)




00013411

05100007

00013411

12356005

20160016(230V 50 Hz)




00013411

05100007

23120021

07130002



00011059

00011058

00003750

00010514


00220413

00003750

20155117



05100007



00003325 (kW5,2@230V)*
00003327 (kW6,1@230V)^Δ
00003334 (kW8,3@230V)
00002441 (kW5,7@115V)
00002461 (kW5,7@254V)

00010500


00010502


00010504
00010514
00220413

00003430

22100002

00003








Зип Общепит

vsezip.ru

+7(812)987-08-81




ТАВ.7
Зип Ощепит


vsezip.ru

87(812)987-08-8


00007020




00206721




00006920




00007120




00206751



FAA031



FAA007



FAA001

