



+7(812)987-08-81



Model	All								
Table	SPMULTI		Page	2		Exploded view structure			
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes
0001	0D5131							SHAFT; W/COTTER PIN	
0002	0HD008							KEY; 5 PCS	
0003	000000								See S2
0004	0D3578							O-RING 47X3 (SET X5)	
0005	0KI998			S	A			RING; 28X40X7MM; FOR TRS; 5 PCS	
0006	0KI590			S				BALL BEARING; 6303 2RS1	
0007	0D5107							PIVOT; TRX	
0008	0D5916				D			SPACER; 18X23X23 TRX	
0009	0D3567				D			BRASS EARTH TERMINAL (SET X5)	
0010	0D0520							PIN; 10 PCS	
0010	0D0610							K35 SCREW TC 4X8	
0011	0KJ007			S	A			BALL BEARING; 6203 2 RS	
0012	0D1669			S	A			BELT	
0012	0D2600				A			POLY V BELT 660 J6	
0013	0D5132				D			SCREW; M5*12 IX; 10 PCS	
0014	000000								See S4
0015	0D0587				D			SET OF 10 PCS NUTS NYLOC M12	
0015	0D1005				D			WASHER; 10 PCS	
0016	000000								See S5
0017	000000								See S5
0018	0KL061			S	A			FOOT; 4 PCS	
0019	0D5133				D			SCREW; M5*25 IX; 10 PCS	
0020	000000								See S6
0021	0KQ366							PULLEY	
0022	0D0551							SCREW; 10 PCS	
0023	0D0757				D			MULTI200 MOTOR SUPPORT PLATE	
0024	034196				D			SCREW 5X8MM; 10 PCS	
0024	0D0546							WASHER; 10 PCS	
0025	0D6627							SENSOR; TRX/MULTI-TR200	
0025	0D6628				D			SENSOR; TRX/MULTI-TR200	
0026	033986					+		SCREW; 10 PCS	
0026	033987					+		SCREW; 10 PCS	
0026	0D0608							SCREW; 10 PCS	
0027	000000								See S7
0028	0D0764							MULTI200 MOTOR ROOL	
0029	0D6622				D			MICROSWITCH; TRX/TR-MULTI200	

Vue éclatée - Trémie fouloir / Exploded view hopper and feed arm / Explosionszeichnung - Trichter mit Druckhebel / Esploso - Tramoggia pestello / Despiece - Tolva pisón


+7(812)987-08-81



Model	All	Зип Общепит							
Table	SPMULTI	Page	6	Exploded view hopper and feed arm					
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes
0050	OKI992			S				FEED STICK	
0051	000000								See S16
0052	OD3620							CAM TRS	
0053	OD0643							SCREW; 10 PCS	
0054	OKJ599			S	A			BUSHING; 5 PCS	
0055	OD0643							SCREW; 10 PCS	See S18
0056	OD0643							SCREW; 10 PCS	
0056	OD2327							MILLED WASHER 14X4.5 SET X5	
0057	OD1583							HINGE PIN	
0058	OKJ002			S				EJECTOR DISK	
0059	OKQ458							REMOVABLE CUTTING CHAMBER	
0060	000000								See S19
0061	033596			S	A			PIN	
0062	OD0758							LOCKING HANDLE MULTI 200	
0063	000000								
0064	000000								
0065	000000								
0S15	OU0446			S	A			PLASTIC CAM	
0S16	OKQ425							FEED ARM ASSEMBLY MULTI 200	
0S17	653287							LEVER-OPERATED HOPPER	
0S18	OD0851							FEED PIN ASSEMBLY MULTI 200	
0S19	OD5134				D			HOPPER	



**Vue éclatée - Cutter / Exploded view cutter /
Explosionszeichnung-Cutter / Esploso Cutter /
Despiece - Trituradora**

+7(812)987-08-81



Vue éclatée / Exploded view / Explosionszeichnung / Esploso / Despiece

Platine électrique bi-vitesse / electric platinum bi-speed / elektrisches Platin Bi-Geschwindigkeit / platino elettrico vi-velocità / platino eléctrico Bivelocidad



Platine électrique vitesse variable / electric platinum variable speed / elektrisches Platin veränderliche Geschwindigkeit / platino elettrico velocità variable / platino eléctrico velocidad variable

Model	All									
Table	SPMULTI		Page	10	Exploded view electric platinum bi-speed					
Pos.	Spare Part	Alias Code	Repl. by	S	Info	Kit	Techn. Bulletin	Description	Notes	
0090	0D5136				D			SCREW; C 3*12 NYLON; 10 PCS		
0090	0D5137							WASHER; PE 4.5*10mm; PCS 10		
0091	033891				A			RESISTOR		
0092	0KJ778		0D7962		A			POWER BOARD; 3-PHASE		
0093	0D5814							BRACKET; COMPOSANT TRS		
0094	0KL072			S	A			COMMUTATOR 3 PHASE		
0095	0KQ662			S	A			CONDENSER		
0096	0U0242				D			HOLDER		
0097	0D5121		0D0810					BRACKET; CONDENSER; TRS MONO		
0098	000000								See S30	
0099	0D0018							TERMINAL BOARD		
0100	0D2848							PRINTED CIRCUIT FIXING SPACER (SET X6)		
0S30	0KQ426				A			FREQUENCY CONVERTER		