


Зип Общепит
vsezip.ru
+7(812)987-08-81



МРК5

Edition 20050101-

Зип Общепит
vsezip.ru
+7(812)987-08-81



Pos	Code	Description	Info
001	3023740	COVER	01/01/2005-
002	3108270	COVER ASSEMBLY	01/01/2005-
003	3199930	BALL HANDLE	01/01/2005-
004	3024280	PIN	01/01/2005-
005	3112370	MAGNET	01/01/2005-
006	3030890	ABRASIVE PLATE	01/01/2005-
007	3022230	MAGNETIC MICROSWITCH 250V-10W	01/01/2005-
008	3040740	GASKET	01/01/2005-
009	3080580	ABRASIVE CLOTH	01/01/2005-
011	MPK5-Pos.011	DOOR GASKET	01/01/2005-
012	MPK5-Pos.012	BIN DOOR	01/01/2005-
013	3199940	BIN DOOR LEVER	01/01/2005-
014	3199950	ELBOW	01/01/2005-
015	3199960	PIPE FITTING	01/01/2005-
016	3024300	SPACER	01/01/2005-
017	3229280	PIPE	01/01/2005-
018	3116950	PANEL BOARD	01/01/2005-
019	3103820	DRAIN PIPE	01/01/2005-
020	3075990	TIMER 240" 1F + HANDLE	01/01/2005-
022	3106490	STOP PUSH BUTTON	01/01/2005-
023	3106510	START PUSH BUTTON	01/01/2005-
028	MPK5-Pos.028	THREE-PHASE FAIRLEAD	01/01/2005-
028	MPK5-Pos.028	MONO-PHASE FAIRLEAD	01/01/2005-
031	3059360	SOLENOID VALVE	01/01/2005-
032	MPK5-Pos.032	PLUG	01/01/2005-
033	3173840	SHAFT	01/01/2005-
034	3113810	GASKET	01/01/2005-
038	3103830	GEASE SEAL	01/01/2005-
039	3103840	BEARING 6204 2RS	01/01/2005-
045	3029050	BELT POLY-V 483 J008	01/01/2005-
046	3173850	HUB POLY-V DP32J08	01/01/2005-
047	3173860	HUB	01/01/2005-
051	MPK5-Pos.051	CAPACITOR 16,5MF 450V	01/01/2005-
053	MPK5-Pos.053	FOOT	01/01/2005-