

Зип Общепит
vsezip.ru
+7(812)987-08-81




3G6SA

Edition 20120111-

Зип Ощепит

vsezip.ru

+7(812)987-08-81




Зип Общепит

vsezip.ru

+7(812)987-08-81

Modello Typ Model Modele Modelo

	3G6SA	3G6SA2	3G6SA4	4G6SB	4G6SB2	4G6SB4	4G6SB6
Num.cassetti Schublad Drawers Tiroirs Gabetas	-	2	4	-	2	4	6
Porte Türen Doors Portes Puertas	2	1	-	3	2	1	-



Page	Pos	Code	Description	Info
002	001	3043180	TOP BRACKET	15/12/2008-
002	002	3044810	FRAME TRIM	15/12/2008-
002	003	3044820	FRAME TRIM	15/12/2008-
002	004	3047140	TRAY	15/12/2008-
002	005	3047170	PIPE COIL	15/12/2008-
002	006	3165760	CONDENSER	07/04/2009-
002	007	3047920	PANEL-BOARD COVER	15/12/2008-
002	008	3048370	BRACKET	15/12/2008-
002	009	3048420	TOP BRACKET	15/12/2008-
002	010	3056800	GUIDE	15/12/2008-
002	011	3097570	FAN.PROT.	07/04/2009-
002	012	3088700	BOTTOM BRACKET	15/12/2008-
002	013	3178700	SILK-SCREE.PANEL	12/02/2010-
002	014	3125940	HORIZONTAL RISER	15/12/2008-
002	015	3129740	HULL	15/12/2008-
002	016	3129750	COVER	15/12/2008-
002	017	3129770	EVAP. GROUP	15/12/2008-
002	018	3131410	RACK	15/12/2008-
002	019	3131420	RACK	15/12/2008-
002	020	3131760	CONTROL BOARD	15/12/2008-
002	021	3131780	SIDE-BACK	15/12/2008-
002	022	3131910	FRAME TRIM	15/12/2008-
002	023	3135200	DRAIN TRAP	15/12/2008-
002	024	3143560	PANEL BOARD	15/12/2008-
002	025	6027270	FRAME	15/12/2008-
002	026	32A2200	POWER SUPPLY CABLE	15/12/2008-
002	027	32D0680	CABLE CLAMP	15/12/2008-
002	028	32D0750	TERMINAL BOARD	15/12/2008-
002	029	32D1350	CABLE CLAMP	15/12/2008-
002	030	32M3280	FAN	15/12/2008-
002	031	32M5920	TANGENTIAL FAN	15/12/2008-
002	032	32M7020	FAN MOTOR	07/04/2009-
002	033	32V1500	CONDENSER	15/12/2008-
002	034	32V3900	RELAY	15/12/2008-
002	035	32V3910	ENGINE CUTOUT	15/12/2008-
002	036	32V6010	EVAPORATOR PROBE NTC	15/12/2008-
002	037	32V8590	THERMOREGULATOR	15/12/2008-
002	038	32W3970	BIPOLAR SWITCH	15/12/2008-
002	039	32X0120	GROMMETØ 21	15/12/2008-
002	040	32X0140	GROMMET Ø13,5-Ø25	15/12/2008-
002	041	32X0230	GROMMET	15/12/2008-
002	042	33A0180	FILTER	15/12/2008-
002	043	33A1200	AUXIL.VALVE	15/12/2008-
002	044	3216230	COMPRESSOR	11/01/2012-
002	045	3216350	MOTOR UNIT	11/01/2012-
002	046	35L6080	GUIDE	15/12/2008-
002	047	36C5180	SWITCH PROT.	15/12/2008-
002	048	3137690	FOOT	19/04/2010-
002	049	36E5490	CONDENS. DRAIN	15/12/2008-
002	050	36Q1880	DRAIN PLUG	15/12/2008-
002	051	36Z2220	PROBE STOPPER	15/12/2008-

Page	Pos	Code	Description	Info
002	052	36Z2370	COND. TRAY	15/12/2008-
002	053	36Z2380	TRAY	15/12/2008-
002	054	3170300	SPRING	15/12/2008-
002	055	36G1140	PIN	15/12/2008-
002	056	3153310	CONTROL BOARD	15/12/2008-
003	001	3044110	BUSHING	15/12/2008-
003	002	3048420	TOP BRACKET	15/12/2008-
003	003	3088710	BUSHING	15/12/2008-
003	004	3125970	DOOR GASKET	15/12/2008-
003	005	3125980	GASKET	15/12/2008-
003	006	3130000	DRAWER UNIT 1/2	15/12/2008-
003	007	3130080	DRAWER FRAME 1/2	15/12/2008-
003	008	3131430	RIGHT DOOR	15/12/2008-
003	009	3131890	SUPPORT	15/12/2008-
003	010	6027740	DRAWER REPLACEMENT UNIT	15/12/2008-
003	011	36C2650	1/2 SUP PLUG	15/12/2008-
003	012	36D0630	PLUG	15/12/2008-
003	013	36M8080	RH GUIDE	15/12/2008-
003	014	36M8090	LH GUIDE	15/12/2008-