

Зип Общепит

vsezip.ru


+7(812)987-08-81



Зип Ощепит

vsezip.ru


+7(812)987-08-81



Зип Ощепит

vsezip.ru

+7(812)987-08-81



Seite	Pos	Kredtor Artikel Nr.	GB
001	001	56001484	KNOB
001	002	3516731550	CONTROL PANEL
001	002	59002079	CONTROL PANEL
001	003	56001485	HOLDER, LED
001	004	56001486	BOARD, HV/LV
001	005	56001210	SCREW
002	001	56001423	DOOR ASSY
002	002	12002624	KIT, SPRING/LATCH/CHOKE COVER
002	003	56001217	SCREW
002	004	12002870	KIT, DOOR HANDLE
002	005	56001406	WINDOW, INNER
003	001	56001217	SCREW
003	003	56001353	FUSE, 20 A
003	004	56001426	FUSE, THERMAL- CAVITY
003	005	56001230	SCREW
003	006	56001337	MOTOR, ANTENNA
003	007	56001454	POWER CORD
003	008	56001217	SCREW
003	009	56001428	AIR DEFLECTOR- REAR
003	010	56001210	SCREW
003	011	56001151	SCREW
003	012	56001429	WRAPPER
003	013	56001210	SCREW
003	014	56001411	BLOWER MOTOR ASSY
003	015	56001432	THERMAL CUTOUT, MAG
003	016	56001433	MAGNETRON
003	017	56001034	LAMP/ SOCKET ASSY
003	018	56001413	SWITCH, INTERLOCK ASSY
003	019	56001435	CAPACITOR- 1.05
003	020	56001436	DIODE
003	021	56001437	TRANSFORMER, HV
003	022	56001151	SCREW
003	023	56001222	SCREW
003	024	56001438	NLA- BASE
003	025	56001456	FOOT, BASE
003	026	56001439	HINGE, BOTTOM
003	027	56001440	AIR GUIDE
003	028	56001450	RIVET ASSY
003	029	56001441	TRAY ASSY
003	030	12002625	KIT, COVER/STIRRER BLADE/RIVETS
003	032	56001217	SCREW
003	033	56001218	BRACKET, CAPACITOR
003	034	56001051	NUT, HINGE
003	035	56001444	FUSE BLOCK / FILTER ASSY
003	036	56001445	GASKET
003	037	56001446	HARNESS, MAIN
003	038	56001151	SCREW
003	039	56001447	SUPPORT
003	040	56001448	SCREW
003	042	56001474	FUSE, HV
003	043	56001482	FOOT COVER
003	044	56001448	SCREW

Зип Общепит

vsezip.ru

+7(812)987-08-81

