




Зип Общепит

Position	Code	description
	5332180400	SLIDING BLOCK BLACK (PA66)
0	9811040850	SCREW
0	5313270059	HEATING ELEMENT SEAL
0	9815003750	INOX NUT M8 X 1 (BOILER/JUNCTION)
0	9815002850	INOX NUT M10 X 1.25 (BOILER/TAP)
001	7313285749	COVER
002	5332169200	MEASURING SPOON
003	5513200169	KNOB
004	5513200139	COVER ASSEMBLY
006	7313276659	WIRING TCO/LAMP
007	5932109700	CONTROL PANEL
008	6113211791	SPRING
009	5532107500	KNOB
013	5513200029	Change Over Switch
014	7313278259	TAP
015	5232101300	THERMOSTAT 125°
016	5232100600	THERMOSTAT 105°
017	536281	TUBE
018	6813210411	BOILER UPPER
019	533216	GASKET
020	5132109800	HEATING Element
022	7313286139	BOILER
023	6032107100	DIFFUSER
024	7313285849	GASKET
025	7313286109	SUPPORT
030	6213210431	CONNECTION
031	6132101300	CLIP
032	5313217701	O-RING D=3,85
033	5513220521	FILTER
034	5332122800	TUBE
035	534848	SUPPORT
036	5113211291	PUMP
037	5532146000	TUBE PTFE DI2-DE4 L=90 2BUSHES
038	7313286129	VALVE
039	5332120300	HINGE
040	536321	TUBE
041	5332125200	TUBE

Зип Общепит

vsezip.ru

7(812)987-08-81

043	7313275619	TANK
045	5332148400	VALVE
046	621986	RING
047	6213210451	DOWEL
049	6113211931	SPRING
051	5332120500	SPACER
052	535733	JOINT
053	5332120200	STOP
054	5332120700	BLOCK
055	535789	FROTHER
056	5332117200	PRESSING DEVICE
057	6113210481	TUBE DISTRIBUTING
058	5332120400	CUP PLATE
059	5332120000	TRAY
060	532233	RUBBER PAD
063	5532113400	BOTTOM
064	9824800009	CLIP CLAMP
066	5332108700	GASKET
067	5332109000	PISTON
068	6132100800	SPRING
069	5332111600	O-RING
070	7313280779	SUMP
071	7313285889	FILTER
072	7313285949	Large two-cup filter
073	6032107200	FILTER
074	534714	LEVER
075	7313285819	Large two-cup filter
076	7313285829	Small one-cup or pod filter