


Зип Оффепит

vsezip.ru

+7(812)987-08-81



The spare parts of 158

1. Ice Bucket	One
2. Up shell	One
3. Drip Tray	One
4. Base	One
5. Back shell	One
6. Hopper	One
7. Split flow Board	One
8. Left frame	One
9. Middle hopper	One
10. Front frame	One
11. Back frame	One
12. Motor	One
13. Back board	One
14. Up hopper	One
15. Lid	One
16. Door handle	One
17. Lid	One
18. Right frame	One
19. Central axis	One
20. Bearing	One
21. Blade	Four
22. Big nylon spacer	Three
23. Ice blade	Three
24. Small nylon spacer	Two
25. Bearing	One
26. Front board	One